

1.5.10 RL

In the **RL** tab, use the shortcut keys to quickly add RL (Delta robot language) instructions to the program. This tab is disabled by default when you start DRASudio. After you open the **RL** page in the menu, this tab is displayed.

