

2

- When there is no end effector installed, the default Tool Frame is defined on the flange as Tool Frame 0 (TF: 0).
- When an end effector is installed, the Tool Frame is defined on the end effector as the Tool Center Point (TCP). The TCP refers to the Word frame and transforms into a new Tool Frame as Tool Frame n (X_{TFn} , Y_{TFn} , Z_{TFn}).

