

## ■ Point operation areas

You can use the Motion Command area to send commands to the robot. The Point operation areas of the **Local** and **Global** tabs are shown and detailed as follows.

Local Point

Add

Clear

Delete

Save

Motion Command(mm)

Please choose one point

File: Global

Teach

☐ Check All

Maximum Top

Name:

Ext Teach

Rise height

Motion: MovP

Go

Drop height

Point operation areas of the **Local** tab

Global Point

Refresh

Clear

Motion Command(mm)

Please choose one point

File: Global

Teach

☐ Check All

Maximum Top

Name: GL\_1

Ext Teach

Rise height

Motion: MovP

Go

Drop height

Point operation areas of the **Global** tab

| Area                | Name        | Description                                                                                                                                                                                               |
|---------------------|-------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Local Point         | Add         | Add a local point. Up to 6,000 points can be saved in one project.                                                                                                                                        |
|                     | Delete      | Select the check box(es) in the Check column, and then click this button to delete the local point(s). After deletion, the IDs of the following points are shifted up.                                    |
|                     | Clear       | Select the check box(es) in the Check column, and then click this button to clear the data of the point(s).                                                                                               |
|                     | Save        | Save the point data.                                                                                                                                                                                      |
| Global Point        | Refresh     | Refresh the data in the <b>Global</b> tab.                                                                                                                                                                |
|                     | Clear       | Select the check box(es) in the Check column, and then click this button to clear the data of the point(s).                                                                                               |
| Motion Command (mm) | Teach       | Use the <b>JOG</b> subpage functions to move the robot to the target position. Select one global or local point, and then click <b>Teach</b> to save the current position of the robot to the point file. |
|                     | Ext Teach   | Teach the external axis.                                                                                                                                                                                  |
|                     | Check All   | Select all the check boxes in the Check column.                                                                                                                                                           |
|                     | <div></div> | A drop-down list box that displays the name of the external axis if one is connected.                                                                                                                     |
|                     | Go          | Select one point and then press and hold this button to move the robot to the point. Release the button to stop the robot.                                                                                |
|                     | File        | Displays "Local" for <b>Local</b> tab. Displays "Global" for <b>Global</b> tab.                                                                                                                           |
|                     | Name        | Displays the name of the currently selected point.                                                                                                                                                        |