


Dry Contact

The function of dry contact is to monitor the ADU and its surrounding environment. Please see the table below for detailed description.



DRY-CONTACT

Pin No.	Meaning	Function	Alarm	Normal Status	Alarm Status
Pin①	SYSTEM STATUS	Monitor the ADU status	Output over voltage	Closed	Open
Pin②	TEMP. STATUS	Monitor source & ambient temperatures	1. Source temperature > 20°C ^{*9} 2. Ambient temperature > 25°C (or 27°C) ^{*10}	Closed	Open
Pin③	FAN STATUS	Monitor fans' status	Fan missing/failure	Closed	Open
Pin④	HIGH-TEMP. ALARM	Monitor the environment temperature	Environment over temperature (Ambient temperature > 50°C)	Closed	Open
Pin⑤	RETURN -SIG ^{*8}	A common return point for all signals	N/A	N/A	N/A

^{*8}: RETURN-SIG=Signal Return

^{*9}: The operating temperature is 10°C~20°C.

^{*10}: The operating temperature is 20°C~25°C (or 27°C) according to the setup of DIP 1 switch (please see **Chapter 4 'DIP Switch'** for detailed information).