



Step 3 Launch PuTTY as shown below.



Step 4 Select **Category** → **Session** and **Connection type** → **Serial**.



Step 5 In the **Serial line** bar, enter your workstation's COM port number, which is connected to the Mini SNMP's COM port. In the **Speed** bar, enter the baud rate 2400.