

Chapter 5 : InsightPower G3 Mini SNMP Web

To configure the Mini SNMP via the InsightPower G3 Mini SNMP Web, please follow the steps below.

- Step 1** Make sure that your Mini SNMP is connected to the LAN. Plug a CAT5 cable into the Mini SNMP's network port.
- Step 2** Launch your web browser. In the address bar, enter the Mini SNMP's Host Name **http://InsightPower/** or IP Address. For encrypted connection, enter **https://InsightPower/** or **https://192.168.1.100/**.
- Step 3** When connection is established, the login page appears. Enter your account and password (default: admin/ password, case sensitive).



NOTE :

1. If you have previously changed the Mini SNMP's Host Name or IP Address, please connect with the new settings.
2. If the login page is accessible but you are unable to log in with the correct account and password, additional network configuration may be needed. The cause could be the difference between the IP subnet of the computer and that of the Mini SNMP. To solve this issue, please refer to **Chapter 7: Troubleshooting Q3**.

The **InsightPower G3 Mini SNMP Web** includes the information of **Monitor**, **Device** and **System**. Please refer to the following sections **5-1~5-3** for more information.