

- **Outlet Control**

Press the **Switch Bank** button to control the UPS output relay (on or off).

- **Power Fail/ Restore Simulation**

Click **Power Fail Test** or **Power Restore Test** button to let the Mini SNMP simulate UPS power failure or power restore event. This function allows you to test all of the connected software and verify whether they work properly or not. Please note that the simulation won't influence UPS operation.

The UPS will remain in its original operation mode.

● **Schedule**

Go to **Device** → **Management** → **Schedule** to arrange a weekly schedule or a specific schedule for the UPS.

- **Weekly**

You can select **Stop Action/ Shutdown/ Restart/ 10 seconds test/ Deep battery test** and set up the day and time you want the action to be executed every week.



- **Specific**

You can select **Stop Action/ Shutdown/ Restart/ 10 seconds test/ Deep battery test** and set up a specific date (YYYY-MM-DD) and time (hh:mm) to execute this action. Once the specific schedule has been set, the weekly schedule will be ignored.