

IPv4

This allows Administrator to configure the IPv4 parameters for the Mini SNMP.



- **DHCP Client**

Enable/ Disable DHCP. If enabled, DHCP server will automatically assign an IP address to the Mini SNMP.

- **IP Address**

The IP address for your Mini SNMP.

- **Subnet Mask**

The subnet mask for your network.

- **Gateway IP**

The IP address for network gateway.

- **DNS 1**

The IP address for Domain Name Server 1.

- **DNS 2**

The IP address for Domain Name Server 2.

- **Search Domain**

If the Host Name you provided cannot be found, the system will append the search domain to your Host Name.