

● MODBUS TCP

The Mini SNMP provides MODBUS TCP service for UPS monitoring. Users can enable or disable the MODBUS TCP service. Please set the slave ID and port according to the monitoring requirements. For cyber security, users can create a white/ block list in the Remote List column.



- **Enable Service (8 sessions max.):** You can enable the MODBUS TCP service. The maximum number of the sessions is eight.
- **Slave ID:** MODBUS Slave ID, the range is 1 to 254.
- **Port:** MODBUS TCP Port, the default value is 502.
- **MODBUS TCP Address Table:** A table of the defined parameters and alarms which UPS supports. Users can download the table for UPS monitoring.
- **Remote List:** Users can set to allow remote IP addresses with different permission levels to create a white/ block list for cyber security. The options in Access Level include Disable, Read Only and Read/ Write.

5-3-3 Notification

The Notification page includes SNMP Trap, Mail Server and Syslog these three selections.