

● Mail Server

You can set up an SMTP Server and specify a list of E-mail recipients who will receive notifications when events occur. The maximum number of recipients is 8.



NOTE:

If a DNS server is not available on the network, you need to manually assign an SMTP server address to enable the E-mail notification system.



- **SMTP Server Name or IP**

If a Host Name is entered, a **DNS IP** should be added. Please refer to **5-3-1 Ethernet**.

- **SMTP Server Port**

The mail server's port number.

- **Mail Title**

The subject of the notification E-mail.

- **Sender E-mail**

The sender's E-mail address.

- **Account**

The mail server login account.

- **Password**

The mail server login password.