

**NOTE:**

1. The communication port is insulated. Contacting the port does not present the risk of electric shock.
2. The CT wiring shall be fastened to avoid open circuit, which will lead to high-voltage risk and secondary circuit burning.

Table 2-10: APF Module Dimensions and Weights

Model	Dimensions (W × D × H)	Weights (kg)
PQCA-400-30-30MM4	484 × 641.5 × 190 mm	33 kg
PQCA-400-30-30MM3	484 × 641.5 × 190 mm	32 kg
PQCA-400-50-50MM4	484 × 641.5 × 190 mm	34 kg
PQCA-400-50-50MM3	484 × 641.5 × 190 mm	33 kg
PQCA-400-75-75MM4	484 × 641.5 × 190 mm	35 kg
PQCA-400-75-75MM3	484 × 641.5 × 190 mm	34 kg
PQCA-400-100-100MM4	484 × 731.5 × 190 mm	48 kg
PQCA-400-100-100MM3	484 × 731.5 × 190 mm	47 kg
PQCA-400-150-150MM4	484 × 731.5 × 190 mm	49 kg
PQCA-400-150-150MM3	484 × 731.5 × 190 mm	48 kg

2.5 Inspection

- **Exterior**

1. During the delivery of APF, unexpected situations may occur. Therefore, it is suggested that you inspect the exterior packaging. If you notice any damage, please immediately Contact Delta or Delta distributor from whom you purchased the unit.
2. The APF system cabinet and the power module are packed individually.

- **Interior**

1. Please check the APF's rating label and make sure that the APF complies with the product that you ordered.
2. Please check if any component is damaged or loosened.
3. Please check if there is any accessory missing.
4. The package list of the APF and HMI is as the chart below.