

2.5 Inspection

- **Exterior**

1. During the delivery of SVG, unexpected situations may occur. Therefore, it is suggested that you inspect the exterior packaging. If you notice any damage, please immediately Contact Delta or Delta distributor from whom you purchased the unit.
2. The SVG system cabinet and the power module are packed individually.

- **Interior**

1. Please check the SVG's rating label and make sure that the SVG complies with the product that you ordered.
2. Please check if any component is damaged or loosened.
3. Please check if there is any accessory missing.
4. The package list of the SVG and HMI is as the chart below.

Table 2-11: Accessories with SVG Module

No.	Item	Q'ty
1	Test Report	1 PC
2	CT Cable with Terminal	1 PC
3	Communication Line with Terminal	1 PC
4	Screw (M6 × 16L)	4 PCS

Table 2-12: Accessories with SVG System Cabinet

No.	Item	Q'ty
1	Cabinet Wiring Diagram	1 PC
2	Key to Cabinet Front Door	2 PCS

Table 2-13: Accessories with 7" HMI

No.	Item	Q'ty
1	Test Report	1 PC
2	Communication Line with Terminal	1 PC
3	M5 Fixing Screw	4 PCS