

Table of Content

Chapter 1 : Important Safety Instructions	5
1.1 Installation Warnings.....	5
1.2 Connection Warnings.....	5
1.3 Usage Warnings.....	6
1.4 Storage Warnings	8
1.5 Standard Compliance	8
Chapter 2 : Introduction	9
2.1 Product Introduction.....	9
2.2 PQC Series Mixed Fixed type SVG Product Category	10
2.3 Functions & Features.....	12
2.4 Product Structure and Appearance.....	13
2.4.1 HMI Display.....	13
2.4.1 Module Exterior & Dimensions	21
2.5 Inspection.....	24
Chapter 3 : Operation Modes	26
3.1 Pre-installation Confirmation.....	26
3.2 Installation Environment.....	26
3.3 SVG Cabinet Unpacking and Hoisting.....	28
3.3.1 Unpacking SVG Cabinet.....	29
3.3.2 Hoisting SVG Cabinet.....	30
3.4 SVG Cabinet Wiring.....	31
3.5 Module Installation	32
3.5.1 SVG Module Structure	32
3.5.2 Pluggable terminals	36
3.5.3 HMI Display Structure	40
3.5.4 Module Installation and Wiring.....	42
3.6 Load Current Detection for CT Installation and Wiring	48
3.6.1 CT Selection.....	48
3.6.2 Basic CT Installation & Wiring.....	49
Chapter 4 : SVG Operation Procedure.....	51
4.1 Inspection Before Start-up	51