

Table 3-3: Lmax and Cross-section Area When CT Secondary Current is 5A and under Single Module System

Cross-section Area of the Conductor	Lmax					
	15VA CT	20VA CT	25VA CT	30VA CT	35VA CT	40VA CT
2.5 mm ²	36 m	50 m	64 m	78 m	92 m	106 m
4 mm ²	58 m	80 m	103 m	125 m	148 m	157 m

3.6.2 Basic CT Installation & Wiring

- The CT for current detection shall be located on either grid side or load side
 - When it's an open loop, the CT for current detection shall be located on the load side to feed the detection signal to the SVG as shown in **Figure 3-27**. When it's a close loop, the CT for current detection shall be located on the grid side to feed the detection signal to the SVG as shown in **Figure 3-28**.
 - A set of three CTs must be provided for current detection in an imbalance load.
 - The CTs shall be oriented accurately. The default is that P1 is placed toward the grid. And the direction of all CTs must be the same.
 - The phase sequences of the detection signal of the CTs must not be changed.
1. The secondary output S1 of CT for R-phase detection must be connected to the terminal board R_S1, and the S2 outgoing line must be connected to the terminal board R_S2.
 2. The secondary output S1 of CT for S-phase detection must be connected to the terminal board S_S1, and the S2 outgoing line must be connected to the terminal board S_S2.
 3. The secondary output S1 of CT for T-phase detection must be connected to the terminal board T_S1, and the S2 outgoing line must be connected to the terminal board T_S2.



NOTE:

1. When compensating a three-phase system, single CT detection can be set up (only the R-phase CT is connected).
2. Corresponding setting shall be set up in accordance with CT wiring under compensation mode; otherwise, the compensation will not be working.
3. The CT wiring shall be fastened to avoid open circuit, which will lead to high-voltage risk and secondary circuit burning.