;Write a program to add ten 16-bit numbers stored in memory and store and display the result in decimal format.

TITLE SUM 10 15 BIT NUMBER FORM MEMORY
.MODEL SMALL
.DATA
NUMS DW 100, 200, 300, 400, 500, 600, 700, 800, 900, 1000
SUMS DW ?
.STACK
.CODE

MAIN PROC FAR MOV AX, @DATA MOV DS, AX

;; CALCULATING THE SUM MOV CX, 10 LEA BX, NUMS MOV AX, 00

L2: ADD AX, [BX]
INC BX
INC BX
LOOP L2
MOV SUMS, AX

;; CONVERTING TO DECIMAL MOV CX, 00 MOV BX, 10

L3: MOV DX, 00
INC CX
DIV BX
CMP AX, 00
PUSH DX
JG L3

;; PRINTING IN DECIMAL DIS: POP DX OR DX, 30H MOV AH, 02H INT 21H LOOP DIS

;; ENDING PROGRAM MOV AH, 4CH INT 21H MAIN ENDP

**END MAIN**