;Write an assembly language program to add ten 16-bit numbers stored in memory and store the result.

.MODEL SMALL .STACK 64 .CODE

MOV BX,0000H MOV AX,0000H MOV CX,000AH MOV DI,400H

AGAIN: ADD AX,[DI]
JNC NEXT

INC BX

NEXT: ADD DI,02H LOOP AGAIN MOV [DI],AX MOV [DI+2],BX MOV AH,4CH INT 21H

END