;Write an assemble language program in DEBUG to add four 16-bit numbers and test it.

.MODEL SMALL
.STACK 64
.DATA
VALUE DW 2555H, 1530H, 8743H, 9853H
.CODE

MOV AX,@DATA MOV DS,AX MOV BX,0000H MOV AX,0000H MOV CX,0004H LEA DI,VALUE

AGAIN: ADD BX,[DI]
JNC NOCARRY
INC AX

NOCARRY: ADD DI,2H

DEC CX
JNZ AGAIN
MOV [DI], BX
ADD DI,2H
MOV [DI], AX
MOV AH,4CH
INT 21H

END