;Write an assembly language program to add ten 16-bit numbers stored in memory and store the result.

.MODEL SMALL
.DATA

.CODE

MOV DX,0000H MOV BX,0400H MOV CL,00H

SET: INC CL MOV [BX],CL INC BX CMP BL,14H JZ GO JMP SET

GO:MOV BX,0400H

L1: CLC

ADD DL,[BX] ;Answer is in DX INC BX ADC DH,[BX] INC BX CMP BL,14H JZ L2 JMP L1

L2: MOV AH,4CH INT 21H

END