9/24/2019 Simulation Viewer

Lab Report

Performance

Your Score: 0 of 4 (0%)

Elapsed Time: 2 minutes 37 seconds

Task Summary

Actions you were required to perform:

Install the 100BaseTX network adapter

X Connect the computer to the network using Cat5e cable

X Verify that Office2 can communicate with the local network and the Internet

Actions you should not have performed:

X Do not install unnecessary components

Explanation

In this lab, your task is to complete the following:

- On the Office 2 workstation:
 - Select and install a new networking card that provides Fast Ethernet speeds (a faster network card is not
 - Connect the workstation to the local network using the appropriate cable.
- On the Office2 workstation, confirm that the workstation has a connection to the local network and the internet.

Complete this lab as follows:

- 1. Above the computer, select **Motherboard** to switch to the motherboard view of the computer.
- 2. In the Power Off warning, select **Yes** to turn off the computer.
- 3. On the Shelf, expand **Network Adapters**.
- 4. Identify the network adapter that supports Fast Ethernet 100BaseTX.
- 5. On the Shelf, drag the 100BaseTX network adapter to a free PCI slot on the computer. The 100BaseTX network adapter supports Fast Ethernet, which is all that is required.



- 6. Connect the computer to the network as follows:
 - a. Above the computer, select **Back** to switch to the back view of the computer.
 - b. Drag the Cat5 cable connector from the motherboard's NIC to the port of the 100BaseTX network
- 7. Verify the connection to the local network and the internet as follows:
 - a. Above the computer, select **Front** to switch to the front view of the computer.
 - b. Click the **power button** on the computer case.
 - c. After the workstation's operating system is loaded, right-click the Network icon in the notification area and select Open Network and Sharing Center. The diagram should indicate an active connection to the network and the internet.

You can also confirm the speed of the connection by clicking **Ethernet** in the Network and Sharing Center.