3/12/2020 Simulation Viewer

Lab Report

Your Performance

Your Score: 5 of 5 (100%) Pass Status: Pass Elapsed Time: 3 minutes 13 seconds Required Score: 100%

Task Summary

Actions you were required to perform:

- Connect the USB hub to the computer
- Connect the inkjet printer to a USB port
- Connect the laser printer into a USB port
- Connect the scanner to a USB hub
- Connect the external hard drive to a USB port

Explanation

In this lab, your task is to complete the following:

- Connect the USB hub to the computer.
- Connect the inkjet printer to a USB port.
- Connect the laser printer to a USB port.
- Connect the scanner to a USB port.
- Connect the external hard drive to a USB port.

Complete this lab as follows:

- 1. Connect the USB hub to the computer as follows:
 - a. Above the computer, select **Back** to switch to the back view of the computer.
 - b. On the Shelf, expand Hubs.
 - c. Drag the **External USB hub** to the Workspace.
 - d. Above the USB hub, select **Back** to switch to the back view of the USB hub.
 - e. On the Shelf, expand **Cables**.
 - f. Select **USB Cable (A/5-pin mini)**.
 - g. Under Selected Component, drag the USB Mini-B Vertical Connector to the USB port on the back of the USB hub.
 - h. Under Selected Component, drag the USB Type A Connector to an open USB port on the back of the computer.
 - i. Above the USB hub, select **Front** to switch to the front view of the USB hub.
- 2. Connect the USB hub to the computer as follows:
 - a. Above the inkjet printer, select **Back** to switch to the back view of the inkjet printer.
 - b. Identify the **USB port**.
 - c. On the Shelf, select **USB Cable (A/B)**.
 - d. Under Selected Component, drag the **USB Type B Connector** to the USB port on the inkjet printer.
 - e. Under Selected Component, drag the **USB Type A Connector** to an open USB port on the computer or on the front of the USB hub.
- 3. Connect the laser printer to a USB port as follows:
 - a. Above the laser printer, select **Back** to switch to the back view of the laser printer.
 - b. Identify the **USB port**.
 - c. On the Shelf, select **USB Cable (A/B)**.
 - d. Under Selected Component, drag the USB Type B Connector to the USB port on the laser printer.
 - e. Under Selected Component, drag the USB Type A Connector to an open USB port on the computer or on the front of the USB hub.
- 4. Connect the scanner to a USB port as follows:
 - a. Above the scanner, select **Back** to switch to the back view of the scanner.

3/12/2020 Simulation Viewer

- b. Identify the **USB port**.
- c. On the Shelf, select **USB Cable (A/B)**.
- d. Under Selected Component, drag the **USB Type B Connector** to the USB port on the scanner.
- e. Under Selected Component, drag the USB Type A Connector to an open USB port on the computer or on the front of the USB hub.
- 5. Connect the external hard drive to a USB port as follows:
 - a. On the Shelf, expand Hard Drives.
 - b. Drag the External Hard Drive onto the Workspace.
 - c. Above the external hard drive, select **Back** to switch to the back view of the hard drive.
 - d. Examine the *ports* on the hard drive. If necessary, zoom in to get a better view of the ports.
 - e. Identify the **USB port**.
 - f. On the Shelf, expand Cables.
 - g. Select **USB Cable (A/5-pin mini)**.
 - h. Under Selected Component, drag the USB Mini-B Vertical Connector to the USB port on the external
 - i. Under Selected Component, drag the **USB Type A Connector** to an open USB port on the computer or on the front of the USB hub.