Probe

Receive probe request

Listen on Channel C

Receive channel D

Probe succeed
C = D

Inform neighbours
and LPBR

Change Receive Channel
C -> D

Probe failed or
timeout

Inform neighbours
and LPBR

Inform neighbours

Probe Wait