


Copyright ©2018 Norman Dunbar

PUBLISHED BY MEMYSELFEYE PUBLISHING ;-)

http://qdosmsq.dunbar-it.co.uk/downloads/AssemblyLanguage/Issue_005/Assembly_Language_005.pdf


Licensed under the Creative Commons Attribution-NonCommercial 3.0 Unported License (the "License"). You may not use this file except in compliance with the License. You may obtain a copy of the License at http://creativecommons.org/licenses/by-nc/3.0. Unless required by applicable law or agreed to in writing, software distributed under the License is distributed on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied. See the License for the specific language governing permissions and limitations under the License.

This pdf document was created on 28/2/2018 at 17:01:16.




1	Preface	. 9
1.1	Feedback	9
1.2	Subscribing to The Mailing List	9
1.3	Contacting The Mailing List	10
2	Feedback on Issue 4	11
2.1	No Feedback so far!	11
3	Langton's Ant	13
3.0.1	The Program Listing	13
3.1	A Few 68020 Improvements, Perhaps?	25
3.1.1	Bit Field Calculations	26
4	Using the MC68020 - Part 2	27
4.1	Word and Long Memory Access Need Not Be Even!	27
4.2	Bit Field Instructions	28
4.2.1	Bit Fields	28
4.2.2	BFCHG - Test Bit Field and Change	30

4.2.3	BFCLR - Test Bit Field and Clear	30
4.2.4	BFEXTS - Extract Bit Field Signed	31
4.2.5	BFEXTU - Extract Bit Field Unsigned	31
4.2.6	BFFF0 - Find First One in Bit Field	32
4.2.7	BFINS - Insert Bit Field	32
4.2.8	BFSET - Test Bit Field and Set	33
4.2.9	BFTST - Test Bit Field	33
4.3	Converting Character and Decimal Numbers	33
4.4	Existing Instruction Upgrades	35
4.4.1	Branching and Linking	35
4.4.2	Division	35
4.4.3	Multiplication	36
4.4.4	MOVEC - Move To/From Control Register	37
4.5	Other New Instructions	38
4.5.1	BKPT - Hardware Breakpoint Support	38
4.5.2	CALLM - Call Module	38
4.5.3	CAS and CAS2 - Compare and Swap	39
4.5.4	CHK2 and CMP2 - Check/Compare Register Against Bounds	40
4.5.5	RTM - Return From Module	42
4.5.6	Coprocessor Instructions	42
5	Improving Langton's Ant	43
5.1	A 68020 Improvement, Perhaps?	43
5.1.1	Bit Field Calculations	44



4.1	Register Bit Field Conversion Table	29
4.2	5 Byte Bit Field Example	30
4.3	MC68020 Control Registers	37



3.1	Langtons Ant - Opening Blurb	4
3.2	Langtons Ant - Equates	4
3.3	Langtons Ant - Job Header	5
3.4	Langtons Ant - Command and Channel Definitions	5
3.5	Langtons Ant - Trap Subroutines	6
3.6	Langtons Ant - Start Here	6
3.7	Langtons Ant - Initialise the World	7
3.8	Langtons Ant - Initialising Constants	8
3.9	Langtons Ant - Register Usage	8
3.10	Langtons Ant - Start of Loop	9
3.11	Langtons Ant - Pixel Calculations	9
3.12	Langtons Ant - Rule 1	1
3.13	Langtons Ant - Rule 2	1
3.14	Langtons Ant - New Direction	1
3.15	Langtons Ant - Walk On	2
3.16	Langtons Ant - Plot New Cell Colour	3
3.17	Langtons Ant - Checking ESC	4
3.18	Langtons Ant - Delaying Tactics	4
3.19	Langtons Ant - The Ant's World	4
3.20	Langtons Ant - A 68020 Improvement	5

4.1	How to Blow Up an MC68008	28
4.2	Bit Field Negative Offsets Example	29
4.3	Example of the BFFFO Instruction	32
4.4	Example of the PACK instruction	34
4.5	Example of the UNPK instruction	34
4.6	Example of the CAS Instruction	39
4.7	Example of the CMP2 Instruction	41
5.1	Langtons Ant - Existing Bitmap Calculation	43
5.2	Langtons Ant - 68020 Bitmap Calculation	45
5.3	Langtons Ant - Existing Rule 1	45
5.4	Langtons Ant - Existing Rule 2	45
5.5	Langtons Ant - 68020 Rule 1	46
5.6	Langtons Ant - 68020 Rule 2	46



1.1 Feedback

Please send all feedback to assembly@qdosmsq.dunbar-it.co.uk. You may also send articles to this address, however, please note that anything sent to this email address may be used in a future issue of the eMagazine. Please mark your email clearly if you do not wish this to happen.

This eMagazine is created in LATEX source format, aka plain text with a few formatting commands thrown in for good measure, so I can cope with almost any format you might want to send me. As long as I can get plain text out of it, I can convert it to a suitable source format with reasonable ease.

I use a Linux system to generate this eMagazine so I can read most, if not all, Word or MS Office documents, Quill, Plain text, email etc formats. Text87 might be a problem though!

1.2 Subscribing to The Mailing List

This eMagazine is available by subscribing to the mailing list. You do this by sending your favourite browser to http://qdosmsq.dunbar-it.co.uk/mailinglist and clicking on the link "Subscribe to our Newsletters".

On the next screen, you are invited to enter your email address *twice*, and your name. If you wish to receive emails from the mailing list in HTML format then tick the box that offers you that option. Click the Subscribe button.

An email will be sent to you with a link that you must click on to confirm your subscription. Once done, that is all you need to do. The rest is up to me!

1.3 Contacting The Mailing List


I'm rather hoping that this mailing list will not be a one-way affair, like QL Today appeared to be. I'm very open to suggestions, opinions, articles etc from my readers, otherwise how do I know what I'm doing is right or wrong?

I suspect George will continue to keep me correct on matters where I get stuff completely wrong, as before, and I know George did ask if the list would be contactable, so I've set up an email address for the list, so that you can make comments etc as you wish. The email address is:

assembly@qdosmsq.dunbar-it.co.uk

Any emails sent there will eventually find me. Please note, anything sent to that email address will be considered for publication, so I would appreciate your name at the very least if you intend to send something. If you do not wish your email to be considered for publication, please mark it clearly as such, thanks. I look forward to hearing from you all, from time to time.

If you do have an article to contribute, I'll happily accept it in almost any format - email, text, Word, Libre/Open Office odt, Quill, PC Quill, etc etc. Ideally, a LATEX source document is the best format, because I can simply include those directly, but I doubt I'll be getting many of those! But not to worry, if you have something, I'll hopefully manage to include it.



2.1 No Feedback so far!



This program is something I remember writing many years ago when I was working in Aberdeen, which was some time in the 11 years prior to 1996 when I moved South of the Border, to deprive an Englishman of a woman and a job!

Back then, I wrote it in C using Borland Turbo C version 3 - probably the first program I wrote in C on a PC.

Anyway, it's a demonstration of something called *Emergent Behaviour* which is something that emerges form some set of rules, but what emerges was not specifically set up in the rules.

The way birds flock together, but manage not to crash into one another, for example, is based on a couple of rules

- Fly in the same direction as your neighbour;
- Don't fly too close nor too far away;
- Don't fly into things.

(Or something similar). A program was written some years ago that embodied those rules and the result was a flock of "boids" as the program was called. It's quite famous.

Anyway, Langton's Ant is another one of those, it has only two rules:

- If you are on a white cell, colour it black, turn right, step forward;
- If you are on a black cell, colour it white, turn left, step forward

That's all there is to it.

3.0.1 The Program Listing

I coded this program in SuperBASIC first of all, just to get my head around the algorithm. When run on QPC on my 10 year old laptop, it ran pretty damned quickly. And yes, the emergent behaviour

¹Joke!

was there after about 10,000 steps, as expected.²

Anyway, I then coded it in Assembly and was wondering just how much faster it would be. The answer? Pretty damned fast. I had to slow it down by inserting a one frame suspension of the job which actually made it run slower than SuperBASIC!

```
; LANGTON'S ANT
2
3
4
     A small routine to demonstrate how emergent behaviour can, ahem,
5
     emerge from simply rules.
6
    See Wikipedia: https://en.wikipedia.org/wiki/Langton's_ant
7
8
    The ant lives in a world which is a certain size wide and deep and
9
10
     the ends wrap around. It starts off in the middle, and walks in a
     downward direction - it makes no difference though, the behaviour
11
12
     will still emerge.
13
     If the ant lands on a cell which is white, it must turn it black,
15
     turn right, and walk on to the next cell in that new direction.
16
17
     If the cell was black, the ant must turn it white, turn left, and
     walk on to the next cell in the new direction.
18
19
20
     That is all the rules. Run the program and see what happens!
21
22
   ; Norman Dunbar
23
     17 February 2018.
24
25
     This source code is open source. Use it as you see fit and if you
    improve it, tell everyone and let them have the new source!
26
27
```

Listing 3.1: Langtons Ant - Opening Blurb

As ever, the code above introduces the program. Not much to see here, but there is a reference to the Wikipedia article about Langton's Ant.

```
28
   ; The sizes must be a power of two. We need this later when we limit
29
   ; them to anything between 0 and the size minus 1. If they are not a
30
31
   ; power of two, it doesn't work the way I've done things later!
32
33
   size_x
34
                                             ; Pixels across (width)
                        512
               equ
35
   size_y
36
                        256
                                             ; Pixels down (height)
               equ
37
38
   ; Color names, better than guessing the colour values. The ESC key is
39
   ; defined here, or its bit number in D1 after an IPC call.
40
41
42
   black
43
               equ
                        0
                                             ; Black cell colour
44
   red
```

²See the Wikipedia article at https://en.wikipedia.org/wiki/Langton's_ant

45		equ	2	; It's a red ant!
46	white	•		
47		equ	7	; White cell colour
48	green			
48 49		equ	4	; The world colour
50 51	esc			
51		equ	3	; Bit number for ESC

Listing 3.2: Langtons Ant - Equates

The next section of code, above, are the equates that are needed. Please note that the two sizes, size_x and size_y define the maximum width and height of the world in which the ant lives. They must be a power of two because if they are not, bad stuff will happen later.

Various colours are also defined here, plus the bit that we need to check to see if there was a press of the ESC key.

```
52
53
    ; Standard Job start.
54
55
    start
56
                 bra.s
                          Langton
                 dc.1
57
58
                 dc.w
                          $4afb
59
60
   name
                          nameEnd-name-2
61
                 dc.w
62
                 dc.b
                          "Langton's Ant"
63
   nameEnd
64
                 equ
```

Listing 3.3: Langtons Ant - Job Header

The code above is the standard QDOSMSQ job header. You should be getting used to seeing these by now!

```
66
67
   ; BLOCK command parameter block.
68
   Block
69
70
                dc.w
                         1,1
71
   xPos
72
                dc.w
                         Size_x/2, Size_y/2
                                               ; 256, 128 initial coordinates
73
74
   ; Check ESC key pressed IPC command string.
75
76
77
   ipc_command
78
                dc.b
                         9,1,0,0,0,0,1,2
                                               ; KEYROW(1)
79
80
    ; Screen channel name and window definition block.
81
82
83
   scr\_def
84
                dc.w
                         'scr_'
                                               ; No input needed, so SCR_
85
                dc.b
86
   winDef
```

Listing 3.4: Langtons Ant - Command and Channel Definitions

The section of code above sets up a few commands, the first is the BLOCK command to draw a 1 pixel by 1 pixel block in the middle of the ant's world.

Next to that is a command to allow the IPC processor to read the keyboard, specifically the equivalent of KEYROW(1) which is where we find the ESC key.

Finally, we have the definition for a SCR_ channel and a block of words to redefine the window we will set up on that channel. We do it this way because we only need to set the sizes of the ant's world, and hopefully, the assembler will work out the window definition for us. Lazy? Me?

```
93
 94
     ; Subroutines to do a trap, test DO and die horribly if there was
95
     ; an error.
96
97
     doTrap1
98
                            #1
                  trap
                           testD0
99
                  bra.s
100
101
     doTrap2
102
                            #2
                  trap
103
                            testD0
                  bra.s
104
105
     doTrap3
106
                  trap
                            #3
107
108
     testD0
109
                  tst.1
                            d0
110
                            suicide
                  bne.s
111
                  rts
112
113
     suicide
114
                            d0, d3
                  move.1
115
                            #mt_frjob, d0
                  moveq
116
                  moveq
                            \#-1, d1
117
                  trap
```

Listing 3.5: Langtons Ant - Trap Subroutines

The code above is a set of three simply subroutines to execute a trap instruction, check the error return and to kill the job if an error occurred.

```
120
121
      The main starting place. Open a scr_ channel. The channel ID will
122
      stay protected in A0.L throughout the rest of the code.
123
124
    Langton
125
                         scr_def, a0
                                                ; Screen channel
                1ea
126
                         #io_open,d0
                moveq
127
                         \#-1, d1
                moveq
                         #0,d3
128
                moveq
129
                 bsr.s
                         doTrap2
```

```
130
131
132
     ; The screen channel is open, make the window the requested size.
133
134
    Window
135
                           #sd_wdef, d0
                                                  ; Window definition
                 moveq
136
                           #0,d1
                 moveq
137
                 moveq
                           #0,d2
138
                 moveq
                           \#-1, d3
139
                           winDef, a1
                 1ea
140
                           doTrap3
                 bsr.s
141
142
143
     ; Set the paper to green.
144
145
     Paper
146
                           #sd_setpa,d0
                                                  ; Set paper to green
                 moveq
147
                 moveq
                           #green, d1
148
                 bsr.s
                           doTrap3
149
150
151
     ; And clear the entire screen.
152
153
    Cls
154
                           #sd_clear, d0
                                                  ; Cls
                 moveq
155
                           doTrap3
                 bsr.s
```

Listing 3.6: Langtons Ant - Start Here

This is the beginning of the real code. We open the channel to the screen, redefine it using the window definition block above, which has been filled in with the appropriate sizes by the assembler, set the paper to green and clear the screen.

Easy stuff, but anyone following http://qlforum.co.uk will know that I had a few problems and needed help. I was calling the wrong trap instructions, so instead of opening a channel, I was creating a weird job instead. Not good when you try to set paper colour on a job id rather than a channel id!

```
157
   ; The cells bitmap defines the ant's world. A bit is clear for white
158
159
   ; or set for black. Initially, all cells are white. It makes no
160
       difference - try setting the cells to FF (all black) and you'll see
161
    ; the same results.
162
163
    clearCells
164
                1ea
                         cells, a3
                                               ; The ant's world lives here
165
                move.1
                         a3, a2
                                               ; Use A2 for the loop
166
                moveq
                         #0,d0
                                               ; Byte counter
167
                                               ; Get width in pixels
                move.w
                         winDef(pc),d0
168
                1 s r . w
                         #3,d0
                                                 Calculate width in bytes
169
                mulu
                         winDef + 2(pc), d0
                                               ; Times height in pixels
170
                         clearNext
                bra.s
171
172
    clearLoop
173
                clr.b
                         (a2)+
                                               ; Clear one byte
174
175 clearNext
```

```
dbra d0, clearLoop; And the rest
```

Listing 3.7: Langtons Ant - Initialise the World

The ant's world is determined by a bitmap where one bit represents the white or black colour of a cell within the world. The code above clears out the bitmap to ensure that no random bits are to be found. The ant's world is coloured white at the start.

However, feel free to change this to black and fill each byte with FF_{hex} instead, if you wish. It is the rules that determine the behaviour.

It should be noted that the size of the ant's world should not exceed a word sized register when multiplying. The calculation is height*(width/8) because each byte represents 8 pixels across.

```
179
    ; Initialise A2 to point at the block command parameters. We need it
180
      in A1 actually, but A1 gets corrupted so we save it in A2. We also
181
      load up the initial position of the ant into D2. The top word of D2
182
      is the Across coordinate, the low word is the Down coordinate. D5
183
      is set to zero, for DOWN, which is the direction the ant is facing.
184
185
    ; Try changing it, see what happens.
    ; A5 is set to the IPC command string, which we need in A3 later. So
    ; as A3 is preserved through an IPC call, we can EXG these two.
187
188
                                             ; Needed in Al later
189
               1ea
                        Block, a2
190
                                             ; Hi = Across, Lo = Down
               move.1
                        xpos(pc), d2
191
               moveq
                        #0,d5
                                               Direction ant is walking
192
                                             ; Read KEYROW 1 for ESC key
                1ea
                        ipc_command, a5
```

Listing 3.8: Langtons Ant - Initialising Constants

The code above initialises some constants within the program. A2 which is never corrupted throughout the program, holds the address of the BLOCK command. We actually need that in A1 but that gets corrupted in places, so A2 is a good place to keep it safe.

D2 is initialised with the initial coordinates which have been set to be half the width and half the height of the ant's world. The upper word of D2 is the x or *across* coordinate and the lower word is the y or *down* coordinate.

D5 holds the direction that the ant is facing. It is initially facing down, but this can be changed if you wish, make sure you set it to aa value between zero and three though.

Finally, A5 holds the address of the IPC command to read the keyboard. This is actually something we need in A3 but that is needed elsewhere, so A5 was a handy place to keep it. We will swap those two registers over as and when we need to.

Talking of registers...

```
; REGISTERS USED BEYOND THIS POINT

; REGISTERS USED BEYOND THIS POINT

; D0 = Trap codes.

; D1 = Ant or Cell colour, red, white or black.

199 ; D2 = Hi word = Across, Lo word = Down coordinates.

200 ; D3 = Timeout for traps. -1 always.

; D4 = Bit number within Cells bitmap, for the current pixel.

202 ; D5 = Direction indicator. 0=Down, 1=Left, 2=Up, 3=Right.

203 ; D6 = Used to calculate A4 and D4 each time through the loop.
```

```
204; D7 = Copy of Direction, used in walking to next cell.
205
206; A0 = Channel Id
207; A1 = Used for trap calls.
208; A2 = Pointer to BLOCK command in job code. (Used in A1.)
; A3 = Pointer to Cells bitmap.
210; A4 = Pointer to byte in Cells where current coordinates is found.
   ; A5 = Pointer to IPC command to read KEYROW 1 for ESC key.
211
   ; A6 = Reserved for QDOS/SMSQ
213; A7 = Stack Pointer.
214 ;
215; Cells Bitmap.
216 ;
217; The cells array of bytes measures size_y * (size_x / 8) bytes
   ; and holds 1 bit for every cell in the screen (512 * 256 default)
218
   ; with a zero bit meaning a white cell and a 1 bit being black.
220
```

Listing 3.9: Langtons Ant - Register Usage

The comments above show the usage of the registers in the remainder of the program. As you can see, I'm just about using all of them for one thing or another.

```
222
223
    ; And here we start the main loop. We adjust the ant coordinates to
224
   ; fall into range. This is why we used a power of two as the sizes as
225
   ; it makes it easier to keep the coordinates in range 0 to size - 1.
226
227
   antWalk
228
                andi.w \#size_y -1,d2
                                             ; Make down 0 to size_y-1
229
                        d2
                swap
230
                                             ; Make across 0 to size_x-1
                andi.w
                        \#size_x -1,d2
231
                swap
                        d2
232
                move.1
                        d2,4(a2)
                                             ; Update block coordinates
233
234
235
    ; We have saved the adjusted coordinates in the BLOCK command's
236
    ; parameters, plot the current ant position with a red pixel. Good
237
    ; luck seeing that, it moves pretty quickly!
238
239
    plotAnt
240
                        \#sd_fill,d0
                                             ; Block command
                moveq
241
                        #red, d1
                                             ; It's a red ant of course!
                moveq
242
                        a2, a1
                                             ; Block parameter block
                move.1
243
                        doTrap3
                                             ; Won't return on error
```

Listing 3.10: Langtons Ant - Start of Loop

This is the code that runs our ant's world. Because we made the width and height of the world a power of two, we can subtract 1 to get a mask that will ensure that it will remain in range and this also helps in wrapping the ant's world around,top and bottom as well as left and right.

Given that width, for example, is 512, then anding the across coordinate with 511 will cause it to be in range 0 to 511 always. If it becomes 512 then and will reset it to 0. If it goes to minus 1, the and will reset it to 511 - and so, we have a simple way of wrapping the coordinates.

```
246; We need to get the current cell at this point. We want the address
    ; of the current byte in A4 and the number of the bit in that byte in
248; D4. At this point we have:
249
250; A3 = the cells bitmap start address.
251
   ; D2 = Across | Down coordinates.
252
253
254
255
    ; First work out the bit number in the cell's byte. This is simply
256
257
    ; the 7 - (across coordinate MOD 8).
258
259
    bitNumber
260
                        d2, d6
                                              ; Copy Across | Down coords
                move. 1
                                              ; Down | Across
261
                        d6
                swap
                                              ; Copy Across coordinate to D4
262
                move.w
                        d6, d4
                        #7,d4
263
                                              ; Mod 8 = 0 to 7
                andi.w
264
                neg.w
                        d4
                                              ; -7 to 0
265
                addq.w
                        #7,d4
                                              ; D4.W = bit number
266
267
    ; The byte within the row, which we calculate soon, is calculated as
268
    ; (across coordinate DIV 8). Easy.
269
270
271
    byteNumber
272
                1 s r . w
                        #3,d6
                                              ; Across div 8
273
274
275
    ; The correct row number in the cells bitmap is the Down coordinate
      multipled by (size_x DIV 8). This shouldn't exceed a word size. The
276
      result is added to A3 which is the start address of the cells
277
278
    ; bitmap and loaded into A4 as the byte address that we want.
279
280
   doRow
281
                        \#size_x, d7
                                              ; Pixels across
                move.w
                                              ; Now bytes across
282
                        #3,d7
                1 s r . w
283
                        d2, d7
                mulu
                                              ; Times down coordinate
284
                1ea
                        0(a3, d7.w), a4
                                              ; Address of correct row
285
                adda.w
                        d6, a4
                                              ; Correct byte in row
286
287
   ; Given the byte address in A4 and the bit number in D4, we can now
288
289
      test that individual bit. A zero is white while a 1 is black.
290
291
                btst
                                              ; 0 = white, 1 = black
                        d4, (a4)
```

Listing 3.11: Langtons Ant - Pixel Calculations

The code above takes the two coordinates of the ant's current cell and from them works out which bit in the bitmap represents that cell.

There are four things we need:

- The base address of the cells bitmap. This is held in A3.
- The correct "row" in the bitmap; This will be in D7.
- The correct byte within the row; This will be in D6

• The correct bit within the byte; This will be in D4.

The calculations are reasonably simple:

```
D4 = 7 - (Across \mod 8)
D6 = (Across \operatorname{div} 8)
D7 = Down * (width \operatorname{div} 8)
```

Once we have calculated all those, we need simply to load the byte address into A4 and the bit number into D4 and then we can test the bit to see if it is black or white, with zero being white.

```
293
294
    ; Rule 1: If the cell is white, turn it black, right turn, walk on.
295
296
    ruleOne
297
                bne.s
                         ruleTwo
298
                bset
                         d4, (a4)
                                                 Turn it black in the bitmap
299
                moveq
                         #black, d1
                                                 Colour for BLOCK command
300
                         #1,d5
                                                Direction - 1 = right
                subq.b
301
                bra.s
                         doDirection
                                              ; Prepare to walk on
```

Listing 3.12: Langtons Ant - Rule 1

This is the code for rule 1. If the cell that the ant arrived on is white then colour it black and make a right turn by subtracting 1 from the direction. We don't actually colour the cell here, we simply set the cell's new colour, black, in D1 ready to be plotted below.

```
303
      Rule 2: If the cell is black, turn it white, left turn,
304
                                                                   walk on.
305
306
    ruleTwo
307
                bclr
                         d4, (a4)
                                                Turn it white in the bitmap
                                              ; Colour for BLOCK command
308
                         #white, d1
                moveq
309
                addq.b
                         #1,d5
                                              ; Direction + 1 = 1eft
```

Listing 3.13: Langtons Ant - Rule 2

This is the code for rule 2. If the cell that the ant arrived on is black then colour it white and make a left turn by adding 1 to the direction. Again there is no actual colouring here, we simply set D1 to be white, ready for later.

```
311
312
    ; We have adjusted the direction. Make sure we restrict it to 0-3.
313
314
    doDirection
315
                andi.b
                         #3,d5
                                                ; Restrict to 0 to 3
316
                move.b
                         d5, d7
                                                ; Copy new direction
317
318
319
      Ready to walk on in the new direction.
320
321
      The directions are:
322
323
                UP
324
325
      LEFT 3
                     1 RIGHT
326
                0
```

```
DOWN
327
328
   ; So, if direction is up (2) then turn right = 1 and turn left = 3
329
330
   ; Plus 1 = turn left
331
332
   ; Minus 1 = turn right.
333
334
      If direction = down = 0 then Down
335
      If direction = right = 1 then Across + 1
   ; If direction = up
                            = 2 then Down
   ; If direction = left
                          = 3 then Across - 1
338
```

Listing 3.14: Langtons Ant - New Direction

Most of the code above is simply comments explaining the directions and how adding or subtracting 1 from the current direction equates to a left or right turn. However, we do have to be careful to make sure that the direction, in D5 is restricted to the values 0 through 3 only.

Because we are going to mess about with the new direction value, in the code below, we copy it to a working register, in this case, D7.

```
340 ;-
341
    ; Check the direction for Down, if not then skip, otherwise adjust
    ; the Down coordinate by +1.
342
343
344
    doWalk
345
                 bne.s
                          tryRight
346
347
    doDown
348
                 addq.w
                          #1,d2
                                                ; Down + 1
349
                 bra.s
                          doPlot
350
351
    ; Check if the new direction is Right. If so, adjust the Across
352
353
    ; coordinate by +1.
354
355
    tryRight
356
                 subq.b
                          #1,d7
357
                 bne.s
                          tryUp
358
359
    doRight
360
                          d2
                 swap
                                                ; Down | Across
                 addq.w
                         #1,d2
361
                                                ; Across + 1
362
                          d2
                 swap
                                                ; Across | Down
363
                          doPlot
                 bra.s
364
365
366
    ; Check if the new direction is Up. If so, adjust the Down coordinate
367
    ; by -1.
368
369
    tryUp
370
                 subq.b
                         #1,d7
371
                 bne.s
                          doLeft
                                                ; Must be left
372
373
    doUp
374
                 subq.w #1,d2
                                                ; Down -1
```

```
375
                 bra.s
                          doPlot
376
377
378
                direction must be Left. Adjust the Across coordinate by -1.
    ; The new
379
    doLeft
380
381
                 swap
                          d2
                                                ; Down | Across
382
                 subq.w
                          #1,d2
                                                  Across - 1
383
                          d2
                                                 Across | Down
                 swap
```

Listing 3.15: Langtons Ant - Walk On

Because we just ANDed the new direction to keep it in range, we could have set the Z flag. If so, the new direction is Down. In that case we add 1 to the current down coordinate in the low word of D2, and skip over the rest of this code section.

Assuming we are not in the downward direction, we check for a heading towards the right. Subtracting 1 will set the Z flag if we are now facing right. If so, we add 1 to the current across coordinate in the high word of D2 and skip the remaining processing.

If we are not facing to the right, are we facing up? Again, subtracting 1 from D7 will set the Z flag. If so, we need to subtract 1 from the ant's current down coordinate in register D2's low word.

Finally, we can only be facing to the left. We have to subtract 1 from the ant's position in the across direction, which is the high word of register D2.

We are now ready to take a step in the new direction as set in D2 but first we have to colour the current cell, which happens to be red at the moment, black or white according to register D1.

```
385
    ; We can overwrite the red ant at the current coordinates with either
386
387
    ; a black or a white cell. When we get here, D1 holds the correct
388
      colour.
389
390
    doPlot
391
                moveq
                        #sd fill, d0
                                              ; Block command
392
                move.1
                        a2, a1
                                              ; Block parameter block
393
                        doTrap3
                                              ; Won't return on error
                bsr
394
395
396
    ; We have overwritten the current coordinate, update the BLOCK
397
      parameters with the new coordinates - this is effectively a single
398
      step in the new direction.
399
400
    nowMove
401
                move. 1 d2, 4(a2)
                                             ; Update coordinates
```

Listing 3.16: Langtons Ant - Plot New Cell Colour

The code above plots a white or black cell over the red pixel at the ant's original position³ with a black or white pixel, depending on which of the two rules were activated by the ant's new position.

Once we have plotted the current cell in the correct black or white colour, we store the new coordinates for the ant in the BLOCK command's parameter, ahem, block. This means that when

³To be honest, the program runs so quick that you almost never see the red ant in the original plot but if you slow it right down, you might see it better.

we next pass through the loop, the ant's new coordinates will be plotted in red again, showing the ant's new position.

```
403
404
    ; Read the keyboard and check on the ESC key. If pressed, we are done
405
      here. If not pressed, go around again after suspending for a few
    ; frames.
406
407
408
    hadEnough
409
                         d5, -(a7)
                                              ; Direction gets corrupted.
                move.w
                                              ; We need the IPC command in A3
410
                exg
                         a3, a5
411
                         #mt_ipcom, d0
                                              ; IPC command coming up
                moveq
412
                bsr
                         doTrap1
                                              ; Dies on error
413
                move.w
                         (a7)+,d5
                                              ; Restore direction
414
                         a3, a5
                                              ; Cells address in A3 again
                exg
415
                         #esc,d1
                                              ; ESC pressed?
                btst
416
                         hangAbout
                                              ; No, pause then go around
                beq
                         #0,d0
                                              ; Yes, show no errors
417
                moveq
418
                bra
                         suicide
                                              ; Kill myself
```

Listing 3.17: Langtons Ant - Checking ESC

This section of code checks if the ESC key is being pressed, once around the main loop. Unusually, this call to QDOSSMSQ corrupts register D5 so we need to preserve it on the stack during the call. It also helps if you restore it afterwards - which I forgot to do and enjoyed many happy hours debugging a strange bug where the code ran for a while, then simply stopped.

```
420 :-
421
    ; Delay processing for a few clocks. Without this, the job has pretty
422
    ; much finished by the time you get to see the screen!
423
424
    hangAbout
                ; bra
                          antWalk
                                               ; Uncomment for full speed!
425
                moveq
                         #3,d0
                                                ; Adjust if too slow/fast
426
427
    d0Loop
                moveq
                         \#-1, d1
                                               ; Inner loop counter
428
429
    d1Loop
                nop
                                               ; Delay a bit
430
                                               ; Delay a bit more
                nop
431
                dbra
                         d1, d1Loop
                                                 End inner loop
432
                 dbra
                         d0, d0Loop
                                                ; End outer loop
433
434
                         antWalk
                                               ; Go around
                 bra
```

Listing 3.18: Langtons Ant - Delaying Tactics

When I first wrote this assembly version, I didn't have a delay. The code pretty much finished before the first appearance of the screen so I had to slow it down.

Initially I suspended the job for 1 frame, but that slowed it down quite a bit, too slow in fact - my SuperBASIC version was much quicker!

In the end, I slowed it down with a pair of NOPs executed 3*65536 times. If your QL or emulator is too slow (or still too fast) adjust the value in D0 to suit.

If you want to see exactly how fast the code is with no delays, uncomment the code at label hangAbout and be amazed!

```
; This is the ant's world. It is a bitmap representing the cells that
the thick the ant walks over. Each bit defines the colour of a cell. Zero is
the thick the thick the thick the colour of a cell. Zero is
the thick the thick the thick that
the thick the thick that
the thick the thick that
the thick that
the thick the thick that
the
```

Listing 3.19: Langtons Ant - The Ant's World

The final part of the listing simply defines a world for the ant. This world consists of one bit per cell and as there are 8 bits (or cells) per byte across the world, we divide by 8 to get the correct number of bytes.

We don't divide for the depth as we need one row per cell in the downward direction.

So that's it. Download the code (or type it in!) from the usual location - http://qdosmsq.dunbar-it.co.uk/downloads/AssemblyLanguage/Issue_005/ - assemble it GWASL works fine - and EXEC it. It will run for a bit creating what looks a fairly random pattern on the screen, but then, after about 10,000 iterations of the antWalk loop, it will head off in a straight line for no apparent reason. This is the emergent behaviour from two simple rules.

3.1 A Few 68020 Improvements, Perhaps?

As presented above, the code will actually assemble using the GWASL assembler that we have been using up until now in this series/footnoteAnd indeed, since I first started writing for *QL Today*, more years ago than I care to even begin to attempt to remember!.

Given how short the code above is, relative to some of the stuff in the last issue for example, can it be improved using the 68020 processor?

In a word, yes. Take the following code where we work out the bit in the ant's bitmap to first of all, determine the colour of the current cell, and then to set it according to the rules.

```
255
256
      First work out the bit number in the cell's byte. This is simply
257
    ; the 7 - (across coordinate MOD 8).
258
259
    bitNumber
260
                move.1
                        d2, d6
                                              ; Copy Across | Down coords
                                              ; Down | Across
261
                        d6
                swap
262
                move.w
                        d6, d4
                                                Copy Across coordinate to D4
263
                andi.w
                        #7,d4
                                              ; Mod 8 = 0 to 7
264
                neg.w
                        d4
                                              ; -7 to 0
                        #7,d4
265
                                              ; D4.W = bit number
                addq.w
266
267
    ; The byte within the row, which we calculate soon, is calculated as
268
269
    ; (across coordinate DIV 8). Easy.
270
271
    byteNumber
272
                1 s r . w
                        #3.d6
                                              : Across div 8
273
274
275
   The correct row number in the cells bitmap is the Down coordinate
276
      multipled by (size_x DIV 8). This shouldn't exceed a word size. The
   ; result is added to A3 which is the start address of the cells
```

```
; bitmap and loaded into A4 as the byte address that we want.
279
280
   doRow
281
                move.w
                         \#size_x, d7
                                               ; Pixels across
282
                1 s r . w
                         #3,d7
                                               ; Now bytes across
283
                                               ; Times down coordinate
                mulu
                         d2, d7
284
                1ea
                                               ; Address of correct row
                         0(a3, d7.w), a4
285
                adda.w
                         d6, a4
                                               ; Correct byte in row
286
287
      Given the byte address in A4 and the bit number in D4, we can now
288
289
      test that individual bit. A zero is white while a 1 is black.
290
291
                                               ; 0 = white, 1 = black
                btst
                         d4,(a4)
```


Listing 3.20: Langtons Ant - A 68020 Improvement

We can, should we wish to, replace all of the above using a bit field test instruction, or BFTST as described in BFTST - Test Bit Field on page 33.

Once you have read the introduction to bit fields - Bit Fields on page 28 you will realise that we no longer need to effectively reverse the bit numbering, as bit fields number from 0 upwards, but bit zero is the most significant bit!

Equally, we only need to calculate the bit number within the entire bitfield, we don't need to work out a bit number, a byte number and a row number first.

3.1.1 Bit Field Calculations



In the last issue, we took a long look at the addressing modes that are now available when using an MC68020 processor as found in QPC - and possibly, but I don't yet know - in other emulators too. The old BBQL¹ uses an MC68008 and cannot cope with the new stuff.

To assemble these 62020 instructions, you need a copy of Gwass available from George's web site.²

One problem I have noticed when using the 68020 instructions, when debugging with QMON, it sometimes gets a tad confused as to exactly which instruction it is executing! Given the age of QMON (and other monitor programs & debuggers) it's hardly surprising that it knows nothing about the 68020, it was current when the 68008 was still *de-rigeur*!

Here are the subjects I will cover in this issue, in relation to the 68020:

- Word and Long memory accessing need no longer be on an even address.
- New bit field instructions.
- Instructions to convert between character and decimal numbers.
- Upgrades to existing instructions.
- New instructions those not already covered above.

4.1 Word and Long Memory Access Need Not Be Even!

This is something that I've been quietly using and never noticed for a while, at least since QPC was upgraded, with George's help and input, to use a 68020 processor.

Once that happened, any time that I inadvertently accessed a word or long sized memory access, *nothing happened*! In the old days, and on the BBQL itself, the 68008 would have died horribly when that happened.

For example:

¹Black Box QL

²http://gwiltprogs.info/page2.htm

```
1
   start
2
                         oddAddress, a1
                1ea
3
                         (a1),d0
                move.w
4
5
   dc.b
                0
                                               ; This should cause an odd address
6
7
8
   oddAddress
9
                equ
```

Listing 4.1: How to Blow Up an MC68008

Of course, it doesn't really cause the processor a problem, it simply follows its programming and raises an Address Error Exception. Unfortunately, the QL's handling of such an exception is somewhat flawed and this will cause either a complete and utter lock up, or something far worse.

On QPC and on other computers or emulators with an MC68020 processor, the address exception no longer happens.

4.2 Bit Field Instructions

The M68000 family architecture supports variable-length bit field operations on fields of up to 32 bits. These instructions can be quite handy, as will be shown later, but first, what exactly is a bit field?

4.2.1 Bit Fields

A bit field is simply a number of consecutive bits in an effective address. A bit field is always specified in curly brackets '{' and '}' and there are two parts, the offset and the width, separated by a colon:

```
{offset:width}
```

The offset is the first bit numbering starts at zero for bit 31 and ends up at 31 for bit zero - beware!³

You can calculate the desired starting bit number by subtracting the highest bit you want from 31. So, for example, if you want bits 15, 14, 13, 12 and 11 of a register, subtract 15 from 31 to get 16. 16 would be the offset and there are 5 bits, so the bit field specification for the appropriate opcode, would be:

```
{16:5}
```

For example, in many opcodes, the size of the operand - .B, .W or .L - is specified in bits 5 and 6 of the opcode instruction word in memory. This is therefore a 2 bit wide bit field, starting at bit 31-5=26 and would be represented as follows:

```
{26:2}
```

This would be tagged onto the end of one of the new bit field instructions.

You should note that although the bits number from the left, bit 0 is the *most* significant bit and bit 32 the *least* significant bit, the bit fields start at the given offset and continue *towards the least*

³This *really* does my head in! All those years of counting from the right, now I have to start counting from the left *as well*.

significant bit for the defined width. This is the complete reverse of the bit numbering in the registers normally.

Table 4.1 is a handy conversion table. Just look for the bit number in a register that you want to start from and find the bit field offset value in the row above (or below) it.

```
31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16 
0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15
```

Table 4.1: Register Bit Field Conversion Table

For example, to start a bit field in register bit 7, we find 7 on the bottom row with 24 above it. So the offset part of our bit field will be 24. Equally, if we wanted to start from register bit 20, we find that on the top row with 11 below it, so 11 is our desired offset. Easy?

Offsets

The offset can be specified as a number from 0 to 31, no other numeric literals are permitted. However, the offset can also be a register name and in that case, all 32 bits can be used, giving an offset of anything from -2^{31} to $2^{32}-1$).

These rather large offsets are *only* for instructions acting on memory locations. It is rather difficult to imagine what a negative offset on a data register, for example, would resolve to!

If an address register, for example, holds a value that is used as the effective address in the instructions, then that is known as the base address. The most significant bit, bit 7, of the base address is offset zero in any bit field. All bit fields are relative to this particular bit.

Negative offsets are fairly simple to use. Assume you have the following code:

```
1
   start
2
                1ea
                         baseAddress, a1
                                                 ; Base address
3
                bfextu
                         (a1) \{0:8\}, d1
                                                 ; D1 gets $12
4
                         (a1) \{-32:8\}, d2
                                                 ; WILL NOT ASSEMBLE!
   ; ;;;
                bfextu
5
                move.1
                         \#-32, d2
                                                   Try again, offset
6
                         (a1)\{d2:8\},d2
                                                 ; D2 gets $9A
                bfextu
7
                         #24,d7
                                                   Offset
                move. 1
8
                move.1
                         #4,d6
                                                   Width
9
                         (a1) \{d7:d6\},d3
                bfextu
                                                 ; D3 gets $07
10
11
   negAddress
12
                dc.1
13
                         $9abcdeff
                                            ; Negative offset here
14
   baseAddress
                         $12345678
                                                 ; Base address here
15
                dc.1
```

Listing 4.2: Bit Field Negative Offsets Example

So the first thing to note is that attempting to use an numeric literals for the offsets will cause assembly errors is they are outside the range 0 to 31 inclusive. This is why we had to use D2 as the offset and the receiving register for one of the instructions.

The data read into D1 is the 8 bits from baseAddress which is the value $$12_{hex}$.

The value loaded into register D2 is from 32 bits *prior* to the address in A1, which corresponds to the address of negAddress. We therefore get 8 bits from that location loaded into D2 and that works out at $$9A_{hex}$.

Finally, D6 and D7 are set up to give a 4 bit width at offset 24 and the 4 bits at that offset from A1 is the nibble $\$7_{hex}$. That value is loaded into D3.

All the values loaded replace the full 32 bit width of the receiving registers.

Widths

Widths are a lot easier than offsets, especially when working with data in RAM. When specified as a number, the width is always between 1 and 32. Any other value results in assembly errors.

When a data register is used to specify the width, the actual width value is taken from the bottom 5 bits of the register and will thus be limited to values between 0 and 31. Hang on! Widths are supposed to be from 1 to 32 bits, not zero to 31. If the register value is zero, then the width is taken to be 32!

When dealing with memory bit fields, the offset and width can cause the bit field to span over 5 separate consecutive bytes in RAM. The processor can cope happily with this. For example:

bfextu (a1){6:32},d1 spans the 5 bytes from the address in A1 starting at offset 6 of that address (bit 1), passing through the next three bytes, and ending up in the 5th byte at its bit 2 (inclusive).

			By	te 1				Byte 2	Byte 3	Byte 4				Byte	5			
7	6	5	4	3	2	1	0	7-0	7-0	7-0	7	6	5	4	3	2	1	0
-	-	-	-	-	-	1	2	7-0 3-10	11-18	19-26	27	28	29	30	31	32	-	-

Table 4.2: 5 Byte Bit Field Example

In table 4.2, the top row is the bit numbers in the memory bytes at (A1) onwards. The bottom row is the bit numbers in the bit field {6:32}. For space reasons the three full bytes in the middle are shortened.

Lets examine the new instructions.

4.2.2 BFCHG - Test Bit Field and Change

The BFCHG instruction sets the condition codes according to the *current* value in a bit field at the specified effective address, then ones-complements the bit field.

For example, a bit field referencing 5 bits starting at bit 5 of D5, would resemble BFCHG D5{26:5}.

The instruction tests the bit field first, then sets the flags as follows before changing the bit field:

- X Not affected.
- N Set if the most significant bit of the field is set; cleared otherwise.
- Z Set if all bits of the field are zero; cleared otherwise.
- V Always cleared.
- C Always cleared.

4.2.3 BFCLR - Test Bit Field and Clear

The BFCLR instruction Sets condition codes according to the value in a bit field at the specified effective address and finally clears the specified bit field.

The instruction tests the bit field and sets the flags as follows:

• X - Not affected.

- N Set if the most significant bit of the field is set; cleared otherwise.
- Z Set if all bits of the field are zero; cleared otherwise.
- V Always cleared.
- C Always cleared.

An example to clear the three bits 6, 5 and 4 of the memory address that A1 points to, would be:

BFCLR (A1){1:3}

4.2.4 BFEXTS - Extract Bit Field Signed

The BFEXTS instruction extracts a bit field from the specified effective address location, sign extends it to 32 bits, and loads the result into the destination data register.

The instruction sets the flags as follows:

- X Not affected.
- N Set if the most significant bit of the field is set; cleared otherwise.
- Z Set if all bits of the field are zero; cleared otherwise.
- V Always cleared.
- C Always cleared.

For example, to extract the three bits 6, 5 and 4 of the memory address that A1 points to, into register D0, with bit 6 indicating the sign, would be:

```
BFEXTS (A1){1:3},D0
```

The flags are set according to the value in the bit field moved into D0, in this case. Bit 4 of the byte would end up in bit zero of D0, bit 5 in bit 1 and bit 6 would be sign extended into all bits from bit 2 to bit 31 (in the normal manner of numbering bits).

4.2.5 BFEXTU - Extract Bit Field Unsigned

The BFEXTU instruction is similar to the BFEXTS instruction above, but is unsigned. It extracts a bit field from the specified effective address location, zero extends it to 32 bits, and loads the results into the destination data register.

The instruction sets the flags as follows:

- X Not affected.
- N Set if the most significant bit of the field is set; cleared otherwise.
- Z Set if all bits of the field are zero; cleared otherwise.
- V Always cleared.
- C Always cleared.

For example, to extract the three bits 6, 5 and 4 of the memory address that A1 points to, into register D0, would be:

```
BFEXTU (A1){1:3},D0
```

The flags are set according to the value in the bit field moved into D0, in this case. Bit 4 of the byte would end up in bit zero of D0, bit 5 in bit 1 etc.

4.2.6 BFFF0 - Find First One in Bit Field

The BFFF0 instruction searches the source operand for the most significant bit that is set to a value of one.

The bit offset of that bit (the bit field *offset* in the instruction plus the *offset* of the first one bit in the bit field) is placed in the specified data register.

If no bits in the bit field are set, the result is the field offset plus the field width.

The instruction sets the flags as follows:

- X Not affected.
- N Set if the most significant bit of the field is set; cleared otherwise.
- Z Set if all bits of the field are zero; cleared otherwise.
- V Always cleared.
- C Always cleared.

An example to find the first set bit within the 9 bits of register D0, starting at bit 15 and extending down to bit 6, setting the result in register D1, would be:

```
BFFF0 D0{16:9},D1.
```

If there were no set bits in the bit field, the result in D0 would be 16+9 or 25, otherwise it would be 16+< bit number of set bit >. Bear in mind, the first one bit is the bit number in the bit field and not the bit number in the register or memory location. The bit numbers in the bit field start from zero and increase up to the field width minus 1.

This example should help:

```
1
  start
2
              clr.1
                                              No bits set in D0
3
               bfffo
                       d0{16:9},d1
                                             ; No bits set, so D1=16+9=25
4
5
                                                                   (Bit Field)
6
                                                       0123 4567 8 (BF Offset)
7
                       #$300, d0
                                                      0000 0011 0000 0000
              move.1
                                              $0000
8
              bfffo
                                             ; Bit 6 of BF set so D1=16+6=22
                       d0,{16:9},d1
```

Listing 4.3: Example of the BFFFO Instruction

The result is the bit field start plus the offset into the bit field where the most significant set bit is found. In our bit field, the starting offset is 16. The first set bit in the 9 bits making up the width of the bit field, is bit number 6 - starting at zero - in the bit field, so the result is 16 + 6 or 22.

A valid range of values in D1 would be 16+0 through 16+8 if a single bit in any position of the bit field was set, or 16+9 if no bits in the bit field were set.

If you need to find out exactly which bit in the register that relates to, subtract the result from 31. In this example, 31 - 22 gives 9 and indeed, it is bit 9 in the register which is the most significant set bit

4.2.7 BFINS - Insert Bit Field

The BFINS instruction inserts a bit field taken from the low-order bits of the specified data register into a bit field at the effective address location. This means that if you have a 3 bit wide bit field in the effective address, then the lowest three bits of the specified data register will be copied to that bit field.

The instruction sets the flags as follows:

- X Not affected.
- N Set if the most significant bit of the field is set; cleared otherwise.
- Z Set if all bits of the field are zero; cleared otherwise.
- V Always cleared.
- C Always cleared.

Continuing the example from above, to move the three bits of D0 into a three bit wide bit field of register D4 in bits 6, 5 and 4, we would use the instruction:

```
BFINS D0,D4{25:3}
```

Bit 0 of D0 would end up in bit 4 of D4, bit 1 would be in bit 5 and bit 2 would end up in bit 6.

4.2.8 BESET - Test Bit Field and Set

The BFSET instruction tests the bit field and sets the flags as follows and then sets all the bits in the field to 1.

- X Not affected.
- N Set if the most significant bit of the field is set; cleared otherwise.
- Z Set if all bits of the field are zero; cleared otherwise.
- V Always cleared.
- C Always cleared.

For example, to set all the bits in bits 6 to 9 (a total of 4 bits) of register D0, we would use the instruction:

```
BFSET D0{25:4}
```

4.2.9 BFTST - Test Bit Field

The BFTST instruction tests the specified bit field and sets the flags as follows:

- X Not affected.
- N Set if the most significant bit of the field is set; cleared otherwise.
- Z Set if all bits of the field are zero; cleared otherwise.
- V Always cleared.
- C Always cleared.

For example, to test the bits in the 3 bit wide bit field beginning at bit 13 of D4 (that's bit 13 numbering in the normal manner) we need to specify the following instruction:

```
BFTST D4{18:3}
```

4.3 Converting Character and Decimal Numbers

The BBQL and the MC68008 has always had the ability to addm subtract and negate Binary Coded Decimal numbers. However, it was never easy to create such things as there was no instructions that would convert an ASCII (or EBCDIC) string of digits, for example, into a BCD format, and vice versa.

With the MC68020 we have the PACK and UNPK instructions to help us do exactly that.

For other character code sets, the instructions take an immediate data portion, which is added to the characters when encoding, and subtracted when decoding. For ASCII or EBCDIC, this immediate data must be zero.

The PACK instruction has the two following formats:

```
PACK Ds, Dd, #data PACK - (As), - (Ad), #data
```

The Ds or (As) registers point at the source text, while the Dd or (Ad) registers point at the destination.

The instruction will only convert 2 bytes of the source into a single byte in the destination.

For example, if using the data register version, (D0.L) contains $$31323334_{hex}$, which is the ASCII character representation of 1234, it takes up the entire 32 bits of the register. All those '3' nibbles are effectively wasted space.

The instruction PACK D0,D1,#0 will convert the ASCII in D0 into the BCD value $$34_{hex}$ in D1.B.

To convert a string of digits, you need to use the in memory version, or do a few shifts along the way.

```
1
   start
2
                1ea
                         asciiDigits +8, a1
                                               ; Source ASCII string
3
                1ea
                         bcdDigits+4,a2
                                                ; Destination BCD buffer
4
                         #3,d2
                                                ; 4 pairs of digits to convert
                moveq
5
   loop
6
7
                         -(a1), -(a2), \#0
                                                ; Convert two bytes
                pack
8
                dbra
                         d2, loop
                                                ; Loop for more
9
                                                ; Done, bcdDigits = $12345678
                . . .
10
11
   asciiDigits
12
                dc.b
                         '12345678'
                                                ; = \$3132333435363738
13
14
   bcdDigits
15
                ds.1
                                                ; Space for result
```

Listing 4.4: Example of the PACK instruction

This code converts the 8 ASCII digits at asciiDigits - in reverse order - from \$3132333435363738_{hex} into a long word at bcdDigits which will end up containing the value $$12345678_{hex}$ thus, packing 64 bits of ASCII data into 32 bits of BCD data.

The UNPK instruction has two formats:

```
UNPK Ds, Dd, #data UNPK - (As), - (Ad), #data
```

And is simply the reverse of the PACK instruction. It converts a single byte into two separate ASCII (or EBCDIC) characters.

```
1
   start
2
                                              ; Source BCD buffer
               1ea
                        bcdDigits+4,a1
3
                        asciiDigits +8, a2
                                              ; Destination ASCII string
               1ea
4
               moveq
                        #3,d2
                                              ; 4 BCD digits to convert
5
6
  loop
7
                        -(a1), -(a2), #0
                                              ; Convert two bytes
               unpk
8
               dbra
                        d2,loop
                                              ; Loop for more
9
                                                Done, asciiDigits = 12345678
```

```
10
11 asciiDigits
12 ds.b 8 ; Space for ASCII result
13
14 bcdDigits
15 dc.1 $12345678 ; Source BCD number
```

Listing 4.5: Example of the UNPK instruction

Once again, the data are converted in reverse so the initial buffer pointers have to be one past the end of the buffers' last character.

The long word at bcdDigits, $$12345678_{hex}$ is converted back into the string $$3132333435363738_{hex}$ or ASCII '12345678' by the above code.

4.4 Existing Instruction Upgrades

Some instructions have changed since their usage in the good old MC68008 installed in the original BBQL. These are discussed below.

4.4.1 Branching and Linking

Currently, on the BBQL, we can have short (8 bit) or word branches in the Bcc, BRA and BSR instructions. These are two's compliment (aka signed) displacements allowing for forward and backward branching. In the MC68020 we now have a long sized branch as well with all 32 bits being permitted.

Using BSR as an example, we now have the following:

BSR.S and BSR.B - this form always assembles to an 8 bit displacement branch which requires two bytes in the binary code.

BSR.W - this form always assembles to a 16 bit displacement branch which requires four bytes in the binary code.

BSR.L - this form always assembles to a 32 bit displacement branch which requires six bytes in the binary code.

If you don't specify a size for the branch instruction, then it depends on whether your assembler has been configured to always use a 16 bit displacement or if you, like me, have configured it to try an 8 bit displacement and error out if the displacement is too far.

Note, the various *Decrement and Branch Unless Condition* (DBcc) instructions have *not* changed, they are restricted to a word sized, 16 bit displacement as before.

The LINK instruction now also has a 32 bit displacement. If you use the old instruction LINK An, #displacement, you continue to get the 16 bit displacement version. You can now. however, also specify a size of .W to force a 16 bit displacement. LINK.W An, #displacement.

To force a 32 bit displacement, specify a size of .L as in LINK.L An, #displacement.

4.4.2 Division

On the BBQL we have played around with the DIVU and DIVS instructions which are word sized in that they return a pair of 16 bit values one for the quotient and one for the remainder. Effectively, a

32 bit value is divided by a 16 bit value to return a pair of 16 bit values in a single data register. The top word is the remainder and the low word is the quotient.

The format of these instructions was always like DIVS #1234, D0 and there was no need to specify a size - .B, .W or .L - because it was always .W.

On the MC68020 we now have the ability to divide 32 and 64 bit numbers by 32 bit ones, resulting in a 32 bit number for the quotient and another for the remainder. We still have the existing word sized divides, but now you need to specify a size of '.W' to indicate your wish to use the old style. Assemblers will still accept the old style of missing out the size specifier and act accordingly to assemble the old word sized instructions.

There are a further three assembly formats for the divide instructions:

DIVS <EA>, Dn - This form divides a 32 bit long word by another 32 bit long word. The result is a 32 bit quotient in the specified register, with the remainder being discarded. A handy integer division instruction.

DIVS <EA>,Dr:Dq - This form divides a 64 bit quad word (in any two data registers) by a 32 bit word taken from the effective addresss. The result is a long-word quotient in the Dq register, and a long-word remainder in the Dr register.

DIVSL.L <EA>,Dr:Dq - This form divides a 32 bit long word by another 32 bit long word. The result is a 32 bit quotient in the Dq register, and a 32 bit remainder in the Dr register. You should note that this instructions has an 'L' tagged on as well as the '.L' for the size. DIVSL.

Although I've used DIVS in the above examples, the DIVU instructions are identical.

Two special conditions may arise during division:

- Division by zero causes a trap.
- Overflow may be detected and set *before* the instruction completes. If the instruction detects an overflow, it sets the overflow condition code, and the operands are unaffected.

The flags are set as follows:

- X Not affected.
- N Set if the quotient is negative; cleared otherwise; undefined if overflow or divide by zero occurs.
- Z Set if the quotient is zero; cleared otherwise; undefined if overflow or divide by zero occurs.
- V Set if division overflow occurs; undefined if divide by zero occurs; cleared otherwise.
- C Always cleared.

4.4.3 Multiplication

Upgrades to the MULU and MULS instructions are similar to those of the division instructions above. Whereas up until now we have been limited to multiplying two 16 bit words to get a 32 bit result, we now have the ability to multiply two 32 bit long words together to give either a 32 bit long word result, or a 64 bit quad word result.

MULS.L <EA>,Dn - this form multiplies the 32 bit effective address value by the data register and stores the lowest 32 bits of the result in the data register. The upper 32 bits of the result are discarded.

MULS.L <EA>, Dh-D1 - this form multiplies the 32 bit effective address value by the data register and stores the highest 32 bits of theb result in the Dh register and the lowest 32 bits of the result in

the D1 register. Nothing is discared.

The multiplication instructions set the flags as follows:

- X Not affected.
- N Set if the result is negative; cleared otherwise.
- Z Set if the result is zero; cleared otherwise.
- V Set if overflow; cleared otherwise.
- C Always cleared.

For MULS, overflow, setting V = 1, can occur only when multiplying 32-bit operands to yield a 32-bit result. Overflow occurs if the highest 32 bits of the quad-word product are not the sign extension of the lowest 32 bits.

For MULU, overflow, setting V = 1, can occur only when multiplying 32-bit operands to yield a 32-bit result. Overflow occurs if any of the high-order 32 bits of the quad-word product are not equal to zero.

Overflow cannot occur when the product is a 64 bit quad word.

4.4.4 MOVEC - Move To/From Control Register

This instruction is only available on the has two separate formats:

MOVEC Rc, Rn MOVEC Rn, Rc

The instruction is privileged, so must be run in supervisor mode.

Register Rc is a *control* register, see table 4.3, while register Rn is a normal register.

Moves the contents of the specified control register (Rc) to the specified general register (Rn) or copies the contents of the specified general register to the specified control register.

This is always a 32-bit transfer, even though the control register may be implemented with fewer bits. Unimplemented bits are read as zeros.

What is a control register? On the MC68020 we have the following control registers:

Control Register	Description
SFC	Source Function Code
DFC	Destination Function Code
USP	User Stack Pointer
VBR	Vector Base Register
CACR	Cache Control Register
CAAR	Cache Address Register
MSP	Master Stack Pointer
ISP	Interrupt Stack Pointer

Table 4.3: MC68020 Control Registers

The flags are not affected by these instructions.

- X Not affected.
- N Not affected.
- Z Not affected.
- V Not affected.
- C Not affected.

4.5 Other New Instructions

4.5.1 BKPT - Hardware Breakpoint Support

This is a new instruction (from the MC68010 onwards) which is useful for hardware debuggers and is unlikely to be of any use in QL programs. However, I have been wrong in the past!

The manual has this to say about the instruction:

For the MC68010, a breakpoint acknowledge bus cycle is run with function codes driven high and zeros on all address lines. Whether the breakpoint acknowledge bus cycle is terminated with \overline{DTACK} , \overline{BERR} , or \overline{VPA} , the processor always takes an illegal instruction exception. During exception processing, a debug monitor can distinguish different software breakpoints by decoding the field in the BKPT instruction.

For the MC68000 and MC68008⁴, the breakpoint cycle is not run, but an illegal instruction exception is taken.

For the MC68020, MC68030, and CPU32, a breakpoint acknowledge bus cycle is executed with the immediate data (value 0-7) on bits 2-4 of the address bus and zeros on bits 0 and 1 of the address bus. The breakpoint acknowledge bus cycle accesses the CPU space, addressing type 0, and provides the breakpoint number specified by the instruction on address lines A2-A4. If the external hardware terminates the cycle with \overline{DSACKx} or \overline{STERM} , the data on the bus (an instruction word) is inserted into the instruction pipe and is executed after the breakpoint instruction. The breakpoint instruction requires a word to be transferred so, if the first bus cycle accesses an 8 bit port, a second bus cycle is required. If the external logic terminates the breakpoint acknowledge bus cycle with \overline{BERR} (i.e. no instruction word available), the processor takes an illegal instruction exception.

For the MC68040, this instruction executes a breakpoint acknowledge bus cycle. Regardless of the cycle termination, the MC68040 takes an illegal instruction exception.

For more information on the breakpoint instruction refer to the appropriate user's manual on bus operation.

This instruction supports breakpoints for debug monitors and real-time hardware emulators.

So that's clear then? It's hardware, only Dave and Nasta (and a few others) will understand any of the above!

The flags are not affected.

- X Not affected.
- N Not affected.
- Z Not affected.
- V Not affected.
- C Not affected.

4.5.2 CALLM - Call Module

The CALLM instruction saves the *Current Module State* on the stack and loads a new module state from the destination.

The format of the instruction is:

⁴Excuse me? My 68008 manual, a Motorola official one, makes no mention of this instruction for either the MC68008 or the MC68010!

CALLM #data, <EA>

This instruction, and RTM require external hardware to be effective.

The effective address of the instruction is the location of an external module descriptor.

A module frame is created on the top of the stack, and the current module state is saved in the frame. (Program counter etc.)

The immediate operand specifies the number of bytes of arguments to be passed to the called module and allows RTM to tidy the stack afterwards.

A new module state is loaded from the descriptor addressed by the effective address.

The flags are not affected.

- X Not affected.
- N Not affected.
- Z Not affected.
- V Not affected.
- C Not affected.

See also RTM which is used to return from a CALLM. Also note that these two instructions have been removed from the MC68040 onwards.

4.5.3 CAS and CAS2 - Compare and Swap

The format of the CAS instruction is:

```
CAS.size Dc,Du,<EA>
```

The size can be .B, .W or .L.

The CAS, Compare and Swap, instruction subtracts the value in the 'compare' register (Dc) from the effective address which is the destination also, and sets the condition codes accordingly.

If the Z flag gets set, the value in the 'update' register (Du) is moved to the destination.

If the Z flag was not set by the instruction, the contents of the effective address are moved to the Dc register.

The CAS instruction sets the flags as follows:

- X Not affected.
- N Set if the most significant bit of the field is set; cleared otherwise.
- Z Set if the result is zero; cleared otherwise.
- V Set if the compare generates an overflow; cleared otherwise.
- C Set if the compare generates a carry; cleared otherwise.

An example of the CAS instruction is as follows. I admit it's a little contrived, but it shows what happens.

```
start
2
                                             ; Where the compared data lives
                        label, al
               1ea
3
                                             ; Dc = compare register
              moveq
                        #2.d2
4
                        #$87654321,d3
                                             ; Du = update register
              move.1
5
                        d2, d3, (a1)
                                             ; Compare (A1) with D2
              cas.1
6
                                             ; IF (A1) = D2 THEN
7
                                                  LET (A1) = D3
                                               ELSE
```

Listing 4.6: Example of the CAS Instruction

So, in the above, the first CAS compares the value at (A1) which is $\$00001234_{hex}$ with the value in D2 which is $\$00000002_{hex}$ and they are not equal, so D2 gets loaded with the value at (A1) and becomes $\$00001234_{hex}$.

The second CAS compares the value at (A1) which is still $\$00001234_{hex}$ with the value in D2 which is now also $\$00001234_{hex}$ and they are obviously equal, so the long word at (A1) gets set to the value in D3 which happens to be $\$87654321_{hex}$.

The CAS2 instruction is similar, except that it uses two 'compare' registers and two 'update' registers. The format is:

```
CAS2.size Dc1:Dc2,Du1:Du2,(Rn1):(Rn2)
```

This instruction compares memory operand 1 (Rn1) to compare operand 1 (Dc1). If the operands are equal, the instruction compares memory operand 2 (Rn2) to compare operand 2 (Dc2). If these operands are also equal, the instruction writes the update operands (Du1 and Du2) to the memory operands (Rn1 and Rn2).

If either comparison fails, the instruction writes the memory operands (Rn1 and Rn2) to the compare operands (Dc1 and Dc2).

The size can be .W or .L.

The CAS2 instruction sets the flags as follows:

- X Not affected.
- N Set if the most significant bit of the field is set; cleared otherwise.
- Z Set if the result is zero; cleared otherwise.
- V Set if the compare generates an overflow; cleared otherwise.
- C Set if the compare generates a carry; cleared otherwise.

Both CAS and CAS2 instructions access memory using locked or read-modify-write transfer sequences, providing a means of synchronizing several processors in a multi-processor system.

4.5.4 CHK2 and CMP2 - Check/Compare Register Against Bounds

The CHK2 and CMP2 are similar instructions except that while the latter simply sets the condition codes in the status register depending on the results of the comparison, the former traps out through an exception vector. A tad excessive if you ask me! ;-)

The CHK2 instruction has the format:

```
CHK2.size <EA>,Rn
```

It looks in memory at the effective address specified for two bytes, words or long words and compares the specified register, which can be a data or address register, with the two values.

The two values are the (signed) lower and upper bounds for the comparison. The data at the address specified in the effective address is the lower bound. The data at that address plus 1, 2 or 4,

depending on the size, is the upper bound.

The flags are set as follows:

- X Not affected.
- N Undefined.
- Z Set if Rn equals either boundary value; cleared otherwise.
- V Undefined.
- C Set is Rn is out of range; cleared otherwise.

In operation, if the register value is equal to, or falls between the two bounds, then execution continues as normal and the C flag is cleared. If the register value happens to equal one of the bounds, then the Z flag will be set.

If the register value is out of bounds, then the exception is raised. A tad harsh, so let's look at a gentler approach. The CMP2 instruction.

This instruction takes the format:

```
CMP2.size <EA>,Rn
```

It sets the flags exactly as the CHK2 instruction does.

It operates exactly as the CHK2 instruction just described, but does not raise an exception if the value is out of bounds. This can be useful when comparing a value in a register to determine if it is a digit, for example, as per the following snippet:

```
start
                                               ; Where we find user input
2
                         inputBuffer, al
                1ea
3
4
   checkLoop
5
               move.b
                        (a1)+,d0
                                               ; Grab one character
6
                                               ; Got a digit?
               cmp2.b
                        digitBounds, d0
7
               bcc.s
                        gotDigit
                                               ; Yes, handle it
8
                                              ; No, check for a linefeed?
               cmpi.b
                        #10,d0
9
                        allDone
                                               ; End of input
               beq.s
10
                                               ; Not a digit, do something else
11
                        checkLoop
                                               ; Keep going
               bra.s
12
13
   allDone
14
               moveq
                        #0,d0
                                               ; Signal done
15
                                               ; Back to caller
                r\,t\,s
16
17
   gotDigits
18
                                               ; Handle digit input here
19
               bra.s
                        checkLoop
                                               ; Loop around
20
21
   digitBounds
                         '0','9'
22
                                               ; Range of valid digits
               dc.b
```

Listing 4.7: Example of the CMP2 Instruction

This is much less hassle than checking the character in D0 with a '0' and skipping out if the flags show that D0 was lower than a '0' then doing something similar for a '9'. I also happen to think that it's a lot easier to read the code done in this way.

4.5.5 RTM - Return From Module

This instruction, and CALLM require external hardware to be effective.

This instruction, is used to terminate a CALLM instruction. It reloads the module state from the stack. The instruction format is:

RTM Rn

The register can be a data or address register.

A previously saved module state is reloaded from the top of stack. After the module state consisting of program counter, status word etc, is retrieved from the top of the stack, the caller's stack pointer is incremented by the argument count value in the module state.

Given that this instruction has been removed from the MC68040 onwards, there's probably not much use for it in QL programs. See also CALLM.

The flags are set according to the word on the stack.

4.5.6 Coprocessor Instructions

There are numerous floating point co-processor instructions which, for now at least, are beyond the scope of the eComic!⁵ I'm pretty certain that George Gwilt, my faithful reader, has written a document on these instructions. The document can be found on the Sinclair QL Homepage.⁶

⁵I don't have a genuine MC680020 to play with, only QPC.

⁶http://www.dilwyn.me.uk/docs/asm/fpu.zip



So, given that we now fully understand these new fangled 680020 instructions, can we improve Langton's Ant?

5.1 A 68020 Improvement, Perhaps?

As presented earlier in this issue, the code will actually assemble using the GWASL assembler that we have been using up until now in this series¹.

Given how short the code above is, relative to some of the stuff in the last issue for example, can it be improved using the 68020 processor?

In a word, yes. We have to work out a number of things each time through the loop:

- The address of the start of the row of bytes where the current cell can be found;
- The Address of the byte, within the row, representing the current cell;
- The Address of the bit, within the byte, representing the current cell;

We need this to enable us to determine the current cell's colour and from that where the next cell will be, plus we also need to change the colour to black or white according to whichever rule we activated.

The following code extract is where we work out the bit we need to set or clear in the ant's bitmap.

¹And indeed, since I first started writing for *QL Today*, more years ago than I care to even begin to attempt to remember!

```
261
                         d6
                                               ; Down | Across
                swap
                move.w
262
                         d6, d4
                                               ; Copy Across coordinate to D4
263
                andi.w
                         #7,d4
                                               ; Mod 8 = 0 to 7
264
                         d4
                neg.w
                                                -7 to 0
                         #7,d4
265
                                               ; D4.W = bit number
                addq.w
266
267
268
     ; The byte within the row, which we calculate soon, is calculated as
269
    ; (across coordinate DIV 8). Easy.
270
271
    byteNumber
272
                1 s r . w
                         #3,d6
                                               ; Across div 8
273
274
275
    ; The correct row number in the cells bitmap is the Down coordinate
276
      multipled by (size_x DIV 8). This shouldn't exceed a word size. The
277
      result is added to A3 which is the start address of the cells
278
    ; bitmap and loaded into A4 as the byte address that we want.
279
280
   doRow
281
                        #size_x,d7
                                              ; Pixels across
                move.w
282
                         #3,d7
                                               ; Now bytes across
                1 s r . w
283
                         d2, d7
                mulu
                                                 Times down coordinate
                                               ; Address of correct row
284
                1ea
                         0(a3, d7.w), a4
285
                adda.w
                         d6, a4
                                               ; Correct byte in row
286
287
288
      Given the byte address in A4 and the bit number in D4, we can now
289
      test that individual bit. A zero is white while a 1 is black.
290
291
                btst
                         d4, (a4)
                                               ; 0 = white, 1 = black
```

Listing 5.1: Langtons Ant - Existing Bitmap Calculation

We can, should we wish to, replace all of the above using a bit field test instruction, or BFTST as described in BFTST - Test Bit Field on page 33.

Once you have read the introduction to bit fields - Bit Fields on page 28 you will realise that we no longer need to effectively reverse the bit numbering, as bit fields number from 0 upwards, but bit zero is the most significant bit!

Equally, we only need to calculate the bit number within the *entire* bitfield, we don't need to work out a bit number, a byte number and a row number first.

5.1.1 Bit Field Calculations

To calculate the bit number we need, is now quite simple - given that bit fields start numbering at the most significant bit. The calculation is:

```
across + (down * x_size)
```

That's it. If, for example we are on the very first bit, that would be bit zero in a bit field, the coordinates would both be 0, 0 for across and down, so this is 0 + (0*256) which is still zero, and is correct.

If we were at the far right of the very first line, we are on the 512^{th} bit in the bitmap, and that comes from the coordinates being 511, 0, giving 511 + (0*512) which is 511, and that is indeed the bit

number of the 512^{th} bit.

And so on down and across the bitmap. In our ant's world, there are 512 by 256 cells, so we need that many bits, which works out at 131,072 bits. (16,384 bytes)

This means that for the very bottom right coordinate, 511, 255, the bit will be 511 + (255 * 512) which works out at 131,071 and yes, that's the bit number of the $131,072^{nd}$ bit in the bitmap.

Currently we calculate a bit number in D4 of the byte at the address held in A4 for the current cell. Using the 68020 we can change all of the above code to the following.

```
255
256
       Calculate the bit number within the cells bit field. This is simply
257
      across + (down * width).
258
259
    bitNumber
                         #x_size,d4
260
                moveq
                                                  Width
261
                 mulu
                          d2, d4
                                                  Width * Down
262
                          d2
                 swap
                                                  Low word = Across
263
                 add.w
                          d2, d4
                                                  Across + (Down * Width)
                          d2
264
                 swap
                                                  Restore
265
                          (a3){d4:1}
                 bftst
                                                ; Test bit
```

Listing 5.2: Langtons Ant - 68020 Bitmap Calculation

As you can see, this chops a whole pile of code out and reduces the number of instructions required to calculate which bit we need to be looking at and setting, or clearing, as part of the rules for the ant. It also frees up D6 and A4 too, which might come in handy elsewhere - for saving D5 perhaps!

Obviously I now need to update the Register Usage comments - but I'm not showing that here.

After this, we also need to update the code for the two rules as we must set or clear the bit representing the current cell. The existing code for the two rules is as follows.

Register A3, if you remember, was initially set to point at the Cells bitmap. So the bftst (a3) {d4:1} instruction says to start at the address held in register A3 and count from the most significant bit at that address, D4 bits - then test the bit that you arrive at.

```
293
294
    ; Rule 1: If the cell is white, turn it black, right turn, walk on.
295
296
   ruleOne
297
                         ruleTwo
                bne.s
298
                bset
                         d4, (a4)
                                               Turn it black in the bitmap
299
                moveq
                        #black, d1
                                                Colour for BLOCK command
300
                        #1,d5
                                                Direction - 1 = right
                subq.b
301
                bra.s
                         doDirection
                                          ; Prepare to walk on
```

Listing 5.3: Langtons Ant - Existing Rule 1

```
303
304
    ; Rule 2: If the cell is black, turn it white, left turn, walk on.
305
306
    ruleTwo
307
                         d4, (a4)
                bclr
                                               ; Turn it white in the bitmap
                                                 Colour for BLOCK command
308
                         #white, d1
                moveq
309
                addq.b
                         #1,d5
                                               ; Direction + 1 = 1eft
```

Listing 5.4: Langtons Ant - Existing Rule 2

These would be changed to allow them to use the BFSET and BFCLR instructions, as follows:

```
293
294
    ; Rule 1: If the cell is white, turn it black, right turn, walk on.
295
296
    ruleOne
297
                bne.s
                         ruleTwo
298
                         (a3) \{d4:1\}
                                               ; Turn it black in the bitmap
                bfset
299
                moveq
                         #black, d1
                                                 Colour for BLOCK command
300
                         #1,d5
                                               ; Direction -1 = right
                subq.b
301
                         doDirection
                bra.s
                                              ; Prepare to walk on
```


Listing 5.5: Langtons Ant - 68020 Rule 1

```
303
304
    ; Rule 2: If the cell is black, turn it white, left turn, walk on.
305
306
    ruleTwo
307
                bfclr
                         (a3){d4:1}
                                              ; Turn it white in the bitmap
308
                         #white, d1
                                                Colour for BLOCK command
                moveq
309
                addq.b
                         #1,d5
                                                Direction + 1 = left
```

Listing 5.6: Langtons Ant - 68020 Rule 2

So a couple of easy changes and we have a smaller source program to type in, a smaller executable program - in my case, by a whole 34 bytes - because we took advantage of the 68020's new instructions.

Happy anting.



The front cover image on this ePeriodical is taken from the book *Kunstformen der Natur* by German biologist Ernst Haeckel. The book was published between 1899 and 1904. The image used is of various *Polycystines* which are a specific kind of micro-fossil.

I have also cropped the image for use on each chapter heading page.

You can read about Polycystines on Wikipedia and there is a brief overview of the above book, also on Wikipedia, which shows a number of other images taken from the book. (Some of which I considered before choosing the current one!)

Polycystines have absolutely nothing to do with the QL or computing in general - in fact, I suspect they died out before electricity was invented - but I liked the image, and decided that it would make a good cover for the book and a decent enough chapter heading image too.

Not that I am suggesting, in any way whatsoever, that we QL fans are ancient.