# e-Block 250

## User Manual (O&M Edition)

**Xi'an Singularity Energy Co., Ltd.**

Version: V1.0 | Date: March 16, 2026

# 0. Contents

**1 About This Manual** **1**

1.1 Explanation of Symbols . . . . . 1

1.2 Scope of Application . . . . . 1

1.3 Introduction to Energy Storage System . . . . . 1

**2 Personnel Entry Safety Precautions** **2**

**3 On-site Operation Specifications** **2**

3.1 Routine Inspection . . . . . 2

3.2 Power On/Off Sequence . . . . . 2

**4 Abnormal Situation Handling Procedures** **2**

4.1 Fire Safety and Alarm Logic . . . . . 2

4.2 Emergency Response for Equipment Fire . . . . . 3

4.3 Other Abnormalities . . . . . 3

# 1. About This Manual

## 1.1 Explanation of Symbols

To ensure the safety of O&M personnel and proper equipment operation, please familiarize yourself with the following symbols:

| Symbol | Name | Meaning for O&M Safety |
|---|---|---|
| ⚠ | **Warning** | Indicates content that, if not properly handled, may pose a danger to user safety or equipment. |
| ⚠ | **Attention** | Indicates content that may lead to equipment damage or performance degradation. |
| ⚠ | **Electric** | Identifies parts with a risk of electric shock. **Do NOT touch** at will. |
| ⚠ | **High Temp** | Identifies parts with high-temperature risks. **Do NOT touch** at will. |
| ⏚ | **Grounding** | Indicates the connection position for the protective earth (PE) wire. |
| ⚠ | **Discharge** | Operations by professionals only. Wait **30 minutes** after power-off before touching. |

## 1.2 Scope of Application

This manual is applicable to the routine O&M of **eBlock-372/418 series**. It is intended for professional personnel with electrical expertise and experience in power distribution.

## 1.3 Introduction to Energy Storage System

The system consists of the **Intelligent Energy Block (eBlock)**, **Intelligent Energy Link (eLink)**, background monitoring, and transformers.

## 2. Personnel Entry Safety Precautions

- **Professional Qualification:** Only trained and qualified electrical technicians are allowed to operate the eBlock.
- **PPE Requirements:** Personnel must wear qualified protective equipment, including insulated gloves, shoes, and safety goggles.
- **Metal Objects:** Remove all metal objects (rings, watches, etc.) before operation.
- **Insulated Tools:** Use professional tools with insulated handles.
- **Capacitor Discharge:** Wait for at least **30 minutes** after power-off before touching any live components.

## 3. On-site Operation Specifications

### 3.1 Routine Inspection

- Check for water ingress, corrosion, or deformation of the cabinet.
- Monitor liquid cooling levels and pressure (standard static pressure: 0.8bar–1bar).
- Inspect cable connections for looseness or signs of overheating.

### 3.2 Power On/Off Sequence

- **Power Off:** Disconnect the AC grid-side breaker first, then the DC-side breaker.
- **Power On:** Reverse the sequence; ensure system self-check is complete before closing.

## 4. Abnormal Situation Handling Procedures

### 4.1 Fire Safety and Alarm Logic

The system triggers tiered responses:

- **Level 2 Alarm:** Smoke/CO/Temperature detected; the **Audible and Visual Alarm** activates.
- **Level 3 Alarm:** The system releases the fire extinguishing agent automatically.

### 4.2 Emergency Response for Equipment Fire

1. **Power Isolation:** Immediately disconnect the power supply to the affected unit.
2. **Evacuation:** Establish a cordon area with a radius of **100 meters**.
3. **Initial Firefighting:** Use CO2 or dry powder extinguishers if safe to do so.

### 4.3 Other Abnormalities

- **Emergency Stop:** Press the red **Emergency Stop** button if there is an immediate threat.
- **Leakage/Odor:** Shut down immediately and contact technical support if unusual smells or leaks occur.