

## Programming guide

- 1. Launch Arduino software.
- 2. Open file that you would like to upload (File > Open)
- **3**. Select serial port for the ALog (Tools > Port)
- **4.** Check that the board is right (Tools > Board)
- **5**. Click the right-arrow "upload" button. Watch lights blink.
- **6.** Open serial monitor (top right button). Check text.
- 7. Syncopated flash? Clock isn't set. Run "ALogClockSet.py"
- **8**. LOOOONG short short? Logger is recording data.