



**OPERATOR TRAINING PROGRAM
JOB PERFORMANCE MEASURE**

STATION:	SALEM		
SYSTEM:	Pressurizer/Pressure Relief		
TASK:	Transfer Pressurizer 22 Backup Heaters to Emergency Power Supply		
TASK NUMBER:	115 043 05 01		
JPM NUMBER:	15-01 NRC Annual IP-i		
ALTERNATE PATH:	☐	K/A NUMBER:	010 A4.02
APPLICABILITY:		IMPORTANCE FACTOR:	
EO ☐	RO ☒	STA ☐	SRO ☒
EVALUATION SETTING/METHOD:		In Plant, Simulate	
REFERENCES:		S2.OP-SO.PZR-0010 Rev. 10 (Rev. checked 8-5-16)	
TOOLS AND EQUIPMENT:		None	
VALIDATED JPM COMPLETION TIME:		<u>20 minutes</u>	
TIME PERIOD IDENTIFIED FOR TIME CRITICAL STEPS:		<u>N/A</u>	
Developed By:	G Gauding Instructor	Date:	8-5-16
Validated By:	S Bickhart / J Hancock SME or Instructor	Date:	9-30-16
Approved By:	 Training Department	Date:	10/10/16
Approved By:	 Operations Department	Date:	10/10/16
ACTUAL JPM COMPLETION TIME:			
ACTUAL TIME CRITICAL COMPLETION TIME:			
PERFORMED BY:			
GRADE: ☐ SAT ☐ UNSAT			
REASON, IF UNSATISFACTORY:			
EVALUATOR'S SIGNATURE:		DATE:	

**OPERATOR TRAINING PROGRAM
JOB PERFORMANCE MEASURE**

SYSTEM: Pressurizer/Pressure Relief

TASK: Transfer Pressurizer 22 Backup Heaters to Emergency Power Supply

TASK 115 043 05 01

NUMBER:

INITIAL CONDITIONS:

Due to a loss of power to the group buses it is necessary to energize the PZR Backup Heaters from their emergency power supply.

INITIATING CUE:

The CRS directs you to perform S2.OP-SO.PZR-0010(Q), Section 5.3, Transferring Pzr Htr 22 BU Group To The Emergency Power Supply.

All prerequisites and Precautions and Limitations have been reviewed and completed.

2A EDG is carrying 2A Vital Bus and is loaded to 2400 KW.

You have a JAM key.

Successful Completion Criteria:

1. All critical steps completed.
2. All sequential steps completed in order.
3. All time-critical steps completed within allotted time.
4. JPM completed within validated time. Completion time may exceed the validated time if satisfactory progress is being made (and NRC concurrence is obtained).

Task Standard for Successful Completion:

1. Simulate opening all but three PZR heater disconnects.
2. Simulate aligning emergency power to PZR heater bus from 2A vital bus.

**OPERATOR TRAINING PROGRAM
JOB PERFORMANCE MEASURE**

NAME: _____
DATE: _____

SYSTEM: Pressurizer/Pressure Relief

TASK: Transfer 22 Backup Heaters to Emergency Power Supply

*	STEP NO.	STEP (*Denotes a Critical Step)	STANDARD	EVAL S/U	COMMENTS (Required for UNSAT Evaluation)
		Operator obtains procedure S2.OP-SO.PZR-0010, Pressurizer Backup Heaters Power Supply Transfer.	Provide marked up copy of S2.OP-SO.PZR-0010, Pressurizer Backup Heaters Power Supply Transfer		
	5.3.1	ENSURE 2AX1AX14X, 2EP PRESSURIZER HEATER BUS FEED (EMERGENCY) is OPEN (84' Swgr Rm).	Locates breaker 2AX1AX14X 2EP PRESSURIZER HEATER BUS FEED (EMERGENCY) on 2A 460V Vital Bus, Elev. 84' Swgr Rm and determines current breaker position. Cue: 2AX1AX14X Breaker indicates OPEN.		
	5.3.2	Request NCO to PERFORM the following: A. PLACE 22 Backup Group in MANUAL. B. PRESS the 22 BACKUP OFF pushbutton	Locates nearest means of communications and requests NCO to place 22 B/U Htrs in MANUAL and press the 22 BACKUP OFF pushbutton. Cue: NCO reports 22 B/U Htrs are in MANUAL and 22 BACKUP OFF pushbutton has been depressed.		
*	5.3.3	ENSURE 2EX1EP2EPX, 2EP 480V PRESSURIZER HEATER BUS MAIN BREAKER is OPEN (78' Electrical Penetration).	Locates 2EX1EP2EPX, 2EP 480V PRESSURIZER HEATER BUS MAIN BREAKER on El. 78 Electrical Pen. Cue: 2EX1EP2EPX, 2EP 480V PRESSURIZER HEATER BUS MAIN BREAKER is OPEN.		

**OPERATOR TRAINING PROGRAM
JOB PERFORMANCE MEASURE**

SYSTEM: Pressurizer/Pressure Relief

TASK: Transfer 22 Backup Heaters to Emergency Power Supply

NAME: _____

DATE: _____


*	STEP NO.	STEP (*Denotes a Critical Step)	STANDARD	EVAL S/U	COMMENTS (Required for UNSAT Evaluation)
*	5.3.4	REMOVE interlock key from breaker 2EX1EP2EPX.	Describes turning key and removing interlock key from breaker 2EX1EP2EPX. Note: Tab must be pushed in to rotate key to allow its removal.		
*	5.3.5	PLACE any eleven of the following disconnects in OFF (only three disconnects are to remain ON) <u>AND</u> MARK the remaining disconnects as N/A:	Operator locates individual heater disconnects, places all but three disconnects in OFF and notes disconnects left ON as N/A in procedure.		
*	5.3.6	PLACE , 2AX1AX14X-1, 2EP PZR HTR BUS EMERGENCY FEED DISCONNECT SWITCH, in the ON position (Elev 78' Electrical Penetration).	Operator locates 2AX1AX14X-1, 2EP PZR HTR BUS EMERGENCY FEED DISCONNECT SWITCH, and places it in the ON position (Elev 78' Electrical Penetration).		
*	5.3.7	INSERT interlock key, <u>AND</u> UNLOCK breaker 2AX1AX14X.	Locates Corry Key Interlock on 2AX1AX14X breaker, inserts and turns key.		
	5.3.8	NOTIFY NCO that PZR Htr 22 B/U Group has been transferred to the emergency power supply (2A 460V Vital Bus).	Candidate makes report to the Control Room. Repeat back notification and state: JPM is complete.		

**OPERATIONS TRAINING PROGRAM
JOB PERFORMANCE MEASURE**


JOB PERFORMANCE MEASURE VALIDATION CHECKLIST

NOTE: All steps of this checklist should be performed upon initial validation. Prior to JPM usage, revalidate JPM using steps 8 and 11 below.

- h 2 5 / 1. Task description and number, JPM description and number are identified.
- h 2 5 / 2. Knowledge and Abilities (K/A) references are included.
- h 2 5 / 3. Performance location specified. (in-plant, control room, or simulator)
- u 2 5 / 4. Initial setup conditions are identified.
- h 2 5 / 5. Initiating and terminating Cues are properly identified.
- h 2 5 / 6. Task standards identified and verified by SME review.
- h 2 5 / 7. Critical steps meet the criteria for critical steps and are identified with an asterisk (*).
- h 2 5 / 8. Verify the procedure referenced by this JPM matches the most current revision of that procedure: Procedure Rev. 4 Date 11/4/15
- h 2 5 / 9. Pilot test the JPM:
a. verify Cues both verbal and visual are free of conflict, and
b. ensure performance time is accurate.
- _____ 10. If the JPM cannot be performed as written with proper responses, then revise the JPM.
- _____ 11. When JPM is revalidated, SME or Instructor sign and date JPM cover page.

SME/Instructor:  Hannah

Date: 9/30/16

SME/Instructor:  Brian

Date: 9/30/16

SME/Instructor: _____

Date: _____

**OPERATIONS TRAINING PROGRAM
JOB PERFORMANCE MEASURE**

**INITIAL
CONDITIONS:**

Due to a loss of power to the group buses it is necessary to energize the PZR Backup Heaters from their emergency power supply.

INITIATING CUE:

The CRS directs you to perform S2.OP-SO.PZR-0010(Q), Section 5.3, Transferring Pzr Htr 22 BU Group To The Emergency Power Supply.

All prerequisites and Precautions and Limitations have been reviewed and completed.

2A EDG is carrying 2A Vital Bus and is loaded to 2400 KW.

You have a JAM key.