

**OPERATOR TRAINING PROGRAM  
JOB PERFORMANCE MEASURE**

|                                                        |                                                                                                              |                                |                                         |
|--------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|--------------------------------|-----------------------------------------|
| <b>STATION:</b>                                        | SALEM                                                                                                        |                                |                                         |
| <b>SYSTEM:</b>                                         | Pressurizer and PRT                                                                                          |                                |                                         |
| <b>TASK:</b>                                           | Adjust PRT level and pressure                                                                                |                                |                                         |
| <b>TASK NUMBER:</b>                                    | N0100110101                                                                                                  |                                |                                         |
| <b>JPM NUMBER:</b>                                     | 15-01 NRC Sim f                                                                                              |                                |                                         |
| <b>ALTERNATE PATH:</b>                                 | <input type="checkbox"/>                                                                                     | <b>K/A NUMBER:</b>             | 007 A4.04                               |
| <b>APPLICABILITY:</b>                                  | <b>IMPORTANCE FACTOR:</b>                                                                                    |                                |                                         |
| EO <input type="checkbox"/>                            | RO <input checked="" type="checkbox"/>                                                                       | STA <input type="checkbox"/>   | SRO <input checked="" type="checkbox"/> |
|                                                        |                                                                                                              | RO                             | SRO                                     |
| <b>EVALUATION SETTING/METHOD:</b>                      | Simulator / Perform                                                                                          |                                |                                         |
| <b>REFERENCES:</b>                                     | S2.OP-SO.PZR-0003, Rev. 15 (checked 8-5-16)                                                                  |                                |                                         |
| <b>TOOLS AND EQUIPMENT:</b>                            | None                                                                                                         |                                |                                         |
| <b>VALIDATED JPM COMPLETION TIME:</b>                  | <u>8 min</u>                                                                                                 |                                |                                         |
| <b>TIME PERIOD IDENTIFIED FOR TIME CRITICAL STEPS:</b> | <u>N/A</u>                                                                                                   |                                |                                         |
| <b>Developed By:</b>                                   | G Gauding<br>Instructor                                                                                      | <b>Date:</b>                   | 8-5-16                                  |
| <b>Validated By:</b>                                   | M Lutek / W Russell<br>SME or Instructor                                                                     | <b>Date:</b>                   | 8-22-16                                 |
| <b>Approved By:</b>                                    | <br>Training Department   | <b>Date:</b>                   | 10/11/16                                |
| <b>Approved By:</b>                                    | <br>Operations Department | <b>Date:</b>                   | 10/11/16                                |
| <b>ACTUAL JPM COMPLETION TIME:</b>                     |                                                                                                              |                                |                                         |
| <b>ACTUAL TIME CRITICAL COMPLETION TIME:</b>           |                                                                                                              |                                |                                         |
| <b>PERFORMED BY:</b>                                   |                                                                                                              |                                |                                         |
| <b>GRADE:</b>                                          | <input type="checkbox"/> SAT                                                                                 | <input type="checkbox"/> UNSAT |                                         |
| <b>REASON, IF UNSATISFACTORY:</b>                      |                                                                                                              |                                |                                         |
| <b>EVALUATOR'S SIGNATURE:</b>                          |                                                                                                              | <b>DATE:</b>                   |                                         |

**OPERATOR TRAINING PROGRAM  
JOB PERFORMANCE MEASURE**

**NAME:** \_\_\_\_\_

**DATE:** \_\_\_\_\_

**SYSTEM:** Pressurizer and PRT

**TASK:** Adjust PRT level and pressure

**TASK NUMBER:** N0450040101

**SIMULATOR SETUP:** 15-01 NRC IC-256 PRT level 56.2% (or low enough for the PRT Hi-Lo Lvl alarm to be locked in) with PRT pressure 9.8 psig. Paper copies of procedure needed.

**INITIAL CONDITIONS:**

Unit 2 is at 100% power.

2PR1 is leaking and 2PR6 is shut with power applied. Operators have been attempting to determine the leak rate through 2PR1.

Console alarm PRT Level Hi-Lo is in alarm (lo) with PRT level at 56.2%.

**INITIATING CUE:**

You are directed to raise PRT level to 60% IAW S2.OP-SO.PZR-0003, Pressurizer Relief Tank Operation, Section 5.1.

**Successful Completion Criteria:**

1. All critical steps completed.
2. All sequential steps completed in order.
3. All time-critical steps completed within allotted time.
4. JPM completed within validated time. Completion time may exceed the validated time if satisfactory progress is being made (and NRC concurrence is obtained).

**Task Standard for Successful Completion:**

1. Raise PRT level to > 60% while maintaining PRT pressure  $\leq 10$  psig.

**OPERATOR TRAINING PROGRAM  
JOB PERFORMANCE MEASURE**

NAME: \_\_\_\_\_

DATE: \_\_\_\_\_

**SYSTEM:** PZR and PRT

**TASK:** Adjust PRT level and pressure

| * | STEP NO. | STEP<br>(*Denotes a Critical Step)                                        | STANDARD                                                                                                                                                                                                                                                                                                                                                                                                                         | EVAL<br>S/U | COMMENTS<br>(Required for UNSAT Evaluation) |
|---|----------|---------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|---------------------------------------------|
|   |          | Provide marked up paper copy of S2.OP-SO.PZR-0003.                        | Reviews Precautions and Limitations.                                                                                                                                                                                                                                                                                                                                                                                             |             |                                             |
|   | 5.1.1    | <u>IF</u> PRT level is low, <b><u>THEN</u> PERFORM</b> the following:     | <p><b>Note:</b> The step for reducing PRT pressure may be performed prior to raising level, since pressure is close to the maximum allowed. (See Step 5.1.1.D)</p> <p><u>IF</u> PRT pressure reduction is performed first, <b><u>THEN Cue</u></b> if PRT pressure is lowered past 7 psig..." CRS states that the pressure reduction is sufficient to allow filling of the PRT now."</p>                                          |             |                                             |
| * | 5.1.1.A  | <u>IF</u> required, <b><u>THEN</u> START</b> 21 or 22 Primary Water Pump. | <p>Depresses start pushbutton for 22 Primary Water Pump. (aligned for manual start)</p> <p align="center">OR</p> <p>Places 21 Primary Water Pump in manual and depresses start pushbutton for 21 Primary Water Pump.</p> <p><u>IF</u> operator does not start a Primary Water Pump and will gravity feed to makeup to the PRT, <b><u>THEN Cue:</u></b> The CRS directs you to use a Primary Water pump to makeup to the PRT.</p> |             |                                             |

**OPERATOR TRAINING PROGRAM**  
**JOB PERFORMANCE MEASURE**

NAME: \_\_\_\_\_

DATE: \_\_\_\_\_

**SYSTEM:** PZR and PRT

**TASK:** Adjust PRT level and pressure

| * | STEP NO. | STEP<br>(*Denotes a Critical Step)                                                                                                              | STANDARD                                                                                                                                                                                                                                                                                                                                                                                                                                                   | EVAL<br>S/U | COMMENTS<br>(Required for UNSAT Evaluation) |
|---|----------|-------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|---------------------------------------------|
| * | 5.1.1.B  | <b>OPEN</b> 2WR80, CONT PRI WATER STOP.                                                                                                         | Depresses open pushbutton for 2WR80 CONT PRI WATER STOP and verifies open light lit.                                                                                                                                                                                                                                                                                                                                                                       |             |                                             |
| * | 5.1.1.C  | <b>OPEN</b> 2WR82, PRT WATER SUPPLY.                                                                                                            | Depresses open pushbutton for 2WR82, PRT WATER SUPPLY and verifies open light lit.                                                                                                                                                                                                                                                                                                                                                                         |             |                                             |
| * | 5.1.1.D  | <u>IF</u> PRT pressure approaches 10 psig, <u>THEN</u> <b>OPEN</b> 2PR15, VENT, as necessary, to maintain PRT pressure at >3 psig and ≤10 psig. | Depresses open pushbutton for 2PR15, VENT <u>prior to PRT pressure rising above 10.0 psig</u> , and depresses close pushbutton prior to PRT pressure lowering below 3.1 psig.<br><br><b>Note:</b> IF PRT Hi Pressure alarm is received, it prevents the 2PR15 from opening, and pressure cannot be reduced.<br><br><u>When</u> operator has demonstrated that they can raise level without exceeding 10 psig, <u>then</u> <b>Cue: PRT level is now 60%</b> |             |                                             |

**OPERATOR TRAINING PROGRAM**  
**JOB PERFORMANCE MEASURE**

NAME: \_\_\_\_\_

DATE: \_\_\_\_\_

**SYSTEM:** PZR and PRT

**TASK:** Adjust PRT level and pressure

| *                   | STEP NO. | STEP<br>(*Denotes a Critical Step)                                                                                                                                                                                                                                                                                                                                                                                                                     | STANDARD                                                                                                                                                                                                                                                                                                                    | EVAL<br>S/U | COMMENTS<br>(Required for UNSAT Evaluation) |
|---------------------|----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|---------------------------------------------|
| *<br><br>*<br><br>* | 5.1.1.E  | <p>When PRT level increases to between 59% and 86%:</p> <ol style="list-style-type: none"> <li>1. <b>CLOSE</b> 2WR80, CONT PRI WATER STOP.</li> <li>2. <b>CLOSE</b> 2WR82, PRT WATER SUPPLY</li> <li>3. <b>ENSURE</b> 2PR15, VENT is closed.</li> <li>4. <u>IF</u> Primary Water Pump is in service IAW Step 5.1.1.A, <u>AND</u> is <u>NOT</u> required to be in service for any other reason, <u>THEN STOP</u> running Primary Water Pump.</li> </ol> | <p>When PRT level rises to 60%:</p> <p>Closes 2WR80, CONT PRI WATER STOP.</p> <p>Closes 2WR82, PRT WATER SUPPLY. Ensures 2PR15, VENT is closed. Depresses stop pushbutton for running Primary Water Pump. <u>IF</u> 21 Primary Water pump was used to fill PRT, <u>THEN</u> places 21 or 22 Primary Water pump in auto.</p> |             |                                             |
|                     | 5.1.1.F  | <b>DIRECT</b> a second Operator to perform an Independent Verification of component position in Attachment 1, Section 1.0                                                                                                                                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                                                             |             |                                             |

TERMINATING CUE: After operator reads Step 5.1.1.F, state JPM is complete.

**OPERATOR TRAINING PROGRAM  
JOB PERFORMANCE MEASURE**

**JOB PERFORMANCE MEASURE VALIDATION CHECKLIST**

**NOTE:** All steps of this checklist should be performed upon initial validation. Prior to JPM usage, revalidate JPM using steps 8 and 11 below.

- u ✓ 8 UM 1. Task description and number, JPM description and number are identified.
- u ✓ 8 UM 2. Knowledge and Abilities (K/A) references are included.
- u ✓ 8 UM 3. Performance location specified. (in-plant, control room, or simulator)
- b ✓ 8 UM 4. Initial setup conditions are identified.
- u ✓ 8 UM 5. Initiating and terminating Cues are properly identified.
- u ✓ 8 UM 6. Task standards identified and verified by SME review.
- u ✓ 8 UM 7. Critical steps meet the criteria for critical steps and are identified with an asterisk (\*).
- 8 UM 8. Verify the procedure referenced by this JPM matches the most current revision of that procedure: Procedure Rev. 15 Date 3/22/16
- 8 UM 9. Pilot test the JPM:  
a. verify Cues both verbal and visual are free of conflict, and  
b. ensure performance time is accurate.
- \_\_\_\_\_ 10. If the JPM cannot be performed as written with proper responses, then revise the JPM.
- \_\_\_\_\_ 11. When JPM is revalidated, SME or Instructor sign and date JPM cover page.

SME/Instructor: ML JTC / [Signature]

Date: 8/22/16

SME/Instructor: W. Russell Russell

Date: 8/22/16

SME/Instructor: \_\_\_\_\_

Date: \_\_\_\_\_

**OPERATOR TRAINING PROGRAM  
JOB PERFORMANCE MEASURE**

**INITIAL CONDITIONS:**

Unit 2 is at 100% power.

2PR1 is leaking and 2PR6 is shut with power applied. Operators have been attempting to determine the leak rate through 2PR1.

Console alarm PRT Level Hi-Lo is in alarm (lo) with PRT level at 56.2%.

**INITIATING CUE:**

You are directed to raise PRT level to 60% IAW S2.OP-SO.PZR-0003, Pressurizer Relief Tank Operation, Section 5.1.