


OPERATOR TRAINING PROGRAM
JOB PERFORMANCE MEASURE

STATION:	SALEM		
SYSTEM:	ADMINISTRATIVE		
TASK:	Perform Duties of Secondary Communicator During an Alert		
TASK NUMBER:	N1240100501		
JPM NUMBER:	13-01 NRC RO Admin A4		
ALTERNATE PATH:	☐	K/A NUMBER:	2.4.39
		IMPORTANCE FACTOR:	3.9
APPLICABILITY:		RO	SRO
EO	☐	RO	☒
STA	☐	SRO	☐
EVALUATION SETTING/METHOD:	Simulator		
REFERENCES:	EP-SA-111-F8, Attachment 8 Secondary Communicator Log, Rev. 02 (checked 9-26-14)		
TOOLS AND EQUIPMENT:	None		
VALIDATED JPM COMPLETION TIME:	8 min		
TIME PERIOD IDENTIFIED FOR TIME CRITICAL STEPS:	N/A		
Developed By:	G Gauding Instructor	Date:	9-26-14
Validated By:	S Bickhart SME or Instructor	Date:	10-14-14
Approved By:	 Training Department	Date:	10-23-14
Approved By:	 Operations Representative	Date:	10-27-14
ACTUAL JPM COMPLETION TIME:			
ACTUAL TIME CRITICAL COMPLETION TIME:			
PERFORMED BY:			
GRADE:	☐ SAT	☐ UNSAT	
REASON, IF UNSATISFACTORY:			
EVALUATOR'S SIGNATURE:		DATE:	

OPERATOR TRAINING PROGRAM
JOB PERFORMANCE MEASURE

NAME: _____

DATE: _____

SYSTEM: Administrative

TASK: Perform Duties of Secondary Communicator During an Alert.

TASK NUMBER: N1240100501

- SIMULATOR OPERATOR:
1. Plug in SPDS cable in computer room.
 2. CALL THE ERDS HELP DESK ON LAND LINE 1-301-415-0467 OR CELL PHONE 1-240-731-2581 BEFORE STARTING JPMS TO INFORM THEM ERDS WILL BE ACTIVATED DURING EXAM. PLACE FOLLOWUP CALL AFTER LAST RO HAS PERFORMED JPM.
 3. Check the NCO T desk computer is toggled to LAN.

INITIAL CONDITIONS: An ALERT was declared at Salem due to the Unit 2 reactor failing to trip when a manual trip signal was initiated. The Rx tripped when the second trip handle was used.

The unit is currently stable in MODE 3.

The Emergency News Center (ENC) has not activated yet.

INITIATING CUE: You are the Secondary Communicator. You are directed to perform EP-SA-111-F8, Attachment 8 Secondary Communicator Log

Successful Completion Criteria:

1. All critical steps completed
2. All sequential steps completed in order
3. All time-critical steps completed within allotted time
4. JPM completed within validated time. Completion time may exceed the validated time if satisfactory progress is being made (and NRC concurrence is obtained).

Task Standard for Successful Completion:

1. Activate ERDS.
2. Does NOT provide plant information to outside caller.
3. Terminate ERDS.

**OPERATOR TRAINING PROGRAM
JOB PERFORMANCE MEASURE**

NAME: _____

DATE: _____

System: ADMINISTRATIVE

Task: Perform Duties of Secondary Communicator During an Alert

*	STEP NO.	STEP (* Denotes a Critical Step)	STANDARD	EVAL S/U	COMMENTS (Required for UNSAT evaluation)
		Provide a copy of ECG Attachment 8.			
			Fills out ECG Attachment 8 by: 1. Printing name 2. Circles ALERT and circles CM2.		
	A.1	OBTAIN a copy of Attachment 6 and ASSIST Primary Communicator with 15-minute notifications, as necessary.	Cue: Primary Communicator does not require assistance.		
	A.2	DIRECT the Shift Rad Pro Tech (SRPT) (2644) to implement SC.EP-EP.ZZ-0301(Q) Shift Radiation Protection Technician Response. (N/A for Common Site)	Cue: Shift Rad Pro Tech (Matt Hassler) has been notified to implement SC.EP-EP.ZZ-0301(Q) Shift Radiation Protection Technician Response.		
	A.3	<u>IF</u> in an UNUSUAL EVENT Only, <u>THEN</u> , within approximately 30 minutes, FAX a copy of the ICMF to the NEI Duty Manager at FAX # 9-1-202-785-4113 (backup Fax # 9-1-202-533-0180).	Determines not in an Unusual Event.		

**OPERATOR TRAINING PROGRAM
JOB PERFORMANCE MEASURE**

NAME: _____
DATE: _____

System: ADMINISTRATIVE

Task: Perform Duties of Secondary Communicator During an Alert

*	STEP NO.	STEP (* Denotes a Critical Step)	STANDARD	EVAL S/U	COMMENTS (Required for UNSAT evaluation)
	A.4	<u>For an ALERT or higher emergency;</u> a. <u>IF</u> an on-shift SRO is not available to fill the OSC Operations Supervisor position, CALLOUT an additional SRO and have him/her report to the OSC.	Cue: The WCC Supervisor is the OSC Supervisor.		
	A.4	b. Within 60 minutes, ACTIVATE ERDS from a LAN computer .	Cue if needed: The SM directs you to activate ERDS now.		
*	A.4. b.1	PROCEED to a computer with its monitor labeled " ERDS XXX " (XXX is the computers asset tag number) in the Salem Control Room and START the program by SELECTING the ERDS_Salem desktop icon.	Proceeds to a computer with its monitor labeled "ERDS XXX" (XXX is the computers asset tag number) in the Salem Control Room and starts the program by selecting the ERDS_Salem desktop icon.		
*	A.4. b.2	On the "Login For ERDS Display" popup window ENTER the PASSWORD and SELECT "Login" to proceed. (The Username will be displayed and the password is the same as the Username)	On the "Login For ERDS Display" popup window enters the PASSWORD and selects "Login" to proceed. (The Username will be displayed and the password is the same as the Username)		

**OPERATOR TRAINING PROGRAM
JOB PERFORMANCE MEASURE**

NAME: _____
DATE: _____

System: ADMINISTRATIVE

Task: Perform Duties of Secondary Communicator During an Alert

*	STEP NO.	STEP (* Denotes a Critical Step)	STANDARD	EVAL S/U	COMMENTS (Required for UNSAT evaluation)
*	A.4. b.3	SELECT the Action button labeled <CONNECT> on the appropriate Salem 1 or Salem 2 "ERDS Link Control and Status Display Screen".	Selects the Action button labeled <CONNECT> on the Salem 2 "ERDS Link Control and Status Display Screen".		
*	A.4. b.4	SELECT the <YES> button in the "Current Link Control State is Disconnect. Do You Want To Connect?" box.	Selects the <YES> button in the "Current Link Control State is Disconnect. Do You Want To Connect?" box.		
	A.4. b.5	OBSERVE that Status changes to "Transmitting Data."	Observes that Status changes to "Transmitting Data."		
	A.4. b.6	VERIFY successful communications status by observing that the "Messages Sent" value is increasing from zero "0" to some positive integer > "0".	Verifies successful communications status by observing that the "Messages Sent" value is increasing from zero "0" to some positive integer > "0".		

**OPERATOR TRAINING PROGRAM
JOB PERFORMANCE MEASURE**

NAME: _____

DATE: _____

System: ADMINISTRATIVE

Task: Perform Duties of Secondary Communicator During an Alert

*	STEP NO.	STEP (* Denotes a Critical Step)	STANDARD	EVAL S/U	COMMENTS (Required for UNSAT evaluation)
	A.4. b.7	INFORM the CRS of successful ERDS activation status.	Informs the CRS of successful ERDS activation status. Cue: Steps A4 through A7 are complete. Steps A8 through A10 are not required to be completed at this time. Section B is not required to be completed at this time.		
*		Simulator Operator: After the previous step cue has been repeated back, call the desk phone and say the following: "This is Anderson Cooper calling from CNN headquarters in Atlanta. We have received a report that the Salem 2 reactor has experienced a Rx accident and the core is melting. Can you give me an update on the current condition of Salem Unit 2?"	Does NOT give plant information to caller. Attachment 8, Section C, INCOMING CALLS, MEDIA, CAUTION, states, "Communicators are <u>NOT</u> authorized to release any information to the News Media." May read either Attachment 8, section C, Incoming Calls, 3.C, OR tell them he cannot provide any information.		

**OPERATOR TRAINING PROGRAM
JOB PERFORMANCE MEASURE**

NAME: _____

DATE: _____

System: ADMINISTRATIVE

Task: Perform Duties of Secondary Communicator During an Alert

*	STEP NO.	STEP (* Denotes a Critical Step)	STANDARD	EVAL S/U	COMMENTS (Required for UNSAT evaluation)
			CUE: Once ERDS is activated AND Media call action is complete, then state, "The Station Event has been terminated. The NRC Operations Center directs you to terminate ERDS transmission."		
	C.4.a	When directed by the NRC, TERMINATE Emergency Response Data System (ERDS) transmission as follows:			
	C.4.b	RETURN to the computer labeled "ERDS XXX" used to activate ERDS in the Control Room. <u>IF</u> the "ERDS Link Control and Status Display Screen" was "MINIMIZED" <u>THEN</u> , MAXIMIZE it.	Returns to the computer labeled "ERDS XXX" used to activate ERDS in the Control Room. <u>IF</u> the "ERDS Link Control and Status Display Screen" was "MINIMIZED" <u>THEN</u> , maximizes it.		
*	C.4.c	SELECT the appropriate (Salem Unit 1 or Salem Unit 2) Action Button marked < DISCONNECT > on the "ERDS Link Control and Status Display" Screen.	Selects the Salem Unit 2 Action Button marked <DISCONNECT> on the "ERDS Link Control and Status Display" Screen.		

**OPERATOR TRAINING PROGRAM
JOB PERFORMANCE MEASURE**

NAME: _____
DATE: _____

System: ADMINISTRATIVE

Task: Perform Duties of Secondary Communicator During an Alert

*	STEP NO.	STEP (* Denotes a Critical Step)	STANDARD	EVAL S/U	COMMENTS (Required for UNSAT evaluation)
*	C.4.d	SELECT the <YES> button in the "Current Link Control State is Connect. Do You Want To Disconnect?" box.	Selects the <YES> button in the "Current Link Control State is Connect. Do You Want To Disconnect?" box.		
			Terminate JPM.		

OPERATOR TRAINING PROGRAM
JOB PERFORMANCE MEASURE

JOB PERFORMANCE MEASURE VALIDATION CHECKLIST

NOTE: All steps of this checklist should be performed upon initial validation. Prior to JPM usage, revalidate JPM using steps 8 and 11 below.

- S 1. Task description and number, JPM description and number are identified.
- S 2. Knowledge and Abilities (K/A) references are included.
- S 3. Performance location specified. (in-plant, control room, or simulator)
- S 4. Initial setup conditions are identified.
- S 5. Initiating and terminating Cues are properly identified.
- S 6. Task standards identified and verified by SME review.
- S 7. Critical steps meet the criteria for critical steps and are identified with an asterisk (*).
- S 8. Verify the procedure referenced by this JPM matches the most current revision of that procedure: Procedure Rev. 2 Date 10/14/14
9. Pilot test the JPM:
a. verify Cues both verbal and visual are free of conflict, and
b. ensure performance time is accurate.
10. If the JPM cannot be performed as written with proper responses, then revise the JPM.
11. When JPM is revalidated, SME or Instructor sign and date JPM cover page.

SME/Instructor: S. Bickel BICKEL

Date: 10/14/14

SME/Instructor:

Date:

SME/Instructor:

Date:

OPERATOR TRAINING PROGRAM
JOB PERFORMANCE MEASURE

INITIAL CONDITIONS:

An ALERT has been declared at Salem due to the Unit 2 reactor failing to trip when a manual trip signal was initiated. The Rx tripped when the second trip handle was used.

The unit is currently stable in MODE 3.

The Emergency News Center (ENC) has not activated yet.

INITIATING CUE:

You are the Secondary Communicator. You are directed to perform EP-SA-111-F8,
Attachment 8 Secondary Communicator Log