




1) KONEKTOR, NAPAJENI




2) VSTUPY Z ECU (XOR + propojka LS/+12V)




3) PRAHY, OSCILATOR 2 Hz, TEST, KONTROLKA




CH1 palivove cerpadlo 25A




CH2 rezerva 25A




CH3 rezerva 25A




CH4 rezerva 25A




CH5 vstrikovace 15A



CH6 cívky 15A



CH7 ECU 15A (klice)



CH8 prislusenstvi 15A

