# **MANUAL GUIDE:**



# **RED BUTTON:**

- 1. Select main menu display, cycle up to 3 times.
  - Short press the RED BUTTON to cycle through the main menu options on the OLED display:
    - 1. Set Height
    - 2. Set Data
    - 3. Tank Display
  - o The ">" symbol highlights the selected option.
- 2. **Hold** (for 1 second) if want to take measurements.
  - Long press the RED BUTTON for 1 second while in tank display (after pressing GREEN BUTTON) to start the ultrasonic measurement mode.
  - The display will show real-time tank data (e.g., percentage, height, weight, liters) for the selected tank (based on YELLOW 1 setting).

### **GREEN BUTTON:**

- 1. **Short** press to **ENTER** the select main menu.
  - After selecting a main menu option with the RED BUTTON, short press the GREEN BUTTON to enter the selected mode:
    - Set Height: Configure tank heights.
    - **Set Data**: Choose between hardcoded or variable data.
    - Tank Display: View tank levels.
- 2. Hold (for 1 second) to enter variable data setup.
  - From the "Set Data" menu (after selecting with RED BUTTON and entering with GREEN BUTTON), long press the GREEN BUTTON for 1 second (after selecting the "SET" sub options in Set Data menu) to enter the variable data setup mode.
  - This allows you to set custom height and weight data points for each tank using YELLOW 2 and the rotary encoder.

#### **YELLOW 1 BUTTON:**

- 1. Short press to cycle through sub-options in a menu.
  - o In **Set Height** mode: Cycles through Tank A, B, C to set heights.
  - In Set Data mode: Cycles through YES, NO, SET options to choose the data set.
  - In Tank Display mode: Cycles through Tank A, B, C to view levels, or shows a back arrow ("<--") to exit.</li>
  - In Variable Data Setup mode: Switches between Tank A, B, C to set custom data points.
- 2. Hold (for 1 second) to confirm data set choice.
  - o In the "Set Data" menu:
    - Long press YELLOW 1 on "YES" to use variable data (custom values).
    - Long press YELLOW 1 on "NO" to use hardcoded data (predefined values).
    - Long press GREEN BUTTON on "SET" to set the custom values.
  - The choice is saved to the SD card after a long press.

### **YELLOW 2 BUTTON:**

- 1. **Short** press to cycle through variable data points.
  - In Variable Data Setup mode (after long pressing GREEN BUTTON in "Set Data"):
    - Short press YELLOW 2 to cycle through 20 data points (1-20) for the selected tank (chosen with YELLOW 1).
    - Each press alternates between height and weight (e.g., 1 Height, 1 Lbs, 2 Height, 2 Lbs, etc.).
  - Use the rotary encoder to adjust the height (cm) or weight (lbs) for the current data point.
  - o Values are saved to the SD card with each **YELLOW 2** press.

#### **ROTARY ENCODER:**

- 1. Turn the knob clockwise or counter clockwise to increase the value.
- 2. If you decrease the value, **press** the rotary encoder and turn the knob clockwise or counter clockwise.
- 3. **Press** the rotary encoder again if you want to increase the value.

## **ADDITIONAL NOTES:**

- **Ultrasonic Mode**: After long pressing the RED BUTTON, the system measures the tank selected by **YELLOW 1** (Tank A, B, or C) and displays real-time data:
  - o Tank name, percentage, height (cm), weight (lbs), and liters.
  - o To exit, short press the **RED BUTTON** to cycle back to the main menu.

## • Exiting Menus:

- From Set Height or Set Data, short press the GREEN BUTTON to return to the main menu.
- From Tank Display, press YELLOW 1 until the back arrow ("<---") appears, then press GREEN BUTTON to return to the main menu.
- From Variable Data Setup, short press the GREEN BUTTON to return to the main menu.