

06-3644-API-TX30 AUG 06 , 2008

# **Application Programmers**Interface for MP3 Decoder

ABSTRACT:

Application Programmers Interface for MP3 Decoder

**KEYWORDS:** 

Multimedia codecs, MP3

## **Revision History**

VERSION	DATE	AUTHOR	CHANGE DESCRIPTION
0.1	18-Feb-2004	Zakir	Initial Draft
1.0	23-Feb-2004	Zakir	Internal review comments incorporated
1.1	06-Mar-2004	Zakir	Customers comments incorporated
1.2	21-Jun-2004	Zakir	Release for ARM9E
1.3	27-Jul-2004	Zakir	PCS comments incorporated.
2.0	06-Feb-2006	Lauren Post	Using new format
2.1	16-Oct-2006	Madhav Varma	Added bit-rate variable in the config structure
2.2	11-Apr-2007	Katherine Lu	Modified input buffer from 16- bit unit to 8-bit unit
			Updated structure to be same as the source code
2.3	17-Oct-2007	Terry Lv	Release of mp3d 1.08.
2.4	25-Mar-2008	Zhongsong Lin	Enable Push mode
2.5	20-May-2008	Bing Song	Add version information
2.6	06-Aug-2008	Baofeng Tian	Output data format change

## **Table of Contents**

ntroduc	ction	4
1.1	Purpose	4
1.2		
1.3		
1.4	•	
1.4.	1 Standards	4
1.4.	2 General references	4
1.4.	Freescale Multimedia References	5
1.5	Definitions, Acronyms, and Abbreviations	5
1.6	Document Location	6
API	Description	7
Step 1	: Allocate memory for Decoder parameter structure	7
Step 4	: Memory allocation for input buffer	11
	: Initialization routine	
-		
Step 6	: Memory allocation for output buffer	12
	: Memory allocation for output buffer: : Call the frame decode routine	
Step 7		12
	1.1 1.2 1.3 1.4 1.4. 1.4. 1.5 1.6 <b>API</b> Step 1 Step 2 Step 3 Step 4	1.1 Purpose

### Introduction

## 1.1 Purpose

This document gives the details of the application programmer's interface of the MP3 Decoder.

## 1.2 Scope

This document describes only the functional interface of the MP3 decoder. It does not describe the internal design of the decoder. Specifically, it describes only those functions by which a software module can use the decoder.

## 1.3 Audience Description

The reader is expected to have basic understanding of Audio Signal processing and MP3 decoding. The intended audience for this document is the development community who wish to use the MP3 decoder in their systems.

#### 1.4 References

#### 1.4.1 Standards

- ISO/IEC 11172-3:1993 Information technology -- Coding of moving pictures and associated audio for digital storage media at up to about 1.5 Mbit/s -- Part 3: Audio (popularly known as *MPEG-1 Audio*).
- ISO/IEC 11172-4:1995 Information technology -- Coding of moving pictures and associated audio for digital storage media at up to about 1.5 Mbit/s -- Part 4: Conformance testing (known as *MPEG-1 Conformance Testing*).
- ISO/IEC 13818-3:1998 Information technology -- Coding of moving pictures and associated audio information -- Part 3: Audio (popularly known as *MPEG-2 Audio LSF*).
- "MPEG Layer-3 Bitstream Syntax and Decoding" by Ralph Sperschneider, issue 1.3 dated 9<sup>th</sup> Sep 1997. (This document describes the bitstream syntax of of ISO/MPEG layer3 bitstream. This also includes syntax extension of MPEG Layer3 bitstream to meet the requirements of very low bitrates and sampling frequencies {8Khz, 11.025Khz, 12Khz}. These lower sampling frequencies syntax extension is not standardized by ISO is called MPEG-2.5)

### 1.4.2 General references

- Ted Painter and Andreas Spanias, "Perceptual Coding of Digital Audio", Proc. IEEE, vol-88, no.4, april 2000
- H.S.Malvar, "Lapped transforms for efficient subband/transform coding", IEEE trans. ASSP, June 1990.

- J.P.Princen, A.W.Johnson, A.B.Bradley, "Subband/transform coding using filterbank design based on time domain aliasing cancellation", in proc. IEEE Int. conference ASSP, april 1987
- MPEG Layer3 Bitstream syntax and decoding (Includes MPEG 2.5 layer3)
- "A Tutorial on MPEG/Audio compression" by Davis Pan

#### 1.4.3 Freescale Multimedia References

- MP3 Decoder Application Programming Interface mp3\_dec\_api.doc
- MP3 Decoder Requirements Book mp3 dec reqb.doc
- MP3 Decoder Test Plan mp3\_dec\_test\_plan.doc
- MP3 Decoder Release notes mp3\_dec\_release\_notes.doc
- MP3 Decoder Test Results mp3\_dec\_test\_results.doc
- MP3 Decoder Performance Results mp3\_dec\_perf\_results.doc
- MP3 Decoder Interface Header mp3\_dec\_interface.h
- MP3 Decoder Application Code mp3\_dec\_api.c

## 1.5 Definitions, Acronyms, and Abbreviations

TERM/ACRONYM	DEFINITION
AAC	Advanced Audio Coding
ADIF	Audio_Data_Interchange_Format
ADTS	Audio_Data_Transport_Stream
API	Application Programming Interface
ARM	Advanced RISC Machine
DAC	Digital to Analog Converter
FSL	Freescale
IEC	International Electro-technical Commission
ISO	International Standards Organization
LC	Low Complexity
MDCT	Modified Discrete Cosine Transform
MP3	Layer 3, MPEG2 Layer3 and MPEG2.5 Layer 3
MPEG	Moving Pictures Expert Group
OS	Operating System
PCM	Pulse Code Modulation
PNS	Perceptual Noise Substitution
RVDS	ARM RealView Development Suite
TBD	To Be Determined
UNIX	Linux PC x/86 C-reference binaries

## 1.6 Document Location

docs/mp3 dec

## 2 API Description

This section describes the steps followed by the application to call the MP3 decoder. During each step the data structures used and the functions used will be explained. Pseudo code is given at the end of each step. The member variables inside the structure are prefixed as mp3d\_ or app\_ to indicate if that member variable needs to be initialized by the decoder or application.

The MP3 decoder API currently support 2 kinds of bitstream mode: the PUSH mode and the PULL (which has been adopted before this version) mode. In the PUSH mode, the decoder will not call swap functions to read in MP3 bitstreams as the original PULL mode does. It is the application's duty to supply enough bitstream for the decoder to decode one frame. PUSH and PULL mode is switched in the makefile of decoder, but both modes share the same interface definition.

## **Step 1: Allocate memory for Decoder parameter structure**

The application allocates memory for the structure mentioned below. This structure contains the decoder parameters and memory information structures.

```
/* Decoder parameter structure */
typedef struct {
     MP3D_Mem_Alloc_Info mp3d_mem_info;
Void *mp3d_decode_i
                               *mp3d_decode_info_struct_ptr;
      MP3D_OUTPUT_FORMAT
MP3D_INT8
                                app out format;
                                (*app swap buf)
                                      MP3D UINT8 ** new buf ptr,
                                      MP3D INT32 *new buf len,
                                      MP3D Decode Config *dec config);
      MP3D INT8*
                                 pInBuf;
      MP3D INT16
                                 inBufLen;
      MP3D\_INT16
                                 consumedBufLen;
} MP3D Decode Config;
```

#### Description of the decoder parameter structure

#### mp3d\_mem\_info

This is memory information structure. The application needs to call the function mp3d\_query\_dec\_mem to get the memory requirements from decoder. The decoder will fill this structure. This will be discussed in step 2.

#### mp3d\_decode\_info\_struct\_ptr

This is a void pointer. This will be initialized by the decoder during the initialization routine. This will then be a pointer to a structure which contains the pointers to tables, buffers and symbols used by the decoder.

#### app out format

The application has to indicate the decoder the output precision required to be outputted. The decoder can output the PCM samples either as 16bit samples or as 24bit samples.

#### app\_swap\_buf (used in PULL mode only)

Function pointer to swap buffers. The application has to initialize this pointer.

#### pInBuf (used in PUSH mode only)

Pointer. to input bitsream. The application has to set this value correctly before decoding one frame.

#### *inBufLen* (used in PUSHmode only)

Length of the input buffer..The application has to set this value correctly before decoding one frame.

#### consumedBufLen (used in PUSH mode only)

The length of bitstream consumed by decoding one frame. The decoder return this value to the application.

#### Example pseudo code for this step:

## Step 2: Get the decoder version information

This function returns the codec library version information details. It can be called at any time and it provides the library's information: Component name, supported ARM family, Version Number, supported OS, build date and time and so on.

The function prototype of *mp3d\_decode\_versionInfo* is :

#### C prototype:

```
const MP3D INT8 * mp3d decode versionInfo();
```

#### **Arguments:**

• None.

#### **Return value:**

• const char \* - The pointer to the constant char string of the version information string.

#### Example pseudo code for the memory information request

```
{
   // Output the MP3 Decoder Version Info
   printf("%s \n", mp3d decode versionInfo());
```

}

## Step 3: Get the decoder memory requirements

The MP3 decoder does not do any dynamic memory allocation. The application calls the function  $mp3d\_query\_dec\_mem$  to get the decoder memory requirements. This function must be called before all other decoder functions are invoked.

The function prototype of *mp3d\_query\_dec\_mem* is :

#### C prototype:

```
MP3D_RET_TYPE mp3d_query_dec_mem (MP3D_Decode_Config * dec_config);
```

#### **Arguments:**

• dec config

- Decoder config pointer.

#### **Return value:**

- MP3D\_OK Memory query successful.
- Other codes
   Error (For other error codes refer to appendix).

This function populates the memory information structure, which is described below:

#### Memory information structure array

#### Description of the structure MP3D Mem Alloc Info

#### mp3d\_num\_regs

The number of memory chunks requested by the decoder.

#### mem\_info\_sub

This structure contains each chunk's memory configuration parameters.

Description of the structure MP3D\_Mem\_Alloc\_Info\_sub

#### mp3d size

The size of each chunk in bytes.

#### *mp3d\_type*:

The type of the memory indicates if the requested chunk of memory needs to be allocated in external or internal memory. The type of memory can be SLOW\_MEMORY or external memory, FAST\_MEMORY or internal memory. In targets where there is no internal memory, the application can allocate memory in external memory. (Note: If the decoder request for a FAST\_MEMORY for which the application

( Note: If the decoder request for a FAST\_MEMORY for which the application allocates a SLOW\_MEMORY, the decoder will still decode, but the performance (Mhz) will suffer.)

#### mp3d\_mem\_desc

The memory description field indicates whether requested chunk of memory is static or scratch.

#### mp3d\_priority

In case, if the decoder requests for multiple memory chunks in the Fast memory, the priority indicates the order in which the application has to prioritize placing the requested chunks in Fast memory.

#### app\_base\_ptr

This will be initialized by the application. The application will allocate the memory for each chunk depending on the requested size and the type and assign the base pointer of this chunk of memory to *app\_base\_ptr*. The application should allocate the memory which is aligned to a 4 byte boundary in any case.

#### Example pseudo code for the memory information request

```
/* Query for memory */
retval = mp3d_query_dec_mem (&dec_config);
if (retval != MP3D_OK)
    return 1;
```

## **Step 4: Allocate Data Memory for the decoder**

In this step the application allocates the memory as required by MP3 Decoder and fills up the base memory pointer 'app\_base\_ptr' of 'MP3D\_Mem\_Alloc\_Info\_sub' structure for each chunk of memory requested by the decoder.

Example pseudo code for the memory allocation and filling the base memory pointer by the application

```
MP3D_Mem_Alloc_Info_sub *mem;
```

The functions alloc\_fast and alloc\_slow are required to allocate the memory aligned to 4 byte boundry.

## Step 5: Memory allocation for input buffer (pull mode)

The application has to allocate the memory needed for the input buffer. It is desirable to have the input buffer allocated in FAST\_MEMORY, as this may improve the performance (Mhz) of the decoder. There is no restriction on the size of the input buffer to be given to the decoder. The recommended minimum size would be 2Kbytes. The decoder, whenever it needs the MP3 bitstream, shall call the function *app\_swap\_buffers\_mp3\_dec* internally from the function *mp3\_decode frame*.

app\_swap\_buffers\_mp3\_dec should be implemented by the application. The application might have different techniques to implement this function. Sample code is given in section 5.1.1

Example pseudo code for allocating the input buffer

```
/* Allocate memory for input buffer */
input buffer = alloc fast(MP3D INPUT BUFFER SIZE);
```

## Step 6: Initialization routine

All initializations required for the decoder are done in  $mp3d\_decode\_init$ . This function must be called before the main decoder function is called. The input buffer pointer and the input buffer length needs to be passed to the initialization function. This is required by the decoder to start decoding the bitstream to begin with.

```
C prototype:
```

```
MP3D_UINT8 *input buffer,
MP3D_INT32 input buffer length);
```

#### **Arguments:**

• Decoder parameter structure pointer.

• input\_buffer Initial pointer to the input buffer

• input\_buffer\_length Length of the input buffer passed in bytes.

#### **Return value:**

MP3D\_OK - Initialization successful.
 Other codes - Initialization Error

#### Example pseudo code for calling the initialization routine of the decoder

```
/* input buffer length to be passed */
input_buffer_length = MP3D_INPUT_BUFFER_SIZE;

/* Initialize the MP3 decoder. */
retval = mp3d_decode_init (dec_config, input_buffer, input_buffer_length);

if (retval != MP3D_OK)
    return 1;
```

## Step 7: Memory allocation for output buffer

The application has to allocate memory for the output buffers to hold the decoded stereo PCM samples for a maximum of one frame size. The pointer to this output buffer needs to be passed to the mp3d\_decode\_frame function. The application can allocate memory for output buffer using alloc\_fast. Allocating memory in internal memory using alloc\_fast will improve the performance (Mhz) of the decoder marginally. Mp3 decoder provide two type of output data format, correspondingly, there should exist two kind of output buffer allocation case.

#### Example pseudo code for allocating memory for output buffer

```
/* Allocate memory for output buffer */
MP3D_FRAME_SIZE = 576;
if( dec_config->app_out_format == MP3D_24_BIT_OUTPUT )
  outbuf = (MP3D_INT32 *)alloc_fast ((sizeof(long))*2*2*MP3D_FRAME_SIZE);
else
  outbuf = (MP3D_INT32 *)alloc_fast ((sizeof(short))*2*2*MP3D_FRAME_SIZE);
```

## Step 8: Call the frame decode routine

The main MP3 decoder function is  $mp3d\_decode\_frame$ . This function decodes the MP3 bit stream in the input buffer to generate one frame of decoder output per channel in every call. The output buffer is filled with left channel and the right channel samples interleaved. For 16-bit stereo output, left sample and right sample use one compact 32-bit word. For 24-bit stereo output, each sample

use one 32-bit word, locate in lsb part. In case of mono streams, the decoder fills samples in a sequential order.

The decoder fills up the structure MP3D\_Decode\_Params.

```
typedef struct {
    MP3D_INT32 mp3d_sampling_freq;
    /* Sampling frequency of the current frame in Khz */
    MP3D_INT32 mp3d_num_channels;
    /* Number of channels decoded in current frame */
    MP3D_INT32 mp3d_frame_size;
    /* Number of stereo samples being outputted for this frame */
    MP3D_INT32 mp3d_bit_rate;
    /* Indicates bit- rate in kbps .
        The decoder fills this variable after parsing the header*/
    MP3D_INT32 layer;
    /* MPEG layer of the current stream
        * 1 for layer-I,2 for layer-II and 3 for layer-III */
    MP3D_INT32 mp3d_remain_bytes;
} MP3D_Decode_Params;
```

If the bit stream has errors, the decoder will try to find the next sync pattern for all types of errors (mentioned in the appendix), except for the MP3D\_END\_OF\_STREAM.

#### C prototype:

#### **Arguments:**

dec\_config
 dec\_param
 Decoder parameter structure pointer
 Decoder output parameter pointer

output\_buffer
 Pointer to the output buffer to hold the decoded samples

#### **Return value:**

• MP3D OK Indicates decoding was successful.

• Others Indicates error

When the decoder encounters the end of bitstream, the application comes out of the loop. In case of error while decoding the current frame, the application can just ignore the frame without processing the output samples by continuing the loop.

In case of mono bitstreams, as mentioned earlier the decoder fills samples in a sequential order. It is the responsibility of the application to use it accordingly. One example is the case in which the application can copy the left channel samples into right channel. This is illustrated in the example code below.

Example pseudo code for calling the main decode routine of the decoder

```
#ifdef PUSH_MODE
/* a size thread is used to make sure one frame of mp3 bitstream is in
the input buffer when in PUSH mode
*/
    const int sizeThread = SIZE_THREAD;
```

```
#endif
while (TRUE)
      /* Decode one frame */
      /* The decoded parameters for this frame is available in the
       * structure MP3D_Decode_Params */
      retval = mp3d decode frame (dec config, &dec param, outbuf);
      if (retval == MP3D END OF STREAM)
            /* Reached the end of bitstream */
            break;
      if (retval != MP3D OK)
            /* Invalid frame encountered, do not output */
            continue;
      /* If mono, copy the left channel to the right channel. */
      if (dec_param.mp3d_num_channels == 1)
            int i;
            i = dec_param.mp3d_frame_size-1;
for (; i >= 0; i--)
                outbuf [2 * i] = outbuf [i];
                outbuf [2 * i + 1] = outbuf [i];
      /* The output frame is ready for use. Decoding of the next frame
       * should start only if the previous output frame has been fully
       * output by the application.
       audio output frame(outbuf, 2*MP3D FRAME SIZE);
      #ifdef PUSH MODE
        In PUSH mode, input buffer size should be large than SIZE_THREAD
        in the exception that the end of bitstream has been reached
      */
         leftLength = dec config->inBufLen - dec config->consumedBufLen;
         if(leftLength<0)
            break;
         if(leftLength>sizeThread)
            dec config->pInBuf += dec config->consumedBufLen;
            dec config->inBufLen -= dec config->consumedBufLen;
            dec config->consumedBufLen =0;
       eĺse
            memcpy(mp3 input, (dec config->pInBuf+dec config-
>consumedBufLen),leftLength);
```

## **Step 9: Free memory**

The application releases the memory that it allocated to MP3 Decoder if it no longer needs the decoder instance.

```
free (outbuf);
free (inpbuf);
for (i=0; i<nr; i++)
{
         free (dec_config->mem_info_sub[i].app_base_ptr);
}
free (dec_config);
```

## 2.1 Call back function usage

Call back function is only used when in PULL mode. It is called by the decoder to get a new input buffer for decoding. This function is called by the MP3 decoder within the mp3d\_decode\_frame function when it runs out of current bit stream input buffer. The decoder uses this function to return the used buffer and get a new bit stream buffer. The call back function call by the decoder will be a function pointer call. This function will be assigned to the pointer app\_swap\_buff before the init is called.

This function should be implemented by the application. The parameter new\_buf\_ptr is a double pointer. This will hold the recently used buffer by the decoder when this function is called. The application can decide to free this or do any sort of arithmetic to get any new address. The application needs to put the new input buffer pointer in \*new\_buf\_ptr to be used by the decoder.

The interface for this function is described below:

#### C prototype:

#### **Arguments:**

- new\_buf\_ ptr
- new\_buf\_len
- mp3d\_decoder\_config
- Pointer to the new buffer given by the application.
- Pointer to length of the new buffer in bytes. (8bit)
- Decoder configuration structure.

#### **Return value:**

- 0
- -1

- Buffer allocation successful.
- End of bitstream

#### Example pseudo code

```
INT8 app swap buffers mp3 dec (MP3D UINT8 ** new buf ptr,
                               MP3D INT32 * new buf len,
                               MP3D Decode Config *mp3d decoder config)
{
     Request for an input buffer from the application.
     Wait for the input buffer.
     If the new buffer arrives
            Return the used buffer to the application.
            Set the new buf ptr to point to the new buffer and
            set *new buf len to the length of the new buffer.
            Return 0 to the calling function to indicate that new buffer
            has been received.
     Else if the application indicates end of bit stream
            Set new buf ptr to NULL and *new buf len to 0.
            Return -1 to the calling function to indicate the end of
            input bit stream.
```