

# Timers CCP Module

Dpt. Enginyeria de Sistemes, Automàtica i Informàtica Industrial


## Introduction


- **Time** is represented by the count in a timer.
- There are many applications that cannot be implemented without a timer:
  - 1. Event arrival time recording and comparison
  - 2. Periodic interrupt generation
  - 3. Pulse width and period measurement
  - 4. Frequency and duty cycle measurement
  - 5. Generation of waveforms with certain frequency and duty cycle
  - 6. Time references
  - 7. Event counting
  - 8. Others

#### **Generic Timers** Clock source (IN) CLK 0 BUS GATE 0 Pause (IN) OUT 0 Rollover (OUT) Countdown reached CLK 1 READ/ WRITE LOGIC GATE 1 + OUT 1 E.g. Configurable counter: One countdown: CLK 2 CTRL WORD GATE 2 N, N-1, ...,2,1,0,0,0,0 REG. OUT 2 Cyclic countdown: N, N-1, ...,2,1,0,N, N-1, ...,2,1,0

# **The PIC18 Timer System**


- A PIC18F45K22 microcontroller has to 7 timers: Timer 0...Timer 6.
- Timer 0, Timer 1, Timer 3 and Timer 5 are 16-bit timers whereas Timer 2, Timer 4 and Timer 6 are 8-bit.
- When a timer rolls over, an interrupt may be generated if it is enabled.
- Timer 2, Timer 4 and Timer 6 use instruction cycle clock as the clock source whereas the other timers may also use external clock input as the clock source.
- Timer 0 is designed to act as a time base (core interrupt) while the other timers are in the peripheral group (alternate time base and CCP operation).







## The PIC18 Timer1/3/5

- Is a 16-bit timer/counter depending upon the clock source.
- An interrupt may be requested when TimerX rolls over from 0xFFFF to 0x0000.
- TimerX operation is controlled by the TxCON and TxGCON register.
- These timers have a number of frequency input sources and a complex gate enable circuitry (if TMRxGE=1)
- These timers can be used to create time delays and measure the frequency of an unknown signal (using the CCP modules).






		TxC	CON	Regis	ster		
REGISTER 1	2-1: TXCO	N: TIMER1/3	/5 CONTRO	L REGISTER			
R/W-0/u	R/W-0/u	R/W-0/u	R/W-0/u	R/W-0/u	R/W-0/u	R/W-0/0	R/W-0/u
TMRxC	S<1:0>	TxCKF	PS<1:0>	TxSOSCEN	TxSYNC	TxRD16	TMRxON
bit 7							bit 0
bit 5-4	10 = Time If Tx Exte If Tx Crys 01 = Time 00 = Time	erved. Do not use. scr1/3/5 clock source SOSCEN = 0: rnal clock from Tx SOSCEN = 1: tal oscillator on St r1/3/5 clock source r1/3/5 clock source r1/3/5 clock source r1/3/5 clock source	e is pin or oscillat CKI pin (on the ris DSCI/SOSCO pin e is system clock e is instruction clo	sing edge) s (Fosc) ock (Fosc/4)			
	11 = 1.8 Prescale value 10 = 1.4 Prescale value 01 = 1.2 Prescale value 00 = 1.1 Prescale value						
bit 3	3 TxSOSCEN: Secondary Oscillator Enable Control bit 1 = Dedicated Secondary oscillator circuit enabled 0 = Dedicated Secondary oscillator circuit disabled						
bit 2	TMRxCS 1 = Do n 0 = Sync	<1:0> = 1X ot synchronize ext hronize external c <1:0> = 0X	emal clock input lock input with sy	rnchronization Control stem clock (Fosc)			
bit 1	TxRD16: 1 = Enab	16-Bit Read/Write les register read/v	Mode Enable bit write of Timer1/3/5		tion		
bit 0	1 = Enab 0 = Stops	: Timer1/3/5 On b les Timer1/3/5 : Timer1/3/5 s Timer1/3/5 Gate					



## The PIC18 Timer2/4/6

- There are 3 8 bit timer/counters with clock source Finstr (Fosc/4) and prescaler and postscaler block logic.
- Controlled by TxCON and related to PRx registers. Can generate interrupts via TMRxIF.
- They can be a source for PWM signals (CCP modules).



#### **T2CON Register** REGISTER 13-1: TxCON: TIMER2/TIMER4/TIMER6 CONTROL REGISTER U-0 R/W-0 TxOUTPS<3:0> TMRxON TxCKPS<1:0> bit 7 bit 0 Legend: R = Readable bit W = Writable bit U = Unimplemented bit, read as '0' u = Bit is unchanged x = Bit is unknown -n/n = Value at POR and BOR/Value at all other Resets '1' = Bit is set '0' = Bit is cleared Unimplemented: Read as '0' bit 6-3 TxOUTPS<3:0>: TimerX Output Postscaler Select bits 0000 = 1:1 Postscaler 0001 = 1:2 Postscaler 0010 = 1:3 Postscale 0010 = 1:3 Postscaler 0011 = 1:4 Postscaler 0100 = 1:5 Postscaler 0101 = 1:6 Postscaler 0110 = 1:7 Postscaler 0111 = 1:8 Postscaler 0111 = 1:8 Postscaler 1000 = 1:9 Postscaler 1001 = 1:10 Postscaler 1001 = 1:10 Postscaler 1001 = 1:11 Postscaler 1001 = 1:12 Postscaler 1100 = 1:13 Postscaler 1101 = 1:14 Postscaler 1110 = 1:15 Postscaler 1111 = 1:16 Postscaler TMRxON: TimerX On bit bit 2 1 = TimerX is on 0 = TimerX is off TxCKPS<1:0>: Timer2-type Clock Prescale Select bits 00 = Prescaler is 1 01 = Prescaler is 4 1x = Prescaler is 16


## The PIC18 CCP units


- A PIC18 device may have one, two, or **five (K22)** CCP modules.
- CCP stands for Capture, Compare, and Pulse Width Modulation.
- Each CCP module can be configured to perform capture, compare, or PWM function.
- In **capture** operation, the CCP module copy the contents of a 16 bit timer into a capture register on a signal edge.
- In **compare** operation, the CCP module compares the contents of a CCPR register with that of a Timer (1, 3 or 5) in every clock cycle. When these two registers are equal, the associated pin may be pulled to high, or low, or toggled.
- In **PWM** mode, the CCP module can be configured to generate a waveform with certain <u>frequency</u> and <u>duty cycle</u>. Timers 2/4/6 are related with the PWM hardware.

# Capture/Compare/PWM (CCP) Modules

- PIC18F45K22 has 5 CCP Modules.
- Each CCP module requires the use of timer resource.
- In capture or compare mode, the CCP module may use either Timer1, Timer3 or Timer5 to operate.
- In PWM mode, either Timer2, Timer4 or Timer6 may be used.
- The operation of a CCP module is controlled by the CCPxCON register (to select the mode), the CCPTMRS0 and CCPTMRS1 registers (to select the operating timer) and the 16-bits data register CCPRx (CCPRxH and CCPRxL).
- A device pin (CCPx pin) can be associated to CCP module operation (with appropriate TRIS configuration).

				₹eσi	icter	•
		CCPxC		it cg.		
14.5 Re	gister Defir	itions: ECCP Control				
REGISTER		xCON: STANDARD CCP:	x CONTROL R	EGISTER		
U-0	U-0	R/W-0 R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
_	_	DCxB<1:0>		CCPx	(M<3:0>	
bit 7						bit (
Legend:						
R = Readab	le bit	W = Writable bit	U = Unimpler	nented bit, rea	nd as '0'	
u = Bit is un	changed	x = Bit is unknown	-n/n = Value a	t POR and BO	OR/Value at all	other Reset
'1' = Bit is se	et	'0' = Bit is cleared				
bit 7-6	Unused					
bit 5-4	DCxB<1:0	: PWM Duty Cycle Least Sign	nificant bits			
	Capture mo Unused	ide:				
	Compare m Unused	iode:				
	PWM mode These bits	gre the two LSbs of the PWM	duty cycle. The el	ght MSbs are f	found in CCPR:	tL.
bit 3-0	CCPxM<3:	0>: ECCPx Mode Select bits				
		pture/Compare/PWM off (rese	ts the module)			
	0001 = Re 0010 = Co	servea mpare mode: toggle output on	match			
	0011 = Re					
	0100 = Ca	pture mode: every falling edge				
		pture mode: every rising edge	_			
		pture mode: every 4th rising e pture mode: every 16th rising (				
			-			
		mpare mode: set output on co				
	1010 = Co	mpare mode: clear output on o mpare mode: generate softwa PxIF is set)				
		mpare mode: Special Event Tr TimerX (selected b	y CxTSEL bits) is	reset		
		ADON is set, starti	ing A/D conversion	n if A/D modul	e is enabled <sup>(1)</sup>	
	11xx =: PV	vivi mode vailable on CCP5 only.				







# **Capture Mode**

- Main use of CCP is to capture **event** arrival time
- An event is represented by a signal edge.

The PIC18 event can be one of the following:

- 1. every falling edge
- 2. every rising edge
- 3. every 4th rising edge
- 4. every 16th rising edge





# **Compare Mode**


- 16-bit CCPRx register is compared against one of the Timers(1/3/5).
- When they match, one of the following actions may occur on the associated CCPx pin:
  - 1. driven high
  - 2. driven low
  - 3. toggle output
  - 4. remains unchanged


### **Software Interrupt Mode**

When Generate Software Interrupt mode is chosen (1010), the CCPx module does not assert control of the CCPx pin.

#### **Special Event Trigger**

The CCPx modules can also generate this event (mode 1011) to reset TMR1/3/5 depending on which timer is the base timer. When this mode is selected CCP5 will start an ADC conversion, if the ADC is enabled.





Pitch table									
Frequency (Hz)									
Note	Octave 0	Octave 1	Octave 2	Octave 3	Octave 4	Octave 5	Octave 6	Octave 7	
C	16.351	32.703	65.406	130.813	261.626	523.251	1046.502	2093.005	
C#,Db	17.324	34.646	69.296	138.591	277.183	554.365	1100.731	2217.461	
D	18.354	36.708	73.416	146.832	293.665	587.330	1174.659	2349.318	
D#,Eb	19.445	38.891	77.782	155.563	311.127	622.254	1244.508	2489.016	
E	20.061	41.203	82.407	164.814	329.626	659.255	1318.510	2367.021	
F	21.827	43.654	87.307	174.614	349.228	698.456	1396.913	2637.021	
F#,Gb	23.124	46.249	92.449	184.997	369.994	739.989	1474.978	2959.955	
G	24.499	48.999	97.999	195.998	391.995	783.991	1567.982	3135.964	
G#,Ab	25.956	51.913	103.826	207.652	415.305	830.609	1661.219	3322.438	
A	27.500	55.000	110.000	220.000	440.000	880.000	1760.000	3520.000	
A#,Bb	29.135	58.270	116.541	233.082	466.164	932.326	1664.655	3729.310	
В	30.868	61.735	123.471	246.942	493.883	987.767	1975.533	3951.066	

# **Example code:**

For the circuit in Figure 8.22, write a program to generate a simple song assuming that  $f_{\rm OSC}$  = 4MHz.

#### Solution:

Two tables are used by the program. 1) Table of numbers to be added to CCPR1 register to generate the waveform with the desired frequency. 2) Table of numbers that select the duration of each note. CCP1 module is used to generate te signal -compare mode toggle CCP1 pin on match-. TIMER0 is used for note duration.

#include	<xc.h></xc.h>		Example XC8
#define	base	3125 // counter count to	create 0.1 s delay
#define	NOTES	38 // total notes in the	song to be played
			const unsigned int per_arr[38]={ C4,A4,G4,A4,F4,C4,C4,C5,
#define	C4	0x777 // semioperiod	B4,C5,A4,A4,F4,D5,D5,D5,
#define	F4	0x598 // for each	C5,A4,C5,C5,B4,A4,B4,C5,
#define	G4	0x4FC // note freq	A4,F4,D5,F5,D5,C5,A4,C5,
#define	A4	0x470	C5,B4,A4,B4,C5,A4};
#define	B4	0x3F4	
#define	C5	0x3BC	const unsigned char wait[38] = $\{3,5,3,3,5,3,5,3,5,5,5,5,5,5,5,5,5,5,5,5$
#define	D5	0x353	3,3,5,3,3,5,3,3,
#define	F5	0x2CC	5,3,3,2,2,3,3,
			6,3,5,3,3,5,3,3,
unsigned	l int half_cy	cle;	3,2,2,3,3,6};


```
void delay (unsigned char xc);
void interrupt high_ISR(void)
{
    if (PIE1bits.CCP1IE && PIR1bits.CCP1IF) {
        PIR1bits.CCP1IF = 0;
        CCPR1 += half_eycle;
    }
}


void interrupt low_priority low_ISR (void)
{
}
```

```
void main (void)
{ int i, j;
   TRISCbits.TRISC2 = 0; /* configure CCP1 pin for output */
   T3CON = 0x81; /* enables Timer3 in 16-bit mode, Timer1 for CCP1 time base */
   T1CON = 0x81; /* enable Timer1 in 16-bit mode */
   CCP1CON = 0x02; /* CCP1 compare mode, pin toggle on match */
   IPR1bits.CCP1IP = 1; /* set CCP1 interrupt to high priority */
   PIR1bits.CCP1IF = 0; /* clear CCP1IF flag */
   PIE1bits.CCP1IE = 1; /* enable CCP1 interrupt */
   INTCON \models 0xC0; /* enable high priority interrupt */
   for (j = 0; j < 3; j++) { /* Play song several times */
       i = 0;
       half_cycle = per_arr[0];
       CCPR1 = TMR1 + half_cycle;
       while (i < NOTES) {
             half_cycle = per_arr[i]; /* get the cycle count for half period of the note */
             delay (wait[i]);
                                   /* stay for the duration of the note */
             i++;
       INTCON &= 0x3F; /* disable interrupt */
                            /* Pause before replay song */
       delay (11);
       INTCON |= 0xC0; /* re-enable interrupt */
}
```

```
/* The following function runs on a PIC18 demo board running with a 4 MHz crystal */
/* oscillator. The parameter xc specifies the amount of delay to be created
void delay (unsigned char xc)
     switch (xc){
                       /* create 0.1 second delay (sixteenth note) */
                T0CON = 0x84; /* enable TMR0 with prescaler set to 32 */
                TMR0 = 0xFFFF - base; /* set TMR0 to this value so it overflows in 0.1 second */
                INTCONbits.TMR0IF = 0;
                while (!INTCONbits.TMR0IF);
                break;
          case 2:
                      /* create 0.2 second delay (eighth note) */
               T0CON = 0x84; /* set prescaler to Timer0 to 32 */
                TMR0 = 0xFFFF - 2*base; /* set TMR0 to this value so it overflows in 0.2 second */
                INTCONbits.TMR0IF = 0;
                while (!INTCONbits.TMR0IF);
                break;
                      /* create 0.4 seconds delay (quarter note) */
          case 3:
                T0CON = 0x84; /* set prescaler to Timer0 to 32 */
                TMR0 = 0xFFFF - 4*base; /* set TMR0 to this value so it overflows in 0.4 second */
                INTCONbits.TMR0IF = 0;
                while (!INTCONbits.TMR0IF);
                break;
```

```
/* create 0.6 s delay (3 eighths note) */
                T0CON = 0x84; /* set prescaler to Timer0 to 32 */
                TMR0 = 0xFFFF - 6*base; /* set TMR0 to this value so it overflows in 0.6 second */
                INTCONbits.TMR0IF = 0;
                while (!INTCONbits.TMR0IF);
                break;
                       /* create 1.2 second delay (3 quarter note) */
                T0CON = 0x84; /* set prescaler to Timer0 to 32 */
                TMR0 = 0xFFFF - 12*base; /* set TMR0 to this value so it overflows in 1.2 second */
                INTCONbits.TMR0IF = 0;
                while (!INTCONbits.TMR0IF);
                break;
                       /* create 1.6 second delay (full note) */
          case 6:
                T0CON = 0x84; /* set prescaler to Timer0 to 32 */
                TMR0 = 0xFFFF - 16*base; /* set TMR0 to this value so it overflows in 1.6 second */
                INTCONbits.TMR0IF = 0;
                while (!INTCONbits.TMR0IF);
                break;
          default:
          break;
}
```





## **Period & Duty cycle**

#### **Pwm formulas:**

#### EQUATION 14-1: PWM PERIOD

 $PWM \ Period = [(PRx) + I] \bullet 4 \bullet TOSC \bullet$   $(TMRx \ Prescale \ Value)$ Note 1: Tosc = 1/Fosc

EQUATION 14-4: PWM RESOLUTION

Resolution =  $\frac{log[4(PRx + 1)]}{log(2)}$  bits

#### EQUATION 14-2: PULSE WIDTH

Pulse Width = (CCPRxL:CCPxCON<5:4>) •

Tosc • (TMRx Prescale Value)

EQUATION 14-3: DUTY CYCLE RATIO

Duty Cycle Ratio =  $\frac{(CCPRxL:CCPxCON<5:4>)}{4(PRx+1)}$ 

#### TABLE 14-7: EXAMPLE PWM FREQUENCIES AND RESOLUTIONS (Fosc = 32 MHz)

PWM Frequency	1.95 kHz	7.81 kHz	31.25 kHz	125 kHz	250 kHz	333.3 kHz
Timer Prescale (1, 4, 16)	16	4	1	1	1	1
PRx Value	0xFF	0xFF	0xFF	0x3F	0x1F	0x17
Maximum Resolution (bits)	10	10	10	8	7	6.6

#### TABLE 14-8: EXAMPLE PWM FREQUENCIES AND RESOLUTIONS (Fosc = 20 MHz)

PWM Frequency	1.22 kHz	4.88 kHz	19.53 kHz	78.12 kHz	156.3 kHz	208.3 kHz
Timer Prescale (1, 4, 16)	16	4	1	1	1	1
PRx Value	0xFF	0xFF	0xFF	0x3F	0x1F	0x17
Maximum Resolution (bits)	10	10	10	8	7	6.6

#### TABLE 14-9: EXAMPLE PWM FREQUENCIES AND RESOLUTIONS (FOSC = 8 MHz)

PWM Frequency	1.22 kHz	4.90 kHz	19.61 kHz	76.92 kHz	153.85 kHz	200.0 kHz
Timer Prescale (1, 4, 16)	16	4	1	1	1	1
PRx Value	0x65	0x65	0x65	0x19	0x0C	0x09
Maximum Resolution (bits)	8	8	8	6	5	5

## Programming recipe.

- 1. Disable the CCPx pin output driver by setting the associated TRIS bit.
- 2. Select the 8-bit TimerX resource, (Timer2, Timer4 or Timer6) to be used for PWM generation by setting the CxTSEL<1:0> bits in the CCPTMRSx register.(1)
- 3. Load the PRx register for the selected TimerX with the PWM period value.
- 4. Configure the CCP module for the PWM mode by loading the CCPxCON register with appropriate values.
- 5. Load the CCPRxL register and the DCxB<1:0> bits of the CCPxCON register, with the PWM duty cycle value.
- 6. Configure and start the 8-bit TimerX resource:
  - Clear the TMRxIF interrupt flag bit of the PIR2 or PIR4 register.
  - Configure the TxCKPS bits of the TxCON register with the Timer prescale value.
  - Enable the Timer by setting the TMRxON bit of the TxCON register.
- 7. Enable PWM output pin:
  - Wait until the Timer overflows and the TMRxIF bit of the PIR2 or PIR4 register is set.
  - Enable the CCPx pin output driver by clearing the associated TRIS bit.

# Light dimmer




Figure 8.25 Using PWM to control the brightness of a light bulb

## **DC Motor Control**

- DC motor speed is regulated by controlling its average driving voltage. The higher the voltage, the faster the motor rotates.
- Changing motor direction can be achieved by reversing the driving voltage.
- Motor braking can be performed by reversing the driving voltage for certain length of time.
- Most PIC18 devices have PWM functions that can be used to drive DC motors.
- Many DC motors operate with 5 V supply.
- DC motors require large amount of current to operate. Special driver circuits are needed for this purpose.
- A simplified DC motor control circuit is shown in Figure 8.26.




Figure 8.26A simplified circuit for DC motor control

