

AIoT Smart Fruit Quality Control - Wiring Diagram

Laptop (Python CNN) -- USB Serial 115200 baud --> NodeMCU ESP8266

NodeMCU pin	Relay module pin	Load
VIN (5V)	-----> VCC	
GND	-----> GND	
D1 / GPIO5	-----> IN1 -----> COM1 / NO1	-> 220 ohm -> Apple LED -> GND
D2 / GPIO4	-----> IN2 -----> COM2 / NO2	-> 220 ohm -> Lemon LED -> GND
D5 / GPIO14	-----> IN3 -----> COM3 / NO3	-> 220 ohm -> Orange LED -> GND
D6 / GPIO12	-----> IN4 -----> COM4 / NO4	-> 220 ohm -> Rotten LED -> GND

Relay logic: active LOW (LOW = ON, HIGH = OFF).

SAFETY: Use only LED or 5-12V DC demonstration loads. Do NOT use PLN 220V AC.

D5/D6 are used instead of boot-strapping GPIO0/GPIO2 for reliable ESP8266 startup.