

OCORA

Open CCS On-board Reference Architecture

CCS On-Board (CCS-OB)

Architecture

This OCORA work is licensed under the dual licensing Terms EUPL 1.2 (Commission Implementing Decision (EU) 2017/863 of 18 May 2017) and the terms and condition of the Attributions- ShareAlike 3.0 Unported license or its national version (in particular CC-BY-SA 3.0 DE).



Document ID: OCORA-TWS01-035

Version: 2.20

Date: 24.06.2022

Management Summary

This document is the 6th edition of the OCORA System / CCS On-Board Architecture. With this release, OCORA split the CCS On-Board Architecture (this document) from the System Architecture [24], which addresses the wider context of the CCS On-Board and identifies all systems of interest to OCORA.

Hence, this document is focussing on the CCS On-Board architecture only. It represents a significant step forward towards an open, modular, exchangeable, migratable, portable, and evolvable CCS On-Board system. Whilst considering economical aspects, modular safety, as well as cyber-security and sector feedback, a reasonable number of plug-and-play like building block have been identified with this release.

The development of the OCORA System Architecture follows an iterative approach, evolving within the progress of the OCORA collaboration. With this release, OCORA made its third step in using Model Based Systems Engineering (MBSE) based on the Arcadia methodology.

OCORA has started using the Capella MBSE tool for developing the logical architecture, well knowing that the Arcadia methodology proposes to start with the operational- and system-analysis before diving into the development of the logical architecture.

It has been a deliberate decision to develop a logical and physical architecture in parallel to conducting the operational- and system-analysis (refer to document [23] to review the current status of the operational- and system-analysis). For the following reasons, OCORA decided to deviate from the strict Arcadia proposed approach:

1. The CCS On-Board system is considered a sub-system of the overall CCS system which includes CCS on-board and CCS trackside. OCORA favours the development of the operational- and system-analysis on a system and not on a sub-system level. This is to ensure the proper development of the end-to-end functionality and to minimize integration efforts at a later stage. The collaboration with RCA for developing system capabilities has continued. However, OCORA aims to develop and communicate its ideas for the CCS On-Board in parallel. This can be done best through a high-level logical and physical architecture.
2. The CCS On-Board system is a well-known system that exists today and is already documented to a certain extent on a logical- and physical architectural level. Starting from this status quo architecture and applying the OCORA Guiding Principles [6], the OCORA Design-Requirements [22], the OCORA Stakeholder-Requirements [43], and the OCORA Program-Requirements [44], has dramatically accelerated the development of a 1st versions of the OCORA System Architecture. The currently proposed logical and physical architecture will be iteratively adjusted and concluded once functions are being allocated to logical components (typically after completion of the system analysis phase). During the latter process, new logical components may evolve, some may be combined, and others may disappear entirely.
3. OCORA aims to develop its CCS On-Board architecture in close collaboration with other programs and sector initiatives (e.g., EU-Rail, RCA, TOBA, EEIG ERTMS UG LWG, CONNECTA, LinX4Rail, X2Rail-4, UNISIG/UNIFE, etc.). Most of these programs have not yet performed and documented the operational- and systems-analysis but have developed a logical and/or physical architecture. To fit in the overall railway / CCS landscape and to facilitate understanding and communication between the different programs, OCORA adopts logical and physical components from other programs wherever reasonable. Adjustments will be performed iteratively at different points in time, concluding in a final logical architecture after completion of the functional allocation process.

The currently proposed OCORA logical architecture is a result of a close collaboration with RCA, EUG-LWG, X2Rail-4, and to some extend the Tauro project. Also, first results from discussions in the context of Europe's Rail Joint Undertaking (ERJU) System Pillar ramp-up are considered in this release. The OCORA logical architecture will continue to evolve alongside with the developments in the mentioned programs.

The currently proposed physical architecture was developed in collaboration with UIC TOBA regarding connectivity, S2R CONNECTA regarding on-board communication, and RCA regarding the safe computing platform. The OCORA physical architecture will continue to evolve alongside with the developments in those programs and incorporate changes due to the advancing logical architecture.

Revision history

Version	Change Description	Initial	Date of change
1.00	<ul style="list-style-type: none">▪ All CCS-OB specific content moved from OCORA-TWS01-030 – System Architecture into this document.	AL	10.06.2022
2.20	<ul style="list-style-type: none">▪ Architecture Aligned with RCA, X2Rail-4, EU-Rail, EUG-LWG▪ Building blocks defined and described▪ Document structure simplified (prepared for document generation through toolchain Capella -> Polarion -> PDF)▪ Text and graphics adjusted to be aligned with the updated logical and physical architecture diagrams	AL	24.06.2022

Table of contents

1	Introduction	11
1.1	Purpose of the document.....	11
1.2	Applicability of the document.....	11
1.3	Context of the document.....	11
2	Scope.....	12
3	Actors	14
3.1	Automatic Train Operation Monitoring (ATOM)	16
3.2	Augmentation (AUG).....	16
3.3	ATO Transactor (AT) / Operational Execution (OE)	17
3.4	Digital Map (DM)	17
3.5	Driver (DRV)	18
3.6	Driver Advisory System (DAS).....	18
3.7	ECN/ECN Security Gateway	18
3.8	Environment (ENV) incl. Physical Train Unit (PTU) and Light Signal (LSIG)	18
3.9	Eurobalise (EUB) & Euroloop (EUL).....	18
3.10	Evaluator (EVAL)	18
3.11	Functional Vehicle Adapter (FVA)	19
3.12	Identity & Access Management On-Board (IAM-OB)	19
3.13	Incident and Prevention Management – Incident Solving Manager (IPM-ISM).....	19
3.14	Juridical Recording Unit (JRU)	19
3.15	Key Management Centre (KMC)	20
3.16	Maintenance Terminal (MNT)	20
3.17	Mission Data (MD)	20
3.18	Mobile Object Transactor (MOT)	20
3.19	Monitoring, Diagnostic, Configuration, Maintenance (MDCM)	20
3.20	National Train Protection Systems (NTPs)	21
3.21	OCORA Gateway (OGW)	21
3.22	On-Board Staff (OBS)	21
3.23	Passenger Info System Adapter (PISA)	21
3.24	Radio Block Center (RBC) & Movement Authority Transactor (MT)	22
3.25	Remote Manual Train Operation (RMTO)	22
3.26	Route Control (RC)	22
3.27	Technician (TECH)	22
3.28	Time Service On-Board (TS-OB).....	23
3.29	Train Control & Management System (TCMS)	23
3.30	Train Data (TD)	23
3.31	Train Recording Unit (TRU)	23
3.32	Voice Communication System (VCS)	24
3.33	Wired I/O Control (WIOC)	24
3.34	Wired I/O Control SIL4 (WIOC-S4).....	24
3.35	Wired Sensors and Actors (WSA)	24

4	External interfaces	25
4.1	CI-DAS	26
4.2	CI-NTP	26
4.3	ERA_ERTMS_015560	26
4.4	HMI-CVR	27
4.5	HMI-MI	27
4.6	HMI-UID	27
4.7	PI-CMD	27
4.8	PI-PER	27
4.9	PI-VLS	27
4.10	SCI-AUG	27
4.11	SCI-CVR	27
4.12	SCI-DRU	28
4.13	SCI-IAM	28
4.14	SCI-MDCM	28
4.15	SCI-RMTO	28
4.16	SCI-TRI	28
4.17	SCI-TS	28
4.18	SCI-VL	28
4.19	SS-026	29
4.20	SS-027	29
4.21	SS-114 & 137	29
4.22	SS-119 (EB)	29
4.23	SS-119 (IS)	29
4.24	SS-119 (SCI-FVA)	30
4.25	SS-119 (TCO)	30
4.26	SS-119* (CS)	30
4.27	SS-119* (SCI-VL)	30
4.28	SS-126	30
4.29	SS-139 (SCI-FVA)	30
4.30	SS-139* (SCI-FVA)	31
4.31	SS-140	31
4.32	SS-149*	31
4.33	SVCI	31
4.34	X2R4-D3.2: C01	32
4.35	X2R4-D3.2: C19	32
4.36	X2R4-D3.2: C24	32
4.37	X2R4-D3.2: C34	32
4.38	X2R4-D3.2: C47	32
4.39	X2R4-D3.2: C55	32
4.40	X2R4-D3.2: C63	32
4.41	X2R4-D3.2: C65	32

5	Building blocks.....	33
5.1	Automatic Train Operation On-Board (ATO-OB).....	36
5.2	Cabin Voice Radio - Legacy (CVR-L)	36
5.3	Cabin Voice Radio - VoIP (CVR-V).....	36
5.4	CCS Communication Network (CCN).....	36
5.5	Digital Map Repository (On-Board).....	37
5.6	Driver Advisory System On-Board (DAS-OB).....	37
5.7	European Train Protection On-Board (ETP-OB)	39
5.7.1	Interfaces	39
5.7.2	Functional Components.....	40
5.8	Functional Vehicle Adapter (FVA)	44
5.9	Localisation On-Board (LOC-OB)	45
5.9.1	Interfaces	45
5.9.2	Functional Components.....	46
5.10	Monitoring, Diagnostics, Configuration, Maintenance (MDCM-OB)	47
5.11	National Train Protections (NTPs)	48
5.12	Perception On-Board	49
5.13	Remote Manual Train Operation On-Board (RMTO-OB)	49
5.14	Safe Computing Platform (SCP).....	50
5.15	Train Display System (TDS)	51
5.16	User Identification and Authentication (UIA)	51
5.17	Virtual Train Coupling System On-Board (VTCS-OB)	51
Appendix A	Train integration scenarios.....	52
A1	Scenario A: CCN as physically separated network	52
A2	Scenario B: CCN as logically separated network	53
A3	Scenario C: Common critical control network logically separated.....	54
A4	Scenario D: Common critical control network physically separated	55
A5	Scenario for retrofit vehicles with OCORA compliant CCS peripherals	56
Appendix B	Relating functions from SUBSET-026.....	57
Appendix C	Large scale graphics	60
C1	CCS-OB – Scope – logical architecture.....	61
C2	CCS-OB – Actors – logical architecture.....	62
C3	CCS-OB – External interfaces – logical architecture	63
C4	European Train Protection On-Board (ETP-OB) – logical architecture	64
C5	Localisation On-Board (LOC-OB) – logical architecture.....	65

Table of figures

Figure 1: Scope – logical architecture	12
Figure 2: Scope – physical architecture – legacy train example	12
Figure 3: Scope – physical architecture – new generation train example.....	13
Figure 4: Actors – logical architecture	14
Figure 5: Actors – physical architecture – legacy train example	15
Figure 6: Actors – physical architecture – new generation train example.....	15
Figure 7: Augmenting GNSS position data.....	16
Figure 8: External interfaces – logical architecture	25
Figure 9: External interfaces – physical architecture – example legacy train	25
Figure 10: External interfaces – physical architecture – example new generation train	26
Figure 11: Functional clustering	33
Figure 12: Scenario 1 – building blocks without SCP – legacy train example	34
Figure 13: Scenario 2 – building blocks with SCP for some applications – legacy train example	34
Figure 14: Scenario 3 – building blocks with SCP for all applications – legacy train example	35
Figure 15: Scenario 4 – building blocks with SCP for all applications – new generation train example	35
Figure 16: Train equipped with ATO-OB and DAS-OB operating in different networks.....	37
Figure 17: Train using DAS-OB functionality from ATO-OB operating in different networks	38
Figure 18: European Train Protection On-Board (ETP-OB).....	39
Figure 19: EuroRadio Safety allocation on the Safe Computing Platform	41
Figure 20: Localisation On-Board (LOC-OB)	45
Figure 21: NG-TCN train – separate networks	52
Figure 22: NG-TCN train – common network	53
Figure 23: NG-TCN train – Common critical control network logically separated	54
Figure 24: NG-TCN train – Common critical control network physically separated	55
Figure 25: Legacy train – OCORA compliant CCS-OB peripherals	56
Figure 26: Scope – logical architecture (large scale representation)	61
Figure 27: Actors – logical architecture (large scale representation)	62
Figure 28: External interfaces – logical architecture (large scale representation)	63
Figure 29: ETP-OB – logical architecture (large scale representation)	64
Figure 30: LOC-OB – logical architecture (large scale representation)	65

References

Reader's note: please be aware that the numbers in square brackets, e.g. [1], as per the list of referenced documents below, is used throughout this document to indicate the references to external documents. Wherever a reference to a TSI-CCS SUBSET is used, the SUBSET is referenced directly (e.g. SUBSET-026). OCORA always reference to the latest available official version of the SUBSET, unless indicated differently.

- [1] OCORA-BWS01-010 – Release Notes
- [2] OCORA-BWS01-020 – Glossary
- [3] OCORA-BWS01-030 – Question and Answers
- [4] OCORA-BWS01-040 – Feedback Form
- [5] OCORA-BWS03-010 – Introduction to OCORA
- [6] OCORA-BWS03-020 – Guiding Principles
- [7] OCORA-BWS04-010 – Problem Statements
- [8] OCORA-BWS05-010 – Road Map
- [9] OCORA-BWS06-010 – Economic Model – Guiding Principles - Assumptions - Assessment Criteria
- [10] OCORA-BWS06-020 – Economic Model
- [11] OCORA-BWS06-030 – Economic Model – Model Description
- [12] OCORA-BWS06-040 – Economic Model – User Manual
- [13] OCORA-BWS06-050 – Economic Model – CCS System Life Cycle Costing Scenario Studies
- [14] OCORA-BWS06-060 – Economic Model – CCS Impact on Vehicle System Life Cycle Costing
- [15] OCORA-BWS07-010 – Alliances
- [16] OCORA-BWS08-010 – Methodology
- [17] OCORA-BWS08-020 – Tooling
- [18] OCORA-BWS09-010 – Acceptance of Global Standards – Overview
- [19] OCORA-BWS09-020 – Acceptance of Global Standards – Focus on Safety in CCS
- [20] OCORA-BWS09-030 – Acceptance of Global Standards – Cartography of Standards
- [21] OCORA-BWS09-040 – Acceptance of Global Standards – Assessment of Railway Sectoral Needs
- [22] OCORA-TWS01-010 – Design Requirements
- [23] OCORA-TWS01-020 – Operational & System Analysis
- [24] OCORA-TWS01-030 – System Architecture
- [25] OCORA-TWS01-035 – CCS On-Board (CCS-OB) – Architecture
- [26] OCORA-TWS01-040 – Capella Modelling
- [27] OCORA-TWS01-041 – MBSE Modelling Guidelines
- [28] OCORA-TWS01-050 – Capella Model Export
- [29] OCORA-TWS01-100 – Localisation On-Board (LOC-OB) – Introduction
- [30] OCORA-TWS01-101 – Localisation On-Board (LOC-OB) – Requirements
- [31] OCORA-TWS01-102 – Localisation On-Board (LOC-OB) – Standard Communication Interface Spec.
- [32] OCORA-TWS01-112 – Automatic Train Protection On-Board (ATP-OB) – MLM Interface Analysis
- [33] OCORA-TWS02-010 – CCS Communication Network – Evaluation
- [34] OCORA-TWS02-020 – CCS Communication Network – Proof of Concept (PoC)

- [35] OCORA-TWS03-010 – SCP – Computing Platform for Railway Applications – Whitepaper
- [36] OCORA-TWS03-020 – SCP – High-Level Requirements
- [37] OCORA-TWS03-030 – SCP – Initial Specification of the PI API between Application and Platform
- [38] OCORA-TWS04-010 – Functional Vehicle Adapter – Introduction
- [39] OCORA-TWS04-011 – Functional Vehicle Adapter – Requirements
- [40] OCORA-TWS04-012 – Functional Vehicle Adapter – Standard Communication Interface Specification
- [41] OCORA-TWS04-013 – Functional Vehicle Adapter – Design Guideline
- [42] OCORA-TWS05-010 – Requirements – Management Guideline
- [43] OCORA-TWS05-020 – Stakeholder Requirements
- [44] OCORA-TWS05-021 – Program Requirements
- [45] OCORA-TWS06-010 – (Cyber-) Security – Project Security Management Plan
- [46] OCORA-TWS06-030 – (Cyber-) Security – Concept
- [47] OCORA-TWS07-010 – RAMS – Modular Safety Strategy
- [48] OCORA-TWS07-020 – RAMS – Evolution Management
- [49] OCORA-TWS07-030 – RAMS – SRAC/AC Management
- [50] OCORA-TWS07-050 – RAMS – RAM Strategy
- [51] OCORA-TWS07-100 – CENELEC Phase 1 – Concept
- [52] OCORA-TWS08-010 – MDCM-OB – Introduction
- [53] OCORA-TWS09-011 – Testing – Strategy
- [54] OCORA-TWS09-020 – Testing – Requirements
- [55] OCORA-TWS09-030 – Testing – Software Test and Integration Eng. acc. EN50657 or EN50128
- [56] OCORA-TWS09-031 – Assessment Strategy and Software Development
- [57] OCORA-TWS09-110 – Train Adapter Block Integration Plan
- [58] OCORA-TWS15-050 – PoC OMS SS-149 – Concept

- [59] EN 15380-4 – Railway applications - Classification system for railway vehicles - Function groups
- [60] EN 50126-1:2017-10 – Railway Applications – The Specification and Demonstration of Reliability, Availability, Maintainability and Safety (RAMS) - Part 1: Generic RAMS Process
- [61] EN 50126-2:2017-10 – Railway Applications – The Specification and Demonstration of Reliability, Availability, Maintainability and Safety (RAMS) - Part 2: Systems Approach to Safety
- [62] EN 50128:2011-06 – Railway Applications – Communication, signalling and processing systems - Software for railway control and protection systems
- [63] EN 50129:2018-11 – Railway applications - Communication, signalling and processing systems - Safety related electronic systems for signalling
- [64] EN 50155: 2017 – Railway applications – Rolling stock – Electronic equipment
- [65] EN 50159:2010-09 – Railway applications - Communication, signalling and processing systems - Safety-related communication in transmission systems

- [66] ERA_ERTMS_015560 – ETCS Driver Machine Interface

- [67] EUG 97E2675B – ERTMS User Group Document 97E2675B
- [68] EUG 21E109 – Vehicle Locator Concept Architecture, LWG, Version 1.0, 2021-07-15

- [69] EUG 22E126 – LOC-OB System Definition & Operational Concept, Version 1.0, 2022-05-30
- [70] EUG 22E135 – LOC-OB Risk Analysis

- [71] ISBN 978-1-78548-169-7 – Model-based System and Architecture Engineering with the Arcadia Method – Jean Luc Voirin – ISTE Press - 01/03/2018

- [72] ISO/IEC 7498-1:1994, Information technology – Open Systems Interconnection — Basic Reference Model: The Basic Model - Part 1.

- [73] RCA.Doc.35 –System Definition, Version 0.2 (0.A), 2020-09-11
- [74] RCA.Doc.35 –System Definition, Version 0.4, 2022-04-26
- [75] RCA.Doc.40 – RCA Architecture Poster, Version 0.4 (0.A), 2022-04-26
- [76] RCA.Doc.54 – Solution Concept: MAP, Version 0.3, 2022-04-22
- [77] RCA.Doc.58 – Digital Map – PHA Preliminary Hazard Analysis, Version 0.5, 2021-12-15
- [78] RCA.Doc.59 – Digital Map – System Definition, Version 0.5, 2022-04-22

- [79] TOBA, On-Board FRMCS Functional Requirements Specification, TOBA-7510
- [80] TOBA, On-Board FRMCS System Requirements Specification, TOBA-7530

- [81] TSI-CCS: 02016R0919 - EN - 16.06.2019 - 001.001 - 1: COMMISSION REGULATION (EU) 2016/919 of 27 May 2016 on the technical specification for interoperability relating to the ‘control-command and signalling’ subsystems of the rail system in the European Union, amended by Commission Implementing Regulation (EU) 2019/776 of 16 May 2019 L 139I

- [82] UIC, FRMCS User Requirements Specification, FU-7100
- [83] UIC, FRMCS Functional Requirements Specification, FU-7120

- [84] X2R3-D6.1: X2R3-WP06-D-ANS-001-03 – Deliverable 6.1 – Virtual Train Coupling System Concept and Application Conditions, Version 2.0, 2019-01-15
- [85] X2R4-D3.2: X2R4-WP03-D-ALS-009-012 – Deliverable D3.2 – GoA3/4 Specification, Version 0.1.4, 2022-04-04

1 Introduction

1.1 Purpose of the document

The purpose of this document is to document and communicate the current status of the OCORA CCS On-Board reference architecture.

This document is addressed to experts in the CCS domain and to any other person, interested in the OCORA concepts for on-board CCS. The reader is invited to provide feedback to the OCORA collaboration and can, therefore, engage in shaping OCORA. Feedback to this document and to any other OCORA documentation can be given by using the feedback form [4].

If you are a railway undertaking, you may find useful information to compile tenders for OCORA compliant CCS building blocks, for tendering complete on-board CCS system, or also for on-board CCS replacements for functional upgrades or for life-cycle reasons.

If you are an organization interested in developing on-board CCS building blocks according to the OCORA standard, information provided in this document can be used as input for your development.

1.2 Applicability of the document

The document is currently considered informative but may become a standard at a later stage for OCORA compliant on-board CCS solutions. Subsequent releases of this document will be developed based on a modular and iterative approach, evolving within the progress of the OCORA collaboration.

1.3 Context of the document

This document is published as part of an OCORA Release, together with the documents listed in the release notes [1]. Before reading this document, it is recommended to read the Release Notes [1]. If you are interested in the context and the motivation that drives OCORA we recommend to read the Introduction to OCORA [5], the Guiding Principles [6], the Problem Statements [7], and the Road Map [8]. The reader should also be aware of the Glossary [2] and the Question and Answers [3].

The wider context of the OCORA system architecture is provided in document [24]. Therefore, reading document [24] prior to reading this document will be helpful to better understand the context and the content of this document.

2 Scope

The scope of this document and the main scope for OCORA is the CCS On-Board (CCS-OB) system as depicted in the following logical and physical architecture diagrams (red boxes). Refer to document [24] for an overview of all systems of interest for OCORA.




Figure 1: Scope – logical architecture

Notes: refer to Appendix C1 for large scale representation
1) may be moved into the PTU-OS / LOC&PAS domain.




Figure 2: Scope – physical architecture – legacy train example

Notes: solid lines indicate wired connections, dashed lines "over the air" communication, dotted lines represent proprietary connections, and dashed-dotted lines represent user interactions. 1) may be moved into the PTU-OS / LOC&PAS domain. 2) lower ISO layers are standardized to ease the introduction of the safe computing platform. Alternatively, the interface with the backbone of the safe computing platform needs to be standardized.




Figure 3: Scope – physical architecture – new generation train example

Notes: solid lines indicate wired connections, dashed lines “over the air” communication, dotted lines represent proprietary connections, and dashed-dotted lines represent user interactions. 1) may be moved into the PTU-OS / LOC&PAS domain. 2) lower ISO layers are standardized to ease the introduction of the safe computing platform. Alternatively, the interface with the backbone of the safe computing platform needs to be standardized.

OCORA aims at providing the architecture for a CCS On-Board (CCS-OB) solution that is compliant with trains equipped with a New Generation – Train Control Network (NG-TCN) while also supporting legacy trains. It further aims at standardizing the CCS-OB in such a way that the same CCS-OB architecture can be used for legacy and NG-TCN based trains.

To develop this proposal for the logical and physical architecture, the OCORA Guiding Principles [6], the OCORA Design-Requirements [22], the OCORA Stakeholder-Requirements [43], and the OCORA Program-Requirements [44] were considered. The architecture was also developed in collaboration with RCA, Shift2Rail (CONNECTA, LINS4RAIL, X2RAIL-4, TAURO), TOBA, SFERA, and EEIG EUG.

While defining the logical and physical architecture, OCORA has identified components for the CCS-OB (blocks inside the red boxes) and their interaction with external systems (actors). All identified components, and actors depicted in Figure 1, Figure 2, and Figure 3 are described further in subsequent chapters of this document.

Components are defined as a piece of hardware and/or software, providing one or more functionalities. A component is used to structure functionality within building blocks. It implements and encapsulates one or more behaviour (business logic) and exposes services via defined interfaces to other components.

The components within the CCS-OB as identified in Figure 1, Figure 2, and Figure 3 support ETCS L0 – L3, level NTC, ATO GoA1 – GoA4 over ETCS (refer to requirement OCORA-58 in [43]), GSM-R and/or FRMCS connectivity, and the potential to implement NNTRs (Notified National Technical Rules). ETP-OB (ETCS) is the primary ATP, hence always present (refer to requirement OCORA-56 in [43]).

The configuration for a specific implementation may include only a subset of the components represented in Figure 1, Figure 2, and Figure 3. But not only the number of deployed components can differ between implementations. The functionality of some of the physical components (Figure 2, and Figure 3) may vary also. For example: on one vehicle the ETP-OB (ETCS) functionality and the ATO-OB functionality are deployed on separate hardware (refer to Figure 2), while another supplier may decide to use a safe computing platform for combined ETP-OB (ETCS) and ATO-OB functionality (refer to Figure 3). To achieve this, the independence of software from hardware is paramount and therefore an important topic to OCORA. Refer to documents [35], [36], and [37] for further details on the safe computing platform.

The components identified in Figure 1, Figure 2, and Figure 3 represent just a high-level view, abstracting many details. For example: The CCN, shown as a single block, is in fact a complex component with many sub-components and configuration options, depending on the needs of the RU/supplier (refer to documents [33], and [34]).

3 Actors

The actors for CCS-OB are identified on the logical and on the physical architecture. They are grouped as follows:

- Operation Control Systems – Infrastructure Manager (OCS-IM)
 - Operation Control Systems – Railway Undertaking (OCS-RU)
 - Physical Train Unit Operation Systems (PTU-OS)
 - Trackside Systems
 - Environment
 - Human Actors
 - Maintenance Equipment
 - Other Systems

All actor groups (blue boxes) and the individual actors are depicted in the following logical and physical architecture diagrams and are described in the following chapters (listed in alphabetical order).




Figure 4: Actors – logical architecture

Notes: refer to Appendix C2 for large scale representation
1) may be moved into the PTU-OS / LOC&PAS domain.




Figure 5: Actors – physical architecture – legacy train example

Notes: solid lines indicate wired connections, dashed lines “over the air” communication, dotted lines represent proprietary connections, and dashed-dotted lines represent user interactions. 1) may be moved into the PTU-OS / LOC&PAS domain. 2) lower ISO layers are standardized to ease the introduction of the safe computing platform. Alternatively, the interface with the backbone of the safe computing platform needs to be standardized.




Figure 6: Actors – physical architecture – new generation train example

Notes: solid lines indicate wired connections, dashed lines “over the air” communication, dotted lines represent proprietary connections, and dashed-dotted lines represent user interactions. 1) may be moved into the PTU-OS / LOC&PAS domain. 2) lower ISO layers are standardized to ease the introduction of the safe computing platform. Alternatively, the interface with the backbone of the safe computing platform needs to be standardized.

3.1 Automatic Train Operation Monitoring (ATOM)

The Automatic Train Operation Monitoring (ATOM) system allows to monitor the operations of all trains of a railway undertaking, independent from the suppliers of the trains. Real-time position and speed information are provided to the operator and compared to the schedule. Significant deviations are highlighted to the operator and possibly forwarded to the current infrastructure manager. In addition, any technical limitations (e.g. door issues, traction issues, brake issues, etc.) a train has, are notified to the operator, and possibly forwarded to the current infrastructure manager's system.

The ATOM system is considered to be mandatory for operators with trains running under ATO GoA 3/4 but may be useful also for ATO GoA 1/2 or for trains not equipped with ATO functionality. To what extend the ATOM should be combined with the MDCM needs to be evaluated.

3.2 Augmentation (AUG)

The Augmentation (AUG) is a means of improving – “augmenting” – the positioning system's performances, such as integrity, accuracy, or availability thanks to the use of external information. (source EUG-S2R JWG).

There is the possibility to acquire the augmentation data through the GNSS receiver (sensor). But this approach is expected to have availability limitations not acceptable in the rail environment. Therefore, discussions are currently ongoing to provide augmentation data through decentralised stations through the connectivity network (GSM-R, FRMCS).




Figure 7: Augmenting GNSS position data

3.3 ATO Transactor (AT) / Operational Execution (OE)

Information on the ATO Transactor (AT) is available in RCA document [73] and [75] while information on the Operational Execution (OE) is available in X2Rail-4 document [84].

Abstract from RCA document [73]: *the ATO Transactor (AT) distributes automatic train operation Journey Profiles, to the On-Board Unit of individual Railway Vehicles. It provides status information and execution progress in the form of Status Report Packet (STR) received from the On-Board Unit. It handles Journey Profile Request Packet (JPReq) and Segment Profile Request Packet (SPReq). It translates Operational Plans into Journey Profile Packet (JP) and Segment Profile Packet (SP) as specified in CCS TSI ATO over ETCS SUBSET-126.*

Abstract from RCA document [75]: *the ATO Transactor (AT) distributes automatic train operation journey profiles, to the CCS on-board of Physical Train Units.*

Abstract from X2Rail-4 document [84]: *The Operational Execution (OE) component supervises all GoA3/4 trains. SIL: not safety related. Note: this component is called ATO-TS in GoA2 specifications.*

3.4 Digital Map (DM)

Information on the Digital Map (DM) is available in X2Rail-4 document [84] and in RCA documents [76], [77], and [78].

Abstract from X2Rail-4 document [84]: *The Digital Map (DM) component shares infrastructure data with relevant applications like:*

- ATO-AV: Segment Profiles
- APM: track zones and associated infrastructure elements
- LZ (outside the scope of GoA3/4): landmarks
- SCV (outside the scope of GoA3/4): lineside signal information

Assumptions:

- DM is structured in different layers for providing services to relevant applications (application engineering is required for each layer).
- DM manages static data but also dynamic data like TSR.

SIL: to be defined.

3.5 Driver (DRV)

The Driver (DRV) is a person capable and authorised to drive trains, including locomotives, shunting locomotives, work trains, maintenance railway vehicles or trains for the carriage of passengers or goods by rail in an autonomous, responsible, and safe manner. Source: Directive 2007/59/EC of the European Parliament and of the Council.

3.6 Driver Advisory System (DAS)

The Driver Advisory System (DAS) of the infrastructure manager application is a non-safe application. It generates, together with the Driver Advisory On-Board (DAS-OB) application, detailed driver advice for adhering to the planned timings while driving energy efficient. The DAS is responsible for conflict detection and calculation of new target train timings, that are forwarded to the DAS-OB application. The DAS is responsible for calculating an energy efficient speed profile to achieve the pre-planned and dynamically updated train timings. The DAS communicates with the DAS-OB, using the SFERA specification or any proprietary (vendor specific) specification.

The DAS is not needed for lines that provide ATO functionality and for vehicles that have ATO-OB functionality deployed, since the ATO Transactor (AT) / Operational Execution (OE), and ATO On-Board (ATO-OB) already include DAS functionality.

3.7 ECN/ECN Security Gateway

The ECN/ECN Security Gateway is a network component providing cyber secure interconnection between the different On-Board network zones (e.g., CCS/TCMS, Operator, Connectivity).

The ECN/ECN Security Gateway is installed on every OCORA based CCS On-Board system, monitors, and filters all traffic between the connected networks based on the configured security policies (e.g., IP source address, IP destination address, Source port, etc.).

3.8 Environment (ENV) incl. Physical Train Unit (PTU) and Light Signal (LSIG)

Environment provides information about conditions, influencing the railway operation. It can be trackside or vehicle based.

3.9 Eurobalise (EUB) & Euroloop (EUL)

The Eurobalise (EUB) is a transponder, mounted on the track, which can communicate with a train passing over it, compliant to the ERTMS/ETCS specifications.

Detailed information on the Eurobalise is available in SUBSET-036

The Euroloop (EUL) is a transponder loop mounted along the track, which can communicate with a train passing along, compliant to the ERTMS/ETCS specifications.

Detailed information on the Euroloop is available in SUBSET-044.

3.10 Evaluator (EVAL)

The Evaluator (EVAL) is a person evaluating data stored in the TRU.

3.11 Functional Vehicle Adapter (FVA)

The Functional Vehicle Adapter (FVA) is a piece of software deployed either on the Safe Computing Platform (SCP), on a separate CCS Computing Unit (CCU), or on the OCORA Gateway (OGW). Its job is to provide OCORA unified and standardised interfaces (SCI-FVA and SCI-MDCM) for the CCS-OB Software to access vehicle functions and vehicle information. Furthermore, it uses a specific interface (SCI-VL) to provide localisation information to the TCMS. Although the TSI-CCS SUBSET-034, SUBSET-119, and SUBSET-139 are defining the interfaces to the TCMS system, vehicles from different suppliers and especially from different generations have still different interfaces implemented. This adapter allows to map, on a functional level, the commands sent, and the information received from a specific TCMS into the (OCORA) CCS-OB standard. This includes that the FVA can likewise be used to integrate vehicles through wired connections.

Remark: Sometimes the FVA is also called Train Interface Unit (TIU). However, the TIU is not clearly defined. Sometimes it refers to the functional level of the interface with the vehicle, while in another context a piece of hardware is meant. To avoid confusion, OCORA does not use the term TIU.

Detailed information on the Functional Vehicle Adapter (FVA) is available in document [\[38\]](#).

3.12 Identity & Access Management On-Board (IAM-OB)

The Identity & Access Management On-Board (IAM-OB) is part of the On-Board Security Service (OSS) and integrates with the trackside Identity & Access Management providing the central management for the identification, authentication and authorisation of devices and applications to resources and functions of the CCS On-Board and trackside systems.

For the identification, the IAM System manages a unique ID for each entity (e.g., device, application). The granularity, on what level the system will identify entities is not yet defined. It can reach from one single ID for the overall CCS On-Board system to IDs for any single device connected to the CCN and to any application, running on the OCORA Platform.

For the authentication of a device or an application, the solution could be based on the Public Key Infrastructure (PKI) or Message Authentication Codes (MAC) using symmetrical encryption mechanisms like 3DES or AES.

The access to resources and functions is centrally managed by roles and granted on a Need-to-Know principle to limit unauthorised access to resources and functions within the CCS On-Board system.

3.13 Incident and Prevention Management – Incident Solving Manager (IPM-ISM)

Information on the Incident and Prevention Management – Incident Solving Manager (IPM-ISM) is available in X2Rail-4 document [\[84\]](#).

Abstract from X2Rail-4 document [\[84\]](#): *The Incident and Prevention Management – Incident Solving Manager (IPM-ISM) component predicts the geographical, temporal and resource-related impact of events on scheduled railway operation. Solving processes are aligned and prioritised. Specified routines are created to resolve Non-Regular Situations with a minimal impact on railway operation. Planned routines are executed and assisting entities coordinated. An Incident is monitored and managed during his whole lifecycle from the first recognition to the dissolution. SIL: to be defined.*

3.14 Juridical Recording Unit (JRU)

The Juridical Recording Unit (JRU) is recording data from the European Train Protection On-Board (ETP-OB) and the Automatic Train Operation On-Board (ATO-OB) systems. Depending on the products available in the market it can be a sub-component of the Train Recording Unit (TRU).

3.15 Key Management Centre (KMC)

The Key Management Centre (KMC) is a system managed by the infrastructure manager and is responsible for the generation, installation, update, and deletion of the authentication keys needed to establish a safe connection between a trackside entity belonging to its domain and any on-board entity operating in its domain.

Further information on the KMC is available in SUBSET-114 and SUBSET-137.

3.16 Maintenance Terminal (MNT)

The Maintenance Terminal (MNT) is a laptop that can indirectly be connected to the CCN (through the ECN/ECN Security Gateway) to perform maintenance tasks on all CCS On-Board components. Maintenance tasks should include the monitoring and downloading of diagnostic data, executing service commands (e.g., reboot of a specific component) and installing updates (new software, configuration, etc).

Multiple MTs can be connected to every OCORA based CCS On-Board system.

Further details will be provided in subsequent versions of the OCORA architecture documentation.

3.17 Mission Data (MD)

Information on the Mission Data (MD) is available in X2Rail-4 document [84].

Abstract from X2Rail-4 document [84]: *the Mission Data (MD) component interfaces with RU to manage the Mission Profile. SIL: not safety related.*

3.18 Mobile Object Transactor (MOT)

Information on the Mobile Object Transactor (MOT) is available in RCA document [73] and [75].

Abstract from RCA document [73]: *the Mobile Object Transactor (MOT) translates between the abstract objects used by the Object Abstraction Layer and the device-specific commands from subsystems on the Device Control Layer and vice versa. It supports location devices with calibration data and provides LocalisationReportEvents. It transfers warnings about planned movements to affected warning devices.*

Abstract from RCA document [75]: *the Mobile Object Transactor (MOT) translates between the abstract objects used by the Object Abstraction Layer and the device-specific commands and vice versa.*

OCORA assumes that the Localisation On-Board (LOC-OB) system is providing kinematic data to the MOT. The MOT may also support train-to-train communication for the Virtual Train Coupling System On-Board (VTCS-OB).

3.19 Monitoring, Diagnostic, Configuration, Maintenance (MDCM)

The Monitoring, Diagnostic, Configuration, Maintenance (MDCM) is part of the CCS Off-Board Support (COBS) system. It includes the following basic functionality:

- Asset management for CCS-OB
- Diagnostic and monitoring of CCS-OB
- Configuration management for CCS-OB
- Software Management for CCS-OB software

OCORA has not published any documents on the MDCM yet. Information will be provided in subsequent releases of the OCORA documentation. To what extend the MDCM should be combined with the ATOM needs to be evaluated.

3.20 National Train Protection Systems (NTPs)

Any kind of national Automatic Train Protection (ATP) system installed at trackside.

3.21 OCORA Gateway (OGW)

The OCORA Gateway (OCORA-GW) is a piece of hardware providing communication capabilities between the CCN and the legacy Train Control Network (if it exists) or the TCMS (if it exists) or the legacy actuators and sensors residing outside the CCS-OB domain but relevant for CCS-OB. Depending on the vehicle, the OCORA Gateway covers multiple OSI layers (refer to OCORA OSI definitions in document [16]). This can include even layer 7 in some cases. The OCORA-GW provides a means of integrating the CCS-OB System with various vehicle technologies, especially when deploying an OCORA based CCS-OB system on existing fleets. For situations, where the CCS-OB and the TCN & Op Networks are using the same technology and the TCMS implements the standard vehicle adapter interface (SCI-FVA), the OCORA-GW is not needed, and an ECN/ECN Security Gateway provides connectivity and ensures security.

The OCORA-GW is installed on every OCORA based CCS On-Board System whilst and where no standardised and common TCMS-CCS network is available. In case there is no TCMS, the CCS-OB can integrate directly with vehicle I/O Ports via the FVA located on the OCORA-GW or on a CCU.

Furthermore, the Operator Network (Op Network), depending on security requirements, may also be connected to the Gateway, ensuring communication between the CCS-OB System and the Passenger Information System (PIS).

OCORA aims at defining a standardised CCS On-Board System with standardized interfaces. To integrate with the different current and future Train Control and Passenger Information Systems without modifying the standardized CCS On-Board System, corresponding adapters might be needed to convert standardised OCORA communication protocols and messages to the specific protocols and messages of the respective Train Control and Passenger Information Systems. The Gateway may provide the environment to run the necessary adapters. Once there is a standardized CCS-OB to TCMS interface defined, the need for adapters vanishes and the Gateway may not be required anymore. For the interface between the CCS On-Board and the vehicle TCMS, this is specified in documents [38], [39] and [40].

While OCORA foresees in its architecture the Gateway for integrating with the specific Train Control and Passenger Information Systems, the implementation of the Gateway remains a vehicle specific integration task. Depending on the specific situation, the OCORA Gateway may be simple or quite complex. In any case, the OCORA Gateway, drawn as a single box, is composed of multiple subcomponents. Some of these sub-components will be part of most OCORA Gateway deployments while others are only needed for some integrations.

3.22 On-Board Staff (OBS)

The On-Board Staff (OBS) is the personnel of the Railway Undertaking (RU), escorting the Passenger Train. The Train Attendant is responsible for Passenger and Train service.

3.23 Passenger Info System Adapter (PISA)

The Passenger Information System Adapter (PISA) is a non-safe piece of software deployed either on the Safe Computing Platform (SCP), or on a separate CCS Computing Unit (CCU), or on the OCORA Gateway. Its job is to allow communication between the standardise CCS-OB and the proprietary Passenger Information System (PIS).

Furthermore, the Passenger Information System Adapter (PISA) might have an interface (X2R4-D3.2: C47) to the Automatic Processing Module (APM). However, the functions and details allocated to this interface are still being worked out within the X2Rail-4 organisation. Only then the interface can be properly standardised.

3.24 Radio Block Center (RBC) & Movement Authority Transactor (MT)

The Radio Block Centre (RBC) is a specialised computing device with Safety Integrity Level 4 (SIL 4) for generating Movement Authorities (MA) and transmitting it to trains. It gets information from Signalling control and from the trains in its section. It hosts the specific geographic data of the railway section and receives cryptographic keys from trains passing in. The RBC provides the trains with MAs until leaving the section. RBC have a standardised interface (SUBSET-026) to trains but have no standardised interface to the signalling control systems.

Movement Authority Transactor (MT) is replacing the Radio Block Center (RBC) in an RCA system. The interface between the train and the MT is the same as the interface between the train and the RBC. During the transition phase from RBCs to the MTs the train may communicate with RBCs and MTs, depending on its location and the infrastructure provided for that location.

The Movement Authority Transactor (MT) communicates with the registered ETCS capable vehicles. Among others, it translates the movement permissions to ETCS Movement Authorities and sends them to the vehicle. Only radio based ETCS is supported by the MT. In the other direction, it receives the train position reports from the vehicle and forwards them to the Object Aggregation (OA).

Detailed information on the Movement Authority Transactor (MT) is available in document [\[73\]](#).

3.25 Remote Manual Train Operation (RMTO)

The Remote Manual Train Operation (RMTO) allows for remote driving of trains. The system receives real-time position and speed information, combined with video streams, allowing to control a train from a central site.

The RMTO system is considered to be mandatory for operators with trains running under ATO GoA 3/4 but may be useful also for ATO GoA 1/2 or for trains not equipped with ATO functionality.

3.26 Route Control (RC)

The Route Control (RC) provides to the CCS-OB an interlocked (safe) train path uniquely assigned to a train/vehicle. This information is seen useful to fetch the required map data for the train path ahead and to validate the determined position by the LOC-OB against track selectivity, e.g., at start-up after vehicle has moved during power-off mode (degraded mode). It might also be used to determine track selectivity, e.g., if the vehicle position is known prior to passing a switch point and to decide whether it turned left or right. Furthermore, RC data may be needed for the Incident and Prevention Management (IPM-OB) to make the proper decision in case an obstacle is detected.

In RCA terminology, a route is defined as a Movement Permission (MP) that is an authorisation for a particular track bound movable object to move in a defined direction, with a defined speed, along a defined path (a contiguous stretch of TrackEdgeSections) on the track network.

The RC data is needed for every OCORA based CCS On-Board system in need to determine track selectivity.

Information on the Route Control (RC) is available in document [\[84\]](#).

3.27 Technician (TECH)

The Technician (TECH) is a person performing preventive and corrective maintenance tasks.

3.28 Time Service On-Board (TS-OB)

The Time Service On-Board (TS-OB) provides a service that allows all On-Board components to have their time in synch with a master clock and therefore in synch with each other and the trackside systems (e.g., safe data centres). The time base is assumed to be UTC and components in need to display the time can convert it to local time based on the systems time zone settings. The TS-OB functionality is significant to simplify diagnostic and analysis tasks and is important for ATO operations, and other aspects (e.g., used to timestamp the output of the localisation system with the validity time of the information provided).

3.29 Train Control & Management System (TCMS)

The Train Control & Management System (TCMS) typically includes the following functionalities, relevant for CCS-OB:

- Traction Control
- Brake Control
- Door Control
- Energy Control
- Air Tightness Control
- Status Synchronisation
- Train Integrity Monitoring
- Digital Automatic Coupling

The TCMS connects to the CCS On-Board (CCS-OB) through the Functional Vehicle Adapter (FVA), using the PTU-OS internal CI-TCMS interface. However, in the long term the TCMS might connect directly to the CCS On-Board (CCS-OB) without having a Functional Vehicle Adapter (FVA) in between. In the latter case it will implement the standardised interfaces SCI-FVA and SCI-VL.

In addition, there is a direct interface (SCI-IS) between the TCMS and the Isolation Management component (ISM) of the European Train Protection On-Board (ETP-OC).

3.30 Train Data (TD)

Information on the Train Data (TD) is available in X2Rail-4 document [84].

Abstract from X2Rail-4 document [84]: *The Train Data (TD) component interfaces with RU to manage the train information required for the mission. Assumption: the train data must be reliable. Provide Train Protection parameters (REP) will use this data and TCMS/DAC information to build safety related data. SIL: to be defined.*

3.31 Train Recording Unit (TRU)

The Train Recording Unit (TRU) includes the Juridical Recording Unit (JRU) and the Diagnostic Recording Unit (DRU). The TRU is located in the train control (vehicle) domain. The JRU records data from the European ETP-OB (ETCS On-Board) system while the DRU is recording data from other vehicle on-board systems, for instance the TCMS. In the future, other functions than ETP on-board residing in the CCS domain (e.g., ATO-OB) also have a need to record juridical data. Hence, further data is proposed to be recorded in the JRU memory. Whether this memory is a specific hardware, separated from the hardware available to record DRU data, or the JRU and DRU hardware are combined into one common unit, or even in the same physical memory, depends on the products available in the market. At least, the two JRU and DRU need to be handled separately at logical level.

For every OCORA based CCS On-Board system a TRU is installed to record data.

3.32 Voice Communication System (VCS)

The Voice Communication System (VCS) is the trackside counterpart to the Cabin Voice Radio (CVR) and provides all required functionalities on trackside to establish and answer voice calls between On-Board staff (e.g., train driver, train attendant) and trackside staff (e.g., operation control centre staff).

3.33 Wired I/O Control (WIOC)

The Wired I/O Control (WIOC) provides connectivity between Wired Sensors and Actors and the CCS-OB through the FVA, where functions are executed with SIL<4. The mapping logic between Wired Sensors and Actors and the CCS-OB is executed within the FVA.

3.34 Wired I/O Control SIL4 (WIOC-S4)

The Wired I/O Control SIL4 (WIOC-S4) provides mandatory wired connectivity between Wired Sensors and Actors and the CCS-OB, where typically functions are executed with SIL4.

Triggering the emergency brake, cutting the traction, or reporting the coupler status of the train are typical functions integrated through the WIOC-S4, as long as no 'SIL4 TCMS' is available.

The isolation signal (SCI-IS) is used to bypass the failsafe states of the Wired I/O in case the ETCS On-Board is isolated.

3.35 Wired Sensors and Actors (WSA)

The Wired Sensors and Actors (WSA) include all Sensors and Actors that are directly wired to the CCS-OB

4 External interfaces

The external interfaces for CCS-OB are identified on the logical and on the physical architecture as depicted in the following diagrams (red labels).




Figure 8: External interfaces – logical architecture

Notes: refer to Appendix C3 for large scale representation
1) may be moved into the PTU-OS / LOC&PAS domain.

SS-nnn: respective subset contains information for the interface.
SS-nnn*: respective subset does not address the interface but should contain the information in the future.




Figure 9: External interfaces – physical architecture – example legacy train




Figure 10: External interfaces – physical architecture – example new generation train

All interfaces are described in the following chapters. They are sorted alphabetically.

4.1 CI-DAS

This is the interface between Driver Advisory System On-Board (DAS-OB) and the Driver Advisory System (DAS). It is either following the SFERA standard or any non-standardised vendor or IM specific specification.

4.2 CI-NTP

This is the interface between the trackside National Train Protection systems (NTPs) and the On-Board National Train Control system (NTC).

This is a specific interface of the existing National ATP systems and is therefore not relevant for OCORA.

4.3 ERA_ERTMS_015560

This is the interface between the Driver Machine Interface (refer to chapter 5.15) and the train driver (DRV) or the technician (TECH).

Standardization efforts for ETCS functionality are ongoing by the ERA. The specification must be extended to include ATO requirements (not in scope of OCORA).

Standardization of the user interfaces for Voice Radio, Diagnostics, Monitoring, Configuration, NTCs, and Driver Advisory Vehicle are not existing and OCORA does not plan, at this point in time, to work on those standards.

Detailed information on the ERA_ERTMS_015560 is available in document [66].

4.4 HMI-CVR

The HMI-CVR specifies the user interface between the On-Board Cabin Voice Radio (CVR) and its actors, the train driver (DRV) and the On-Board staff (OBS).

OCORA does not aim to standardize this interface.

4.5 HMI-MI

The HMI-MI specifies the user interface between the Maintenance HMI (MI-HMI) and the Technician (TECH) or the Evaluator (EVAL).

OCORA does not aim to standardize this interface.

4.6 HMI-UID

This is the interface between the User Identification Reader and the Train Driver (TRDR) or the Driver's UID card.

OCORA does not aim to standardize this interface.

4.7 PI-CMD

This is the perception interface between the Cold Movement Detection (CMD) and the environment (ENV). The sensors of the CMD are sensing the environment using different type of technologies.

4.8 PI-PER

This is the perception interface between the Perception On-Board (PER-OB) and the environment (ENV). The sensors of the PER-OB are sensing the environment using different type of technologies (e.g. LIDAR, camera, etc.).

4.9 PI-VLS

This is the perception interface between the Vehicle Locator Sensors (VLSs) and their environment (ENV). The VLSs are sensing the environment using different type of technologies (e.g. radar, camera, etc.)

4.10 SCI-AUG

This is the standard communication interface for Augmentation (AUG) data used to improve localisation quality.

4.11 SCI-CVR

This is the standard communication interface of the Cabin Voice Radio component (refer to 5.3) that can be used for the integration with other systems or components (e.g., Passenger Information System).

OCORA aims at standardizing this interface. Details will be provided in subsequent versions of the OCORA Architecture.

4.12 SCI-DRU

This is the standard communication interface of the Diagnostic Recording Unit (DRU) component that allows recording the data from the Diagnostic Data Writing (DDW) component for the National Train Protection (NTP) sub-system integrated through the Specific Transmission Module (STM) with the European train Protection On-Board (ETP-OB). However, the detailed DRU data is not defined and standardized. The to be recorded data is embedded in SUBSET-027 and allows a project or sub-system specific implementation.

4.13 SCI-IAM

The SCI-IAM is the standard communication interface to use the services provided by the Identity & Access Management On-Board (IAM-OB).

Refer to Section [3.12](#) for details on the IAM-OB.

4.14 SCI-MDCM

The SCI-MDCM is the standard communication interface of the Monitoring, Diagnostic, Configuration & Maintenance On-Board component (refer to chapter 5.10) that exchanges data with the Physical Train Unit Operation Systems (PTU-OS). Regarding the SCI-MDCM the MDCM-OB on the one hand collects relevant information from the CCS On-Board (CCS-OB) and provides it to the Physical Train Unit Operation Systems (PTU-OS), on the other hand it receives relevant information from the Physical Train Unit Operation Systems (PTU-OS) and provides it to the different components of the CCS On-Board (CCS-OB).

Detailed information on the Monitoring, Diagnostic, Configuration & Maintenance On-Board (MDCM) component is available in document [\[52\]](#).

4.15 SCI-RMTO

The SCI-RMTO provides localisation, speed, and video data needed for remote train driving. The interface also transmits commands (acceleration, braking, etc.) from the remote train driver to the train.

4.16 SCI-TRI

The SCI-TRI provides Train Routing Information (TRI) from the Route Control (RC) to the CCS On-Board (CCS-OB).

4.17 SCI-TS

The SCI-TS is the standard communication interface of the On-Board time service (TS-OB) allowing all On-Board components to use a synchronized time.

Refer to Section [3.28](#) for details on the TS-OB

4.18 SCI-VL

The SCI-VL provides standardised kinematic data to the various consumers.

4.19 SS-026

This is the interface between the European Train Protection On-Board (ETP-OB, refer to chapter 5.7) or more specifically its Vehicle Supervisor (VS) component and the Radio Block Center (RBC) & Movement Authority Transactor (MT) or the Eurobalise (EUB) & Euroloop (EUL), depending on the operative ETCS level.

SUBSET-026 chapters 7 & 8 define this interface.

4.20 SS-027

This is the standard communication interface of the Juridical Recording Unit (JRU) component that allows recording the data from the Juridical Data Writing (JDW) component for the European Train Protection On-Board (ETP-OB).

SUBSET-027 defines the data to be stored in the JRU. However, the access to the JRU is not standardized yet.

Furthermore, OCORA may consider standardizing the JRU read out format to facilitate data evaluation with a vendor independent evaluation software and integration into standardised remote monitoring.

4.21 SS-114 & 137

SUBSET-114 and SUBSET-137 define the interface between the Key Management Centre (KMC) and the KMAC Services On-Board (KMPC-OB) whereas SS-114 specifies the offline interface and SS-137 the interface for the online key management.

Further information is available in SUBSET-114 and SUBSET-137.

4.22 SS-119 (EB)

This is the standard communication interface between the European Train Protection On-Board (ETP-OB, refer to chapter 5.7) or more specifically its Vehicle Supervisor (VS) component and the Wired I/O Control SIL4 actor (WIOC-S4) to control the Emergency Brake (EB) device of the Physical Train Unit Operation Systems (PTU-OS).

4.23 SS-119 (IS)

This is the standard communication interface between the European Train Protection On-Board (ETP-OB, refer to chapter 5.7) or more specifically its Isolation Management (ISM) component and the Physical Train Unit Operations System (PTU-OS) or more specifically its actors Wired I/O Control SIL4 (WIOC-S4), Wired I/O Control (WIOC) and/or Train Control & Management System (TCMS). The interface is used to inform the Physical Train Unit Operations System (PTU-OS) that the European Train Protection On-Board (ETP-OB) has been isolated, and to ensure that brakes activated by the European Train Protection On-Board (ETP-OB) are released.

4.24 SS-119 (SCI-FVA)

This is the standard communication interface between the Physical Train Unit Operation Systems (PTU-OS) and sub-systems in the CCS On-Board (CCS-OB). Typically these latter are the European Train Protection On-Board (ETP-OB, refer to chapter 5.7) or more specifically its Vehicle Supervisor (VS) and its Trackside Condition Services (TCS) components, and the Localisation On-Board (LOC-OB, refer to chapter 5.9) or more specifically its Vehicle Locator (VL) component. Through this interface data is exchanged that is relevant for the ETCS on-board.

Detailed information on the Functional Vehicle Adapter (FVA) is available in document [\[38\]](#).

4.25 SS-119 (TCO)

This is the standard communication interface between the European Train Protection On-Board (ETP-OB, refer to chapter 5.7) or more specifically its Vehicle Supervisor (VS) component and the Wired I/O Control SIL4 actor (WIOC-S4) to control the Traction Cut-Off (TCO) device of the Physical Train Unit Operation Systems (PTU-OS).

4.26 SS-119* (CS)

This is the standard communication interface between the European Train Protection On-Board (ETP-OB, refer to chapter 5.7) or more specifically its Vehicle Supervisor (VS) component and the Wired I/O Control SIL4 actor (WIOC-S4) to get specific information about the Coupler Status (CS) condition of the Physical Train Unit Operation Systems (PTU-OS).

Details and functions of the Coupler Status (CS) have not been elaborated yet. Further details will be provided in subsequent versions of the OCORA architecture documentation.

4.27 SS-119* (SCI-VL)

This is the standard communication interface provided by the Localisation On-Board (LOC-OB, refer to chapter 5.9) or more specifically its Vehicle Locator (VL) component. Through this interface the Vehicle Locator (VL) makes location information available to other components or sub-systems outside of the CCS On-Board (CCS-OB), typically these components are the Physical Train Unit Operation Systems (PTU-OS), the Automatic Train Automation Monitoring (ATOM) and the Mobile Object Transactor (MOT). Which components are involved in this data exchange depends on the system capabilities required from the vehicle in the specific project.

OCORA aims at providing a standard for this interface.

4.28 SS-126

This is the standard communication interface between the ATO Transactor (AT) / Operational Execution (OE) and the ATO On-Board (ATO-OB). The interface is described in SUBSET-126.

4.29 SS-139 (SCI-FVA)

This is the standard communication interface between the Physical Train Unit Operation Systems (PTU-OS) and the Automatic Train Operation On-Board (ATO-OB, refer to chapter 5.1) or more specifically its Automatic Train Operation Vehicle (AV) component. Through this interface data is exchanged that is relevant for the Automatic Train Operation On-Board (ATO-OB).

Detailed information on the Functional Vehicle Adapter (FVA) is available in document [\[38\]](#).

4.30 SS-139* (SCI-FVA)

This is the standard communication interface between the Physical Train Unit Operation Systems (PTU-OS) and the Remote Manual Train Operation On-Board (RMTO-OB, refer to chapter 5.135.1). Through this interface data is exchanged that is relevant in the context of Automatic Train Operation On-Board (ATO-OB) with GoA 3 & 4.

Details and functions of the Remote Manual Train Operation On-Board (RMTO-OB) have not been elaborated yet. Further details will be provided in subsequent versions of the OCORA architecture documentation.

Detailed information on the Functional Vehicle Adapter (FVA) is available in document [\[38\]](#).

4.31 SS-140

This is the standard communication interface of the Train Recording Unit (TRU) that allows recording the data from the Automatic Train Operation Vehicle (AV) component integrated in the Automatic Train Operation On-Board (ATO-OB).

SUBSET-140 defines the data to be stored in the Train Recording Unit (TRU). However, the access to the Train Recording Unit (TRU) is not standardized yet.

Furthermore, OCORA may consider standardizing the Train Recording Unit (TRU) read out format to facilitate data evaluation with a vendor independent evaluation software and integration into standardised remote monitoring.

4.32 SS-149*

The SS-149 is the interface to the OMS Wayside Server as specified in SS-149. It is assumed that the Monitoring, Diagnostic, Configuration, Maintenance System (MDCM) of the railway undertaking comprises the OMS Wayside Server.

The detection of wayside and on-board CCS system failures, whether imminent or already reality, supports reliable train operations. Issues might arise when failure reporting is delayed, or necessary repair work is postponed, let alone if failures remain undetected. Regular infrastructure and rolling stock maintenance activities often have of a cyclical character, implying that potential failures can remain hidden for quite some time, e.g., until the next inspection.

The SS-149 interface aims at providing a harmonized European mechanism for sharing monitoring and diagnostic data generated by rolling stock, throughout the European rail network.

Detailed information about this interface is available in document SUBSET-149.

Furthermore, this is the Standard Maintenance Interface to the Automatic Train Operation Monitoring (ATOM) of the railway undertaking the vehicle belongs to. Information exchanged via this interface allows operators to remotely monitor the automatic train operation and to intervene and switch to manual remote driving (see 3.25 Remote Manual Train Operation) as a last resort.

Further details will be provided in subsequent versions of the OCORA architecture documentation.

4.33 SVCI

The Standard Voice Communication Interface (SVCI) is the interface between On-Board Cabin Voice Radio and the trackside Voice Communication System.

This is either the specific interface between the voice communication systems over the existing GSM-R, or the future FRMCS standard and is not further elaborated in this document.

4.34 X2R4-D3.2: C01

Refer to document [\[84\]](#) for further information.

4.35 X2R4-D3.2: C19

Refer to document [\[84\]](#) for further information.

4.36 X2R4-D3.2: C24

Refer to document [\[84\]](#) for further information.

4.37 X2R4-D3.2: C34

Refer to document [\[84\]](#) for further information.

4.38 X2R4-D3.2: C47

Refer to document [\[84\]](#) for further information.

4.39 X2R4-D3.2: C55

Refer to document [\[84\]](#) for further information.

4.40 X2R4-D3.2: C63

Refer to document [\[84\]](#) for further information.

4.41 X2R4-D3.2: C65

Refer to document [\[84\]](#) for further information.

5 Building blocks

OCORA aims to introduce “plug & play”-like exchangeability for the CCS On-Board building blocks.

A building block is a sourceable unit of the CCS on-board system (hardware and/or software), having standardised functionality, standardised performance (RAM), standardised safety (including Tolerable Functional Failure Rate [TFFR], Safety Integrity Level [SIL] and Safety Related Application Conditions [SRAC]), standardised security and standardised interfaces towards other building blocks and/or external systems.

Combined HW/SW Building blocks exclusively communicating with each other through the CCS Communication Network (CCN) through standardise interfaces.

SW Building blocks, deployed on an instance of the generic (safe) computing platform, shall communicate with each other through the standardised Platform Independent API. Communication with computing platform external systems will be realised by the computing platform (integrating with the CCN).

Building blocks are modifiable / adaptable and therefore portable / replaceable, without impacting other building blocks.

OCORA clusters the functional components for assigning functionality to building blocks as depicted in [Figure 11](#).




Figure 11: Functional clustering

The functional clusters are now mapped to the physical hardware, using different scenarios:

- **Scenario 1:** dedicated hardware (no safe computing platform) for each functional cluster, combined with the legacy train physical architecture example.
- **Scenario 2:** dedicated hardware for some functional clusters and a safe computing platform (SCP) for the remaining functional clusters, combined with the legacy train physical architecture example.
- **Scenario 3:** a safe computing platform (SPC) for all functional clusters, combined with the legacy train physical architecture example.
- **Scenario 4:** a safe computing platform (SPC) for all functional clusters, combined with the new generation train physical architecture example.

Other combinations are possible (e.g. new generation train with only some functional clusters deployed on a safe computing platform) but are not depicted below. The following diagrams depict the different scenarios as listed above.




Figure 12: Scenario 1 – building blocks without SCP – legacy train example




Figure 13: Scenario 2 – building blocks with SCP for some applications – legacy train example




Figure 14: Scenario 3 – building blocks with SCP for all applications – legacy train example




Figure 15: Scenario 4 – building blocks with SCP for all applications – new generation train example

5.1 Automatic Train Operation On-Board (ATO-OB)

Detailed information on the Automatic Train Operation On-Board (ATO-OB) is available in document [\[84\]](#).

5.2 Cabin Voice Radio - Legacy (CVR-L)

The CVR-L is used for the communication between the driver and the operations control personnel and in some cases for communication between train staff. Today, it contains a control panel, a microphone, a loudspeaker, and a GSM-R voice radio and may connect directly with the PIS through a legacy connection (e.g., UIC) and to the DMI and/or JRU through respective connections. In current implementations, the CVR-L is only loosely integrated into the CCS domain, if at all. But with the upcoming migration from GSM-R to FRMCS options become available to share the new connectivity infrastructure, the FRMCS On-Board System, between the CCS data and cabin voice.

The CVR-L is an optional deployment on OCORA based CCS On-Board system. Refer to [Figure 12](#), [Figure 13](#) and [Figure 14](#) to locate the CVR-L building block in the OCORA architecture. In situations, where the train is running on FRMCS based infrastructure only, the need of a dedicated CVR-L vanishes and the communication between the driver, the operations control personnel and the train staff can be provided by using the OCORA based CVR-V building block described in section [5.3](#).

5.3 Cabin Voice Radio - VoIP (CVR-V)

The CVR-V building block, deployed on the OCORA computing platform, implements the Cab Voice Radio functionality in the CVR functional component and contains the Cab Voice Devices (CVD) consisting of the handset, the microphone, and the loudspeaker(s) in the cabin, combined with some electronics, allowing to communicate over the CCN with the FRMCS On-Board System.

The CVR is operated through the CVR-HMI component, which allows the train driver to initiate and receive voice communication between the train and the trackside operations control centres. In some cases, the CVR may also provide the functionalities to communicate with the train staff and to use the Passenger Information System for announcements by using the SCI-CVR interface.

For communication with the trackside operation control centres, the CVR component is using the services provided by the FRMCS On-Board System.

The CVR-V building block can be deployed on OCORA based CCS On-Board system, once an FRMCS On-Board System is installed on the vehicle and FRMCS is rolled out on the infrastructure where the vehicle is used.

In case GSM-R Radio is still used on the trackside infrastructure, the vehicle needs to be equipped with a legacy Cab Voice Radio (CVR-L) with a dedicated GSM-R radio module.

5.4 CCS Communication Network (CCN)

The CCS Communication Network (CCN) allows direct communication between all CCS On-Board components connected to it and eventually with external systems, such as the TCMS. The CCN is the most central part of the OCORA architecture and is the basis for achieving modularity that results in “plug & play” -like exchangeability of all identified building blocks. The CCN is a TSN Ethernet based network with the use of SDTv2/v4 as safety layer. On session layer (OSI layer 5, refer to OCORA OSI definitions in document [\[16\]](#)) different protocols (e.g., TRDP 2.0, OPC UA PubSub over TSN, DDS/RTPS over TSN) are possible. At the final stage, the CCN will be specified on all layers together with Shift2Rail CONNECTA/Safe4RAIL projects in the new IEC 61375 standards series.

Information regarding the requirements used for evaluating the CCN and the respective evaluation can be found in document [\[33\]](#).

5.5 Digital Map Repository (On-Board)

Detailed information on the Automatic Train Operation On-Board (ATO-OB) is available in document [84].

5.6 Driver Advisory System On-Board (DAS-OB)

The Driver Advisory System On-Board is an optional and non-safe and not necessarily standardised application typically calculating an energy efficient speed profile to achieve the pre-planned and dynamically updated train timings. It is either following the SFERA standard or any non-standardised vendor or IM specific specification. The DAS-OB is not needed for vehicles that have ATO-OB deployed and are operating on lines that provide ATO functionality, since the ATO-OB already includes DAS functionality.

The DAS-OB typically generates detailed driver advice for adhering to the planned timings while driving energy efficient. The trackside Driver Advisory System (DAS) or the Traffic Management System (TMS) is responsible for conflict detection and calculation of new target train timings, that are forwarded to the DAS-OB and evaluated accordingly. The typical integration of DAS-OB application is defined EN 15380-4. The DAS-OB can also operate standalone (e.g., without integration into the vehicle).

The DAS-OB application can be deployed on OCORA based CCS On-Board system, depending on the requirements of the rail network, the RU operates in. The DAS-OB installed on an OCORA platform can receive kinematic data from LOC-OB through the standardised interface SCI-VL. Vehicles can have multiple DAS-OB installed, depending on the network the vehicle operates in, one or the other is used. Also, a combination of DAS-OB and ATO-OB is feasible (see also Figure 16 and Figure 17). This might be especially interesting during transition periods from DAS-OB to ATO-OB.




Figure 16: Train equipped with ATO-OB and DAS-OB operating in different networks




Figure 17: Train using DAS-OB functionality from ATO-OB operating in different networks

5.7 European Train Protection On-Board (ETP-OB)

The European Train Protection On-Board (ETP-OB) represents the core of the on-board part of the European Train Control System (ETCS). ETCS is the signalling and control component of the European Rail Traffic Management System (ERTMS). It is a replacement for legacy train protection systems and designed to replace the many incompatible safety systems currently used by European railways.




Figure 18: European Train Protection On-Board (ETP-OB)

Notes: refer to Appendix C4 for large scale representation

1) may be moved into the PTU-OS / LOC&PAS domain.

SS-nnn: respective subset contains information for the interface.

SS-nnn*: respective subset does not address the interface but should contain the information in the future.

The European Train Protection On-Board (ETP-OB) is a building block that implements the core on-board part of the ETCS excluding functions expected to have independent lifecycles (e.g., connectivity, localisation, etc.). The ETP-OB is deployed on every OCORA based CCS On-Board system.

5.7.1 Interfaces

The following table lists all ETP-OB interfaces. Refer to Figure 18 to identify the currently foreseen ETP-OB communication partners. The interfaces of the type “Provider (P)” indicates that the ETP-OB building block is providing these interfaces. The interface of the type “Consumer (C)” indicates that the LOC-OB building block uses these interfaces.

Name	Description	Type
SCI-CMD	Standard Communication Interface – Cold Movement Detection	Provider (P)
SCI-ODS	Standard Communication Interface – Operational Data Storage	Provider (P)
SCI-VS	Standard Communication Interface – Vehicle Supervisor	Provider (P)
SS-130 (SCI-VS)	SUBSET-130 – ATO over ETCS	Consumer (C)
SCI-VL	Standard Communication Interface – Vehicle Locator	Consumer (C)
SCI-TS	Standard Communication Interface – Time Service	Consumer (C)
SCI-IAM	Standard Communication Interface – Identity and Access Management	Consumer (C)
SS-119 (EB)	SUBSET-119 – Emergency Brake	Consumer (C)
SS-119 (TCO)	SUBSET-119 – Traction Cut-Off	Consumer (C)
SS-119* (CS)	SUBSET-119 – Coupler Status	Consumer (C)
SCI-MDCM	Standard Communication Interface – Monitoring, Diagnostics, Configuration & Maintenance	Consumer (C)
SS-119 (SCI-FVA)	Standard Communication Interface – Functional Vehicle Adapter	Consumer (C)
SCI-DRU	Standard Communication Interface – Diagnostic Recording	Consumer (C)

Name	Description	Type
SS-119 (IS)	SUBSET-119 – Isolation	Consumer (C)
SS-027	SUBSET-027 - Juridical Recording	Consumer (C)
SCI-ETCS-DMI	Standard Communication Interface – ETCS DMI	Consumer (C)
SCI-VETS	Standard Communication Interface – Virtual ETCS Transponder Service	Consumer (C)
PI-CMD	Perception Interface – Cold Movement Detection	Consumer (C)
SCI-CMD	Standard Communication Interface – Cold Movement Detection	Provider (P)
SCI-STMC	Standard Communication Interface – STM Controller	C Consumer (C)
SCI-PETS	Standard Communication Interface – Physical ETCS Transponder Service	Provider (P)
SS-026	SUBSET-026 - RBC, Eurobalise and Euroloop communication	C Consumer (C)
SS-114 & 137	SUBSET-114, SUBSET-137 – Key Management Centre	C Consumer (C)

Table 1 ETP-OB Interfaces

Note: Standard Communication Interfaces for which the ETP-OB is the service provider (P), shall be exposed on the CCN to be available to an arbitrary number of current and future applications.

5.7.2 Functional Components

Vehicle Supervisor (VS)

The Vehicle Supervisor (VS) application, deployed on the OCORA computing platform, is a safe ETCS application (mandatory requirements are specified in SUBSET-026) in charge of calculating location specific speed limits (based on various inputs) and activating the braking system in case of speed limit overshoot. Location information is received from the Vehicle Locator (VL).

In ETCS L2 and L3 mode, the VS interacts with the RBC or the MT respectively. It receives the movement authority (MA) and reports the train position (TPR) to the respective system. The VS is agnostic to the communication technology used. Therefore, communication via GSM-R as well as via FRMCS or any future technology is possible. The VS also displays to the driver the necessary information (including cab signalling in ETCS L1, L2 and L3). It supports all ETCS modes and ETCS levels defined in the TSI-CCS.

In today's ETCS implementations, the VS is part of the monolithic ETCS OBU. Since the VS is a safe application and is expected to have a very different technological life cycle than the Localisation On-Board (LOC-OB), it is essential that the VS is a separate component, containing just the minimum functionality needed to perform the supervision of the vehicle during ETCS operations. Appendix B contains, on a very high-level, a first proposed split of functionality between the VS, VL, and the MLM / STMC, based on SUBSET 026, chapter 4.5. The OCORA architecture team is aware that splitting the functionality only based on the SUBSET-026, chapter 4.5 is not sufficient, because the SUBSET does not provide all requirements. SUBSET-026 is providing the mandatory requirement specifications only. A more detailed separation and a first version of a VS model, identifying additional requirements to SUBSET-026, can be expected in subsequent OCORA documentation releases.

Isolating the VS-functionality from the Localisation On-Board- and MLM- / STMC-functionality has the positive side-effect that the complexity of the VS is reduced and a stable component with little need for changes can be developed. A very important aspect since the VS requires a safe implementation and already many changes for the CCS On-Board are foreseeable. For example, it is expected that changes will be introduced, and more functionalities will be added to CCS On-Board in the upcoming TSI-CCS revisions and through the introduction of new game changers, which are:

- FRMCS
- ATO
- Train integrity detection for ETCS L3 mode

It is the goal of the OCORA architecture team to build a VS model that is mostly agnostic to these changes, and where not possible, does already consider the changes in the design.

Further details will be provided in subsequent versions of the CCS-OB architecture documentation.

EuroRadio Gateway (EGW) & Safety Protocol (ERS)

To address the design principles of OCORA, the current EuroRadio Protocol as specified in SUBSET-037 needs to be divided into multiple parts allowing a split between safe-/ non-safe functionalities and to enable access to future mobile communication technologies such as FRMCS without changing the safe part of the upstream application (e.g., ETP-OB).

[Figure 19](#) below illustrates the allocation of the divided functionalities (Safe Functional Module and Communication Functional Module) onto the OCORA Safe Computing Platform.

The Vehicle Supervisor (VS) and the EuroRadio Safety Layer (ERS) as Part of the ETP-OB component run on multiple instances to provide the appropriate safety integrity level (SIL) to the overall system. The EuroRadio Gateway acts as the gateway between the Safe Computing Platform and the external, non-safe entities (e.g., On-Board FRMCS). The EuroRadio Gateway is also responsible for the coordination between the legacy EDOR and the new FRMCS On-Board System and implements the FRMCS client realizing the loose coupling to the services of the On-Board FRMCS.




Figure 19: EuroRadio Safety allocation on the Safe Computing Platform

Mode and Level Manager (MLM)

The Mode & Level Manager (MLM) is a safe component of the ETP-OB in charge of managing the ETCS modes and levels. It ensures that the proper ETCS mode and level are active and manages the transitions from one mode or level to the other. In the latter context it also handles the handover between different RBCs. Furthermore, it makes sure that the correspondent information (e.g., current mode and level) is transmitted to the TCMS.

In today's ETCS implementations, the MLM is part of the monolithic ETCS OBU.

An analysis has been conducted in order to identify the information received and transmitted by the MLM. The result of the analysis is provided in document [32]. The methodology followed for the identification of input is based on the analysis of the SUBSET-026, chapter 4 (v3.6.0 incl. CR1238). The transition conditions provide the information needed by the MLM to compute mode and level state. We identify information already transmitted and specified in another logical component (FVA or HMI e.g.). The objective is to reuse information that are already defined. Document [32] contains multiple sheets:

- Transition condition: each condition id in the SUBSET-026, chapter 4.6.3 table are made up of elementary condition which are repeated several times through the table.
- Each elementary condition is listed with:
 - condition where they are involved
 - logical component which provides this information
- MLM IN: identify entry signal of the logical component. Elementary conditions are state of an information (desk open / desk close are elementary condition of the information cabin status e.g.) An input signal contains one or several information (driver acknowledgment OS, SR, SH... e.g.). Information that are already defined are reused (FVA specification interface, SUBSET-121 e.g.)

- MLM OUT: output of the MLM and identification of the recipient logical component
- MLM function: list of function supported by MLM
- Open Point: Point to be discussed for future evolution of the document

It is planned to complete the analysis for a future OCORA release by adding the following information: trigger (time or event), time constraint, safety of information exchanged, identification of function which use the information in the MLM and functions which use the information in another logical component.

Further details will be provided in subsequent versions of the CCS-OB architecture documentation.

STM Controller (STMC)

The STM Controller (STMC) is a safe component of the ETP-OB in charge of managing the safety authority between ETCS and installed national ATP systems (STM / NTC). It ensures that the proper ATP system is active and manages the switch-over from ETCS to the national ATP system and vice versa. The STMC interacts with the national ATP systems as defined in SUBSET-035 and SUBSET-058. The STMC with the respectively integrated national ATP systems enable an automatic transition from ETCS to the national ATP system and vice versa while the vehicle is driving.

In today's ETCS implementations, the STMC is part of the monolithic ETCS OBU and corresponds to the STM Control Function defined in SUBSET-035.

Further details will be provided in subsequent versions of the CCS-OB architecture documentation.

Physical ETCS Transponder Service (PETS)

The PETS component reads the ETCS telegrams from the trackside installed infrastructure (Eurobalise and Euroloop) and forwards them to the CCS On-Board applications.

Cold Movement Detection (CMD)

The logical component CMD is a vehicle-based function that detects if the train has moved while the CCS-OB system was powered-off. The CMD function is especially needed in the migration phase. In the final phase, where the vehicle is "always on" and "always connected / located", the function may not be needed anymore.

It is under discussion, if CMD should also provide the magnitude of the cold movement (see also CR1345 – Threshold small movements). With the implementation of CR1350 (always connected, always reporting) CMD functionality on the vehicle may not be required anymore.

Isolation Management

The logical component IM allows to isolate one or multiple ATP systems and informs the Physical Train Unit Operation Systems (PTU-OS) accordingly.

Trackside Condition Services (TCS)

The Trackside Condition Services (TCS) is a non-safe component of the ETP-OB in charge of managing the trackside condition information received from balises, RIU, or RBC. It calculates the remaining distance to specific trackside points and triggers the appropriate actions according to the location. Location information is received from the Vehicle Locator (VL). Also, the TCS informs the driver about the trackside points: it sends the commands to display the different pictograms on the DMI depending on the trackside point and the relative location to it. Furthermore, it makes sure that the correspondent information is transmitted using the SCI-FVA interface via FVA to the vehicle, and the distance information is updated as needed. The TCS remains active during level transitions, including transition to level NTC.

Further details will be provided in subsequent versions of the CCS-OB architecture documentation.

ETP Repository On-Board (ERP-OB)

The logical component EDR-OB includes the Operational Data Storage (ODS) and the Configuration Data Storage (CDS) components.

Operational Data Storage (ODS)

The Operational Data Storage (ODS) is a data storage for saving quite dynamic data that is entered / provided during an operational day of a vehicle and has no relevance for long-time safeguarding. The operational data storage is separated from the ETCS components (e.g., VS) to make the data easily available to other applications that may need it (e.g., ATO-OB). The operational data storage contains data provided by the driver, the TCMS, I/O Ports, and possibly the device and configuration management. Examples of Operational Data is the driver id, the train running number, the status of a cab, etc. In subsequent versions of the OCORA specifications, the ODS will be specified in more detail.

Configuration Data Storage (CDS)

The Configuration Data Storage (CDS) stores static and semi-static data needed for the CCS On-Board system. The data storage is separated from the operational data, and it is separated from the ETCS components (e.g., VS) to make the data easily available to other applications that may need it (e.g., VL). The Configuration Data Storage contains data provided when commissioning a CCS On-Board system for the first time and is changed whenever configurations of the vehicle change (e.g., additional sensors, additional DMI, etc.). The data is entered by service technicians through the local maintenance terminal or via the remote maintenance. In both cases this occurs through the Monitoring, Diagnostics & Configuration On-Board (MDCM-OB) component. In subsequent versions of the OCORA specifications, the CDS will be specified in more detail.

The ETCS On-Board application should implement configuration capability for the train characteristics, the latter being independent from other configuration parameters. This to allow defining the train characteristics for different train types without affecting the certification of the whole ETCS On-Board application, the same also being valid in case of modifications.

Scope of OCORA is to reduce the variability of implementation of the CCS On-Board applications (i.e. ETCS On-Board application). This is achieved by properly defining what is expected from the ETCS On-Board application in terms of configurability (at the end this results in a list of requested configuration parameters).

Goal is that CCS On-Board applications from different suppliers can be exchanged between each other, but also that the same CCS On-Board application can be deployed on different train types with a minimal effort.

ETP Data Recording On-Board (EDR-OB)

The logical component EDR-OB includes the Juridical Data Writing (JDW) and the Diagnostic Data Writing (DDW) components.

Juridical Data Writing (JDW)

The component responsible for compiling JRU messages as per SS-027 and sending them to the JRU.

Diagnostic Data Writing (DDW)

The component responsible for compiling national diagnostic messages and sending them to the DRU.

KMAC Services On-Board (KMAC-OB)

The KMAC Services On-Board (KMAC-OB) is responsible for managing the authentication keys needed to establish a safe connection between the on-board and trackside entity. It communicates with the Key Management Centre (KMC) of the infrastructure manager using SS-114 and SS-137.

5.8 Functional Vehicle Adapter (FVA)

Refer to chapter 3.11 for details

5.9 Localisation On-Board (LOC-OB)

Localisation On-Board (LOC-OB) contains the Vehicle Locator (VL) and Vehicle Locator Sensor (VLS) functionality. The Figure 20 identifies the LOC-OB component in the overall CCS-OB architecture and depicts all interfaces to all currently known CCS-OB actors and CCS-OB components.




Figure 20: Localisation On-Board (LOC-OB)

Notes: refer to Appendix C5 for large scale representation

1) may be moved into the PTU-OS / LOC&PAS domain.

SS-nnn: respective subset contains information for the interface.

5.9.1 Interfaces

The following table lists all LOC-OB interfaces. Refer to Figure 20 to identify the currently foreseen LOC-OB communication partners. The interface of the type “Provider (P)” indicates that the LOC-OB building block is providing this interface. The interface of the type “Consumer (C)” indicates that the LOC-OB building block uses these interfaces.

Name	Description	Type
SCI-VL	Standard Communication Interface – Vehicle Locator	Provider (P)
SCI-DREP	Standard Communication Interface – Digital Map Repository	Consumer (C)
SCI-TRI	Standard Communication Interface – Train Routing Information	Consumer (C)
SCI-AUG	Standard Communication Interface – Augmentation	Consumer (C)
SCI-TS	Standard Communication Interface – Time Service	Consumer (C)
SCI-IAM	Standard Communication Interface – Identity and Access Management	Consumer (C)
SCI-MDCM	Standard Communication Interface – Monitoring, Diagnostic, Configuration, Maintenance	Consumer (C)
SS-119 (FVA)	SUBSET-119 – Functional Vehicle Adapter	Consumer (C)
PI-VLS	Perception Interface – Vehicle Locator Sensors	Consumer (C)
SCI-CMD	Standard Communication Interface – Cold Movement Detection	Consumer (C)
SCI-CDS	Standard Communication Interface – Configuration Data Storage	Consumer (C)
SCI-ODA	Standard Communication Interface – Operational Data Storage	Consumer (C)
SCI-PETS	Standard Communication Interface – Physical ETCS Transponder Service	Consumer (C)
SCI-VS	Standard Communication Interface – Vehicle Supervisor	Consumer (C)

Table 2 LOC-OB Interfaces

Note: Standard Communication Interfaces for which the LOC-OB is the service provider (P), shall be exposed on the CCN to be available to an arbitrary number of current and future applications.

5.9.2 Functional Components

Vehicle Locator (VL)

The Vehicle Locator (VL) is a safe CCS On-Board component that uses sensor data and supporting information to provide train location output information safely and reliably. The Vehicle Locator (VL) is able to provide the absolute and relative position of the front end of the train, train orientation information as well as kinematic parameters such as speed, acceleration, or rotational angles; hence, the VL is more than just an odometry component. The VL is deployed on every OCORA based CCS On-Board system.

In today's ETCS implementations, the VL is part of the monolithic ETCS OBU. Since the VL has a different technological life cycle than the VS, it is essential that the VL is a separate component, containing just the functionality needed to perform the vehicle localisation. This allows new localization technologies to be introduced more quickly in the future without the need to modify the VS functionality. Appendix B contains, on a very high-level, a first proposed split of functionality between the VS, and VL, based on SUBSET-026, chapter 4.5. The OCORA architecture team is aware that splitting the functionality only based on the SUBSET-026, chapter 4.5 is not sufficient, because the subset does not provide all requirements. SUBSET-026 is providing the mandatory requirement specifications only. A more detailed separation and a first version of a VL model, identifying additional requirements to SUBSET-026, can be expected in subsequent OCORA documentation releases.

Isolating the VL- from the VS-functionality has the positive effect that the complexity of the VL is reduced. A very important aspect, since the VL is requiring a safe implementation and already many changes for the CCS on-board, impacting the VL, are foreseeable. New functionalities (game changers) with potential impact on the VL are:

- FRMCS
- ATO
- Train integrity detection for ETCS L3
- GNSS augmentation
- Digital map

It is the goal of the OCORA architecture team to build a VL model that is mostly agnostic to these changes, and where not possible, does already consider the upcoming changes in the design.

This logical component includes the functionality the locator sensors are providing. Further information can be found in the documents [29], [30], [69], and [70].

Vehicle Locator Sensors (VLS)

This logical component includes the functionality the locator sensors are providing. Further information can be found in the documents [29], [30], [69], and [70].

5.10 Monitoring, Diagnostics, Configuration, Maintenance (MDCM-OB)

The MDCM-OB is an OCORA CCS-OB building block that provides standardised services for monitoring, diagnostic, configuration, and maintenance tasks to onboard and trackside clients.

For remote monitoring and diagnostic tasks, the MDCM-OB collects relevant data from onboard systems and forwards it to trackside clients via the Mobile Communication Gateway (MCG).

For local monitoring and diagnostic tasks (onboard the vehicle), the MDCM-OB provides relevant data for the Maintenance Terminal (MNT) or the Train Display System (TDS).

For the configuration of onboard equipment, the corresponding MDCM-OB services can be either used locally through the Maintenance Terminal, or remotely through the Monitoring, Diagnostic, Configuration, Maintenance (MDCM) trackside server application.

Remarks:

- Technically, the MDCM-OB is deployed on the OCORA CCS-OB computing platform or on a dedicated hardware.
- MDCM-OB services are typically used by RUs and potentially by IMs. Other potential MDCM-OB stakeholders/users are, for example, CCS-OB or train providers.
- MDCM-OB data services and associated data channels can be configured for data-driven or demand-driven operation.
- Onboard equipment which is configurable through the MDCM-OB includes CCUs, network components and peripheral devices.
- When it comes to MDCM-OB configuration services, RUs will use them for vehicle configuration, such as equipment configuration, calibration, and software updates.
- The MDCM-OB services will process the data (as far as possible) in a transparent manner. That is, the content of the data, in particular configuration data, is not in MDCM-OB scope.

Detailed information on the Monitoring, Diagnostics & Configuration On-Board (MDC-OB) is available in document [\[52\]](#).

5.11 National Train Protections (NTPs)

The NTPs provides Automatic Train Protection functionality on national level. The NTPs can be either a dedicated NTC HW Solution (NTC-HWS) or it can be deployed as NTC Application (NTC-APP) running on the OCORA computing platform.

The NTPs is foreseen to be deployed on every OCORA based CCS On-Board system in need of NTP.

NTC HW Solution (NTC-HWS)

The NTC-HWS is a dedicated hardware solution implementing the national Automatic train protection solution with the NTC and STM components.

The NTC-HWS is foreseen to be deployed on every OCORA based CCS On-Board system in need of NTP. Refer to Appendix D4 on page 116 to locate the NTC-HWS component in the OCORA architecture.

Further details will be provided in subsequent versions of the OCORA architecture documentation.

National Train Control (NTC)

The National Train Control (NTC) implements the national Automatic Train Protection functionality on dedicated hardware. It communicates with other OCORA components, namely the STM and can also use the functionality of other components connected to the CCN (e.g., DRU).

The NTC is foreseen to be deployed on every OCORA based CCS On-Board system in need of NTP. Refer to Appendix D4 on page 116 to locate the NTC component in the OCORA architecture.

Further details will be provided in subsequent versions of the OCORA architecture documentation.

Specific Transition Module (STM)

The Specific Transmission Module (STM) provides the connection between the ETCS system (in case of OCORA the CCN) and the National Train Control System (NTC). The STM and the NTC are often closely integrated, hence the term STM is often used, when referring to the NTC system.

The STM is foreseen to be deployed on every OCORA based CCS On-Board system in need of NTP. Refer to Appendix D4 on page 116 to locate the STM component in the OCORA architecture.

Further details will be provided in subsequent versions of the OCORA architecture documentation.

NTC Application (NTC-APP)

The National Train Controls Applications (NTC-APP), deployed on the OCORA computing platform, are safe applications in charge of ensuring Automatic train protection based on national systems. NTC-APPs, implemented on the OCORA computing platform, must communicate, as a minimum, with the Mode and Level Manager (MLM) and can use their specific sensors and actuators. In addition, they can take advantage of the standard OCORA interfaces. E.g., location information can be received from the Vehicle Locator (VL), data can be recorded in the DR-OB, DMI can be used, the TCMS can be accessed through the Functional Vehicle Adapter (FVA) and the NTC-APPs can also access balise telegrams through the ETCS Transponder Service (ETS) in order to get the packet 44 information.

Multiple NTC-APPs can be deployed on OCORA based CCS On-Board system, depending on the requirements of the rail network, the RU wants to operate in. Refer to Appendix D4 on page 116 to locate the NTC-APPs in the OCORA architecture.

Further details will be provided in subsequent versions of the OCORA architecture documentation.

5.12 Perception On-Board

The PER-OB logical component is deployed on every OCORA based CCS On-Board system in need of ATO GoA 3 or GoA 4 functionality. In case of light signalling perception, the PER-OB may also be used for GoA1-2 operations. Refer Appendix D4 on page 116 to locate the PER-OB component in the OCORA architecture.

5.13 Remote Manual Train Operation On-Board (RMTO-OB)

The Remote Manual Train Operation On-Board (RMTO-OB) allows for remote driving of trains. The system provides real-time position and speed information, combined with video streams to RMTO, allowing to control a train from a central site.

The RMTO-OB system is considered to be mandatory for operators with trains running under ATO GoA 3/4 but may be useful also for ATO GoA 1/2 or for trains not equipped with ATO functionality.

5.14 Safe Computing Platform (SCP)

The computing platform provides the infrastructure required for operating OCORA's modular, software-component-based, distributed functional CCS On-Board applications. Safety and non-safety critical applications shall be able to coexist on the same platform and may even run on the same computing hardware.

The incentive to postulate an open, standardised computing platform is directly derived from the OCORA problem statements, key principles, objectives, and design statements as described in [5] and [7].

Todays deployed CCS On-Board systems are proprietary, monolithic vendor specific solutions, creating undesired vendor lock-ins resulting in very high cost of ownership. High-priced changes and extensions stall advancements and impede new game-changing technologies.

Safety functions implemented by CCS On-Board systems demand adherence to railway specific standards during development, operation, and maintenance of the entire systems. The stringent homologation processes imposed by CENELEC (standards such as EN50126, EN50128, EN50129) is exorbitantly expensive and time consuming when applied to proprietary, monolithic products in every (type of) rolling stock.

OCORA aims to mitigate the problem by breaking down the CCS On-Board system into different layers and components with defined, open interfaces that can be developed, tested, and certified independently.

The proposed computing platform provides a communication focused abstraction layer; a construction kit for building functional applications, agnostic of the underlying operating system, board support package, hypervisor, and hardware.

Today's monolithic solutions block innovative new application development due to

- lacking support for new functions, sensors, and actuators
- lacking ability to cope with increased/different processing requirements (like real-time/non-real time)
- lacking support for calculation intense machine learning algorithms that require GPU hardware processing.

The OCORA computing platform pursues to address these issues by abstracting the underlying hardware, board support package and operating system. An open, unified platform independent API shall open the door to platform agnostic application development while entrusting the computing platform internals to experienced vendors.

Industrial and technological readiness are essential, when deploying new CCS components. To meet this target, a computing platform that is deployed on a large scale must have been extensively field tested (e.g., to ensure reliability in operation). It will take several computing platform iterations to achieve all OCORA goals (e.g., full hardware independency may not be achieved in the first computing platform generation). Along the journey, applications' portability will be indispensable to leverage implementation and certification effort across the evolving computing platform generations.

Detailed information on the Computing Platform is available in the following documents:

- Computing Platform – Whitepaper [35]
- Computing Platform – Requirements [36]
- Computing Platform – Initial Specification of the PI API between Application and Platform [37]

5.15 Train Display System (TDS)

The Train Display System (TDS) provides Human Machine Interface (HMI) functionality to any CCS-OB application (multi-application display). It can handle, in a standardised way, the speed indication in case of isolation of the ETCS (fallback speed) and provides fail-over functionality from one display to the other. The TDS can also handle safe and non-safe information in a standardised manner. Refer also to CR1246 for further information.

5.16 User Identification and Authentication (UIA)

The User Identification and Authentication (UIA) building block is used to automate the identification process for drivers and service technicians. RFID card readers may be the most common option used at this point in time for the User Identification Reader (UIDR). But as technology advances, fingerprint, face ID, etc. might become viable options. The OCORA specifications will be technology agnostic.

The UIA is an optional deployment on OCORA based CCS On-Board system. Further details will be provided in subsequent versions of the OCORA architecture documentation.

5.17 Virtual Train Coupling System On-Board (VTCS-OB)

The Virtual Train Coupling System On-Board (VTCS-OB) provides all functionality needed for trains to drive in a virtual coupling mode. Refer also to document.

Further information is available in X2Rail-3 document [84].

Appendix A Train integration scenarios

OCORA has identified the following scenarios for integrating the OCORA CCS On-Board solution into the various type of trains. The scenarios listed are not exhaustive but provide a representative selection.

A1 Scenario A: CCN as physically separated network

This scenario applies to all cases where an OCORA compliant CCS System is integrated into a Train having a NG-TCN. The CCS-, NG-TCN-, Communication- and Operator networks are physically separated networks interconnected through an ECN/ECN Security Gateway. This scenario further assumes that all Peripheral Devices are OCORA compliant and are therefore directly connected to the CCN, following the OCORA interface standard. Refer to [33] for further details on related topology of this scenario.





Figure 21: NG-TCN train – separate networks

Highlighted elements in Figure 21:

 Indication of physical segmentation between CCS, Train and other networks

 Components supporting legacy trackside infrastructure during migration phases

A2 Scenario B: CCN as logically separated network

This scenario applies to all cases where an OCORA compliant CCS System is integrated into a Train having a NG-TCN. The control system networks (CCN and NG-TCN) are using the same physical network while separated from the non-control networks (e.g., Operator Network) through the ECN/ECN Security Gateway. The common control system network is then logically segmented into different virtual networks (VLANs) based on its **functional domain** (CCS and TCMS systems). This scenario further assumes that all peripheral devices and connectivity devices are OCORA compliant and are therefore directly connected to the CCN, following the OCORA interface standard. Refer to [33] for further details on related topology of this scenario.




Figure 22: NG-TCN train – common network

Highlighted elements in [Figure 22](#):

- Common physical network for the CCS and TCMS systems separated from non-control systems
- Components supporting legacy trackside infrastructure during migration phases

A3 Scenario C: Common critical control network logically separated

This scenario applies to all cases where an OCORA compliant CCS System is integrated into a Train having a NG-TCN. The control system networks (CCN and NG-TCN) are using the same physical network while separated from the non-control networks (e.g., Operator Network) through the ECN/ECN Security Gateway. The common control system network is then logically segmented into different virtual networks (VLANs) based on its **criticality** (critical and non-critical control systems). This scenario further assumes that all peripheral devices and connectivity devices are OCORA compliant and are therefore directly connected to the CCN, following the OCORA interface standard. Refer to [33] for further details on related topology of this scenario.




Figure 23: NG-TCN train – Common critical control network logically separated

Highlighted elements in Figure 23:

- Common physical network for the CCS and TCMS systems separated from non-control systems
- Components supporting legacy trackside infrastructure during migration phases

A4 Scenario D: Common critical control network physically separated

This scenario applies to all cases where an OCORA compliant CCS System is integrated into a Train having a NG-TCN. The critical-control systems (CCS and critical control components of the TCMS) are using the same physical network while physically separated from any other network (e.g., Operator network, Auxiliary network) through the ECN/ECN Security Gateway. This scenario further assumes that all peripheral devices and connectivity devices are OCORA compliant and are therefore directly connected to the CCN, following the OCORA interface standard. Refer to [33] for further details on related topology of this scenario.





Figure 24: NG-TCN train – Common critical control network physically separated

Highlighted elements in Figure 24:

 Common physical network for the critical control systems separated from other networks

 Components supporting legacy trackside infrastructure during migration phases

A5 Scenario for retrofit vehicles with OCORA compliant CCS peripherals

This scenario applies to all cases where an OCORA compliant CCS System is integrated into a legacy train that has no Ethernet based network for its train control. Hence, the communication with the TCMS is implemented through the OCORA Gateway and the respective Functional Vehicle Adapter (FVA). This scenario further assumes that all Peripheral Devices and Connectivity Devices are OCORA compliant and are therefore directly connected to the CCN, following the OCORA interface standard. Refer to [33] for further details.





Figure 25: Legacy train – OCORA compliant CCS-OB peripherals

Highlighted elements in Figure 25:

 Components related to the integration between the CCS and Train

 Components supporting legacy trackside infrastructure during migration phases

Appendix B Relating functions from SUBSET-026

To support modularity, OCORA suggests implementing the current ETCS On-Board functionality in separate functional blocks. Among others, the following key functional blocks have been already identified in previous OCORA releases: VS = Vehicle Supervisor / VL = Vehicle Locator / MLM = Mode & Level Manager / STMC = STM Control. This list of functional blocks has now evolved and do so in subsequent releases of the OCORA documentation releases.

The following table assigns current ETCS On-Board functionality (as per SUBSET-026, chapter 4.5) to the respective functional block. It contains, on a very high-level, a first proposed split of functionality between the functional blocks identified so far. The OCORA architecture team is aware that splitting the functionality only based on the SUBSET-026, chapter 4.5 is not sufficient, because the SUBSET does not provide all requirements. SUBSET-026 is providing the mandatory requirement specifications only. A more detailed separation and identification of additional requirements to SUBSET-026 can be expected in subsequent OCORA documentation releases.

N°	On-Board Functions	Reference SUBSET-026	VS	VL	MLM	STMC	CMD	NTP	TCS	PETS	ODS	CDS	FVA	TS-OB	JDW	TDS
Data Consistency																
1)	Check linking consistency	3.16.2.3 3.4.4	X ¹													
2)	Check Balise Group Message Consistency if linking consistency is checked	3.16.2.4.1 3.16.2.4.3	X ¹													
3)	Check Balise Group Message Consistency if no linking consistency is checked (because no linking information is available and/or because the function "check linking consistency is not active")	3.16.2.4.4	X ¹													
4)	Check Unlinked Balise Group Message Consistency	3.16.2.5	X ¹													
5)	Check correctness of radio messages	3.16.3.1.1	X													
6)	Check radio sequence	3.16.3.3	X													
7)	Check safe radio connection (only level 2/3)	3.16.3.4	X													
Determine Train Speed and Position																
8)	Determine train position referenced to LRBG	3.6.1 3.6.4		X												
9)	Determine train speed, train acceleration	None		X												
10)	Determine train standstill			X												
11)	Determine Geographical Position	3.6.6	X	X ²												
12)	Report train position when train reaches standstill	3.6.5.1.4 a)	X ³													
13)	Report train position when mode changes to...1	3.6.5.1.4 b)	X ⁴													
14)	Report train position when train integrity confirmed by driver	3.6.5.1.4 c)	X ⁴													
15)	Report train position when loss of train integrity is detected	3.6.5.1.4 d)	X ⁴													
16)	Report train position when train front/rear passes an RBC/RBC border (only level 2/3)	3.6.5.1.4 e) 3.6.5.1.4 k)	X ⁴													
17)	Report train position when train rear passes a level transition border (from level 2/3 to 0, NTC, 1)	3.6.5.1.4 f)	X ⁴													
18)	Report train position when change of level due to trackside order	3.6.5.1.4 g)	X ⁴													
19)	Report train position when change of level due to driver request	3.6.5.1.4 g)	X ⁴													

¹ VS informs VL about valid Balise Groups

² In case of on-board localisation

³ Content must be safe in future (L3 / moving block); Trigger for Report is "ns"

N°	On-Board Functions	Reference SUBSET-026	VS	VL	MLM	STMC	CMD	NTP	TCS	PETS	ODS	CDS	FVA	TS-OB	JDW	TDS
20)	Report train position when establishing a session with RBC	3.6.5.1.4 h)	X ⁴													
21)	Report train position when a data consistency error is detected (only level 2/3)	3.6.5.1.4 i)	X ⁴													
22)	Report train position as requested by RBC...	3.6.5.1.4	X ⁴													
23)	... or Report train position at every passage of an LRBG compliant balise group	3.6.5.1.4 j)	X ⁴													
Manage MA																
24)	Request MA Cyclically respect to approach of perturbation location (T_MAR) or MA timer elapsing (T_TIMEOUTTRQST) (only level 2/3)	3.8.2.3 a) and b)	X													
25)	Request MA Cyclically when "Start" is selected (only level 2/3)	4.4.11 5.4, 5.11	X													
26)	Request MA on reception of "track ahead free up to the level 2/3 transition location" (only level 0,1,NTC)	3.8.2.7.1	X													
27)	Request MA on track description deletion (only level 2/3)	3.8.2.7.3	X													
28)	Determine EOA/LOA, SvL, Danger Point, etc.	3.8.4 3.8.5	X													
29)	Handle Co-operative MA revocation (only level 2/3)	3.8.6	X													
30)	Manage Unconditional Emergency Stop	3.10	X													
31)	Manage Conditional Emergency Stop	3.10	X													
Determine Most Restrictive Speed Profile, based on:																
32)	SSP	3.11.3	X													
33)	ASP	3.11.4	X													
34)	TSR	3.11.5	X													
35)	Signalling related speed restriction when evaluated as a speed limit	3.11.6	X													
36)	Mode related speed restriction	3.11.7	X													
37)	Train related speed restriction	3.11.8	X													
38)	STM max speed	3.11.2.2 g)	X													
39)	STM system speed	3.11.2.2 h)	X													
40)	LX speed	3.12.5.6	X													
41)	Speed restriction to ensure a given permitted braking distance	3.11.11	X													
42)	Override related speed restriction	5.8.3.6	X													
Supervise Train Speed																
43)	Speed and Distance Monitoring based on MRSP, MA, release speed, gradient, mode profile, non-protected LX start location, and route unsuitability location	3.13 5.9.3.5 57.3.4 3.12.2.8 3.12.5.4	X													
44)	Speed and Distance Monitoring based on MRSP	4.4.10.1	X													
45)	Speed and Distance Monitoring based on MRSP, allowed distance to run in Staff Resp. mode	4.4.11	X													
46)	Ceiling Speed Monitoring only (no braking curve) based on MRSP	4.4.8.1.1 a) 4.4.18.1.3 a)	X													
Supervise Train Movements																
47)	Backwards Distance Monitoring	4.4	X													
48)	Roll Away Protection	3.14.2	X													
49)	Reverse Movement Protection	3.14.3	X													
50)	Standstill Supervision	3.14.4 4.4.7.1.5	X													
51)	Supervise "danger for shunting" information and list of expected balises for shunting	4.4.8.1.1 b) and c)	X													

N°	On-Board Functions	Reference SUBSET-026	VS	VL	MLM	STMC	CMD	NTP	TCS	PETS	ODS	CDS	FVA	TS-OB	JDW	TDS
52)	Supervise "Stop if in SR" information and list of expected balises for Staff Responsible	4.4.11.1.3 c) and d)	X													
53)	Supervise signalling related speed restriction when evaluated as a trip order	3.11.6.4	X													
54)	Command Emergency Brake	4	X	tbd				X								
55)	Determine Mode and Level															
56)	Determine ERTMS/ETCS Mode	3.12.4 4.6			X											
57)	Determine ERTMS/ETCS level	5.10			X											
58)	Other functions															
59)	System Version Management	3.17	X													
60)	Manage Communication Session	3.5	X ⁴													
61)	Delete Revoked TSR	3.11.5.5	X													
62)	Override (Trip inhibition)	5.8	X													
63)	Manage Track Conditions excluding Sound Horn, Non-Stopping Areas, Tunnel Stopping Areas and Big Metal Masses	3.12.1	X						X							
64)	Manage Track Conditions Sound Horn, Non-Stopping Areas, Tunnel Stopping Areas	3.12.1	X													
65)	Manage Track Condition Big Metal Masses	3.12.1	X						?							
66)	Manage Route Suitability	3.12.2	X													
67)	Manage Text Display to the driver	3.12.3	X													?
68)	Manage LSSMA display to the driver	4.4.19.1	X													?
69)	Manage RBC/RBC Handover (only level 2/3)	3.15.1 5.15	X ⁵													
70)	Manage Track Ahead Free Request (only level 2/3)	3.15.5	X													
71)	Provide Fixed Values, and Default/National Values	3.18.1 3.18.2	X								X					
72)	Manage change of Train Data from external sources	5.17	X									X	X			
73)	Provide Date and Time	3.18.5												X		
74)	Provide Juridical Data	3.20													X	
75)	Inhibition of revocable TSRs from balises (only level 2/3)	3.11.5.12 3.11.5.13 3.11.5.14 3.11.5.15		X												
76)	Cold Movement Detection	3.15.8						X								
77)	Continue Shunting on desk closure (Enabling transition to Passive Shunting mode)	5.12.4			X											
78)	Manage "Stop Shunting on desk opening" information	4.4.20.1.8 4.4.20.1.9			X											
79)	Manage Virtual Balise Covers	3.15.9	X													
80)	Advance display of route related information	3.15.10	X													?

Table 3 Relating Functions from SUBSET-02

⁴ OCORA aims to split safe from non-safe functionality. Hence, it might be reasonable to remove this functionality from the VS and have it implemented in a separate component. This will be elaborated in more detail in subsequent versions of this document.

⁵ RBC handover might also be relevant for VL, e.g. digital map downloads

Appendix C Large scale graphics

This section contains large scale graphics of graphics used throughout the document.

C1 CCS-OB – Scope – logical architecture




Figure 26: Scope – logical architecture (large scale representation)

1) may be moved into the PTU-OS / LOC&PAS domain.

C2 CCS-OB – Actors – logical architecture




Figure 27: Actors – logical architecture (large scale representation)

1) may be moved into the PTU-OS / LOC&PAS domain.

C3 CCS-OB – External interfaces – logical architecture




Figure 28: External interfaces – logical architecture (large scale representation)

1) SS-nnn* may be moved into the PTU-OS / LOC&PAS domain.
SS-nnn* respective subset contains information for the interface.
SS-nnn* respective subset does not address the interface but should contain the information in the future.

C4

European Train Protection On-Board (ETP-OB) – logical architecture




Figure 29: ETP-OB – logical architecture (large scale representation)

1) SS-sss may be moved into the PTU-OS / LOC&PAS domain.
SS-sss* respective subset contains information for the interface.
SS-sss* respective subset does not address the interface but should contain the information in the future.

C5 Localisation On-Board (LOC-OB) – logical architecture




Figure 30: LOC-OB – logical architecture (large scale representation)

1) may be moved into the PTU-OS / LOC&PAS domain.
SS-nnn respective subset contains information for the interface.
SS-nnn* respective subset does not address the interface but should contain the information in the future.