OSIM

uSqueeze XE DUO FOOT

User Manual
OZ1007

CONTENTS

Safety Instructions 2
Warranty Claims 4
Main Unit & Accessories 5
Controller Diagram 6
Product Features 8
Product Maintenance 9
Troubleshooting 10
Product Specifications 11
Contact Us 12

Safety Instructions

I. Usage environment

- Do not use this appliance for any purpose or during circumstances as mentioned in the user manual.
- Do not use this appliance in the bathroom.
- Do not place or store the appliance where it can fall or be pulled into a bathtub.
- Do not place the appliance in water.
- Do not use this appliance outdoors.
- Do not operate the appliance where aerosol (spray) products are being used or where oxygen is being administered.

II. Unsuitable user

Check the medical contraindications or conditions as stated below, before using this appliance.

- Suffering from heart disease
- Pregnancy
- Cancer

III. When the product should not be used

- Do not use this appliance if it is damaged.
- If the power cord is damaged, it must be replaced by a qualified service person.
- Do not use the product unless sitting.
- Do not use the product lying down.
- Do not use the product while sleeping.
- Do not use the product under the influence of alcohol.
- Do not use this appliance for other than its intended purpose.

IV. Caution and warning

- Unplug the appliance from the wall socket when not in use.

Safety Instructions

- Do not use any attachments that are not recommended by Osim.
- Do not use the appliance with damaged cords or plugs. If the appliance is not working as it should, has been dropped, damaged, left outdoor, or dropped into water, return it to a service center for examination and repair.
- Keep the hair, loose clothing, fingers and all parts of the body away from moving parts of the appliance.
- Keep the power cord away from heated surfaces.
- Do not insert or allow objects to enter any opening.
- Do not carry the appliance by the power cord.
- Do not use while appliance is under the blanket.

V. Note

- Due to the product quality, may occasionally malfunction to ensure proper use, please read the manual carefully.
- Please read the manual carefully before using the product. If you are using a pacemaker or other electronic device, please consult your doctor before using the product. Electromagnetic waves may affect the operation of your pacemaker or other electronic devices.
- Please keep the manual properly for reading during the whole process of usage. Transfer it to a new owner or usage user when the unit is transferred.
- Please keep the packaging properly for storage or transportation.
- Please do not use the product for other purposes than the intended use mentioned in the manual.
- Please do not use the product if it is damaged.

Safety Instructions

- Do not dismantle the uSqueeze, as this could be dangerous or cause to malfunction.
- Please use the appliance in the electrical supply in home.

Warranty Claims

- Warranty is non-transferable.
- The warranty is effective only for the product is purchased from osimcare.com, osim.com or OSIM authorized retail stores in Singapore.
- All material replacements, including but not limited to broken digital panel/main PCB, will be subjected to a service charge of $50 (subject to prevailing GST).
- Warranty does not cover damages caused due to accidental misuse/abuse and wear and tear caused by the operating.
- Warranty does not cover damages caused by unauthorized repair by non-OSIM Authorized Service Centre.
- Warranty does not cover damages caused by unreasonable, unnecessary or other misrepresentations.
- Warranty does not cover any consumables that be depleted by means and/or normal wear and tear.
- Warranty does not cover any damages caused by improper packaging or incorrect shipping method.

Main Unit & Accessories

1. Calf Massager
2. Main Controller
3. Calf Massager Cover
4. Plug
5. Power Cord
6. Foot Massager Connector
7. Foot Massager
8. Foot Massager Cover (Please note that the foot massager cover is not washable.)
9. Remote Control





Controller Diagram



Hold these 2 or 4 buttons once and off as the unit for your safety.

When OSIM® System is pressed, the device will automatically move to the default massage position. Please ensure that the device is in the default position before the massage session starts. Any form of movement will interrupt the massage session.

ON/OFF
Press the "ON/OFF" button to turn on the device and automatically start the default auto massage function. Press the "ON/OFF" button again to turn off the device.

Auto
Press the "Auto" or the "Save" button to cycle through "Full Back", "Upper Back" and "Lower Back" massage functions.

Full Back
Press the "Full Back" button to activate the mode. the light will on. Recreate the massage function of a therapist's hands from neck to calves.

Upper Back
Press the "Upper Back" button to activate the mode. the light will on. Recreate the massage function of a therapist's hands from neck to upper back.

Lower Back
Press the "Lower Back" button to activate the mode. the light will on. Recreate the massage function of a therapist's hands from upper back to calves.

Spot
Press the "Spot" button, the light will on. Select massage function on one area, you can choose from neck, back, shoulder, calves.

Vibration
Press "Vibration" button to activate the vibration, the vibration on feet, calves and thighs will be activated. Press again to deactivate the vibration.

Controller Diagram

Heat
Press the "Heat" button to turn the massage heat on and off. Use with Intensity and Speed to customize your massage. Heat will automatically turn off after 30 minutes of continuous use.

Intensity
Press the "Intensity" button to change the range of air settings. Set the air pressure to your preference.

Stop
Press the "Stop" button to pause the massage, the light will on.

Product Features

- 3 massage programs and 3 manual programs for customization of your spare time.
- Heat function for massage, 30 minutes continuous use.
- Intensity and speed.
- Easy to use with remote control.
- Foot massager connector.
- Calf massager.

Effects by using the appliance

- Relieves the muscle aches and pains.
- Relaxes the muscles and improves blood circulation.
- Promotes a sense of well-being.

Please note that you should not use this product for more than 1 hr off the power immediately until the motor has cooled down to normal and the operation again.

Product Maintenance

To store

- Keep the massager in the box or in a safe, dry and cool place.
- Keep the massager away from sharp edges or parts to clean to the angle.
- Keep the massager away from heat sources and open flames.
- Do not store the massager in direct sunlight.
- Do not store the massager in extreme temperatures.

To clean

- Clean the massaging unit by dry liquid-free cleaning.
- Do not use any cleaning agents or solvents.
- Do not immerse the massager in water or any other liquid.
- Keep the appliance away from water or any liquid.
- Do not use the appliance if the cover is damaged or severely stained, please contact us to get a new cover for replacement.

Caution

- Do not store the unit when plugged into power to the control unit.
- Do not store the unit when the foot massager and calf massager is pulled.
- Do not pull on the foot massager and calf massager when the foot massager and calf massager is pulled out.
- Do not store the unit when the foot massager and calf massager is pulled out.
- Do not attempt to repair the massager yourself, please contact us for assistance.

Troubleshooting

The following simple solutions may help you should your OSIM® uSqueeze XE DUO FOOT not function properly. Please refer to the message chart below for reference.

Issue	Solution
The remote control does not work.	Change the batteries when necessary. Ensure the batteries are placed correctly. Ensure no obstacles between the remote control and the sensor.
The light for heating function is on but there is no heat.	Heat will automatically turn off for the safety of the user. Please wait for the heat to cool down before using the heat function.
Cleaning operations: the massager is not working. Use the manual massage function.	If the massager is not connected to the power supply, please check the power cord is connected to the power supply. If the massager is not working, please contact us for assistance.
Auto massage function is not working.	Please ensure the power switch is switched on.
Rubber noise	Please ensure the rubber is not stuck. Please contact us for assistance if the problem persists.

Product Specifications

Description	Specification
Model	OZ1007
Power source	220-240V
Frequency	50/60Hz
Power output	60W
Power consumption	60W
Dimensions(Length/Width/Height)	(Random Pieces)
Weight	9.1KG

Contact Us

SINGAPORE
OSIM International Pte Ltd
No. 15 Jalan Tenggiri Phase 2 Pioneer
Singapore Industrial Park
Singapore 619965
Tel: +65 6896 7777
Fax: +65 6896 7677

MALAYSIA
OSIM International Sdn Bhd
Unit 1-01, Level 1, Tower 1
Avenue 3, Bangsar South
No. 8, Jalan Kerinchi
59200 Kuala Lumpur
Tel: +603 2282 7777
Fax: +603 2282 7677

HONG KONG
OSIM International Trading (Hong Kong) Limited
Unit 1, 2/F, Tower 1, Enterprise Square Five
38 Wang Chiu Road
Kowloon Bay
Kowloon, Hong Kong
Tel: +852 2976 3777
Fax: +852 2976 3700

THAILAND
OSIM International (Thailand) Co., Ltd.
Unit 1, 2nd Floor, Tower 1
Ocean Tower 1 Building
No. 75/1 Soi Sukhumvit 19 (Wattana)
Sukhumvit Road
Klongtoey Nua, Wattana
Bangkok 10110
Tel: +66 2 207 8999 (107 lines)
Fax: +66 2 207 8900

TAIWAN
OSIM International Taiwan Limited
10F, No. 97, Sec. 2, Dunhua South Road
Da-An District
Taipei City 106
Tel: +886 2 2700 8168
Fax: +886 2 2700 8166

CHINA (P.R.C.), SHANG
OSIM(China) Trading Co.,Ltd.
Unit 1101, Tower 1, Shanghai Kerry Everbright City
No.218 Tianmu West Road
Shanghai
Tel: +86 21 6113 3000 (107 lines)
Fax: +86 21 6113 3001

MACAU
OSIM International Macau Ltd.
Unit No.: A, 19th Floor
Macau Landmark
No. 555 Avenida da Amizade
Macau
Tel: +853 2878 3777
Fax: +853 2878 3700

OSIM

uSqueeze XE DUO FOOT

说 明 书
OZ1007

目录

安全说明 2
保修事项 4
主机及附件 5
控制器图示 6
产品特点 8
产品保养 9
故障排除 10
产品规格 11
联系我们 12

安全说明

一、使用环境

- 请勿将此按摩器用于说明书所述之外的用途，以及特殊的情况。
- 请勿在浴室使用此按摩器。
- 请勿将此按摩器放置或存放在可能掉落或被拉入浴缸的地方。
- 请勿将此按摩器放入水中。
- 请勿在户外使用此按摩器。
- 请勿在使用氧气或喷雾产品的地方使用此按摩器。

二.不适宜的用户

在使用此按摩器前，请检查以下的医疗禁忌症或情况。

- 患有心脏病
- 孕妇
- 癌症

三、产品不适合下列情况下的使用

- 按摩器一旦损坏请勿使用。
- 如电源线损坏，必须由专业人员更换，避免发生危险。
- 请勿在站立时使用此产品。
- 请勿在躺下时使用此产品。
- 请勿在睡觉时使用此产品。
- 请勿在酒后使用此产品。
- 请勿将此按摩器用于其他用途。

四、注意事项和警告。

- 不使用时，请将插头拔离墙插座。

安全说明

- 请勿使用未经OSIM推荐的附件。
- 请勿使用电线或插头已损坏的按摩器。如按摩器无法正常运作或已摔落，请将其送回服务中心检查和维修。
- 请勿将按摩器放置在户外，或掉入水中。
- 请勿将头发、松散衣物、手指和身体各部位靠近运动中的部件。
- 请勿将电源线靠近热表面。
- 请勿将物体插入或放入任何开口中。
- 请勿拉着电源线搬运按摩器。
- 请勿在盖着被子的情况下使用按摩器。

五、注意事项和警告。

- 请依照本说明书的指示使用本产品，如有疑问请咨询医生。
- 如果您正在使用心脏起搏器或其他电子设备，请在使用本产品前咨询您的医生。电磁波可能会影响心脏起搏器或其他电子设备的运作。
- 请妥善保管说明书，以便在使用过程中随时查阅。将产品转让给新的使用者或用户时，请一并转交说明书。
- 请妥善保管包装，以便储存或运输。
- 请勿将本产品用于说明书所述以外的用途。
- 如果产品已经损坏，请勿使用。

保修声明

- 保修不可转让。
- 保修仅适用于在osimcare.com、osim.com或OSIM新加坡授权零售店购买的产品。
- 所有材料更换，包括但不限于损坏的数字面板/主PCB，将收取50元服务费（须缴纳现行消费税）。
- 保修不涵盖因意外误用/滥用和正常操作导致的损坏和磨损。
- 保修不涵盖因未经授权的非OSIM授权服务中心维修而造成的损坏。
- 保修不涵盖因不合理、不必要或其他虚假陈述而造成的损坏。
- 保修不涵盖因正常使用而耗尽的任何耗材和/或正常磨损。
- 保修不涵盖因包装不当或运输方式不当而造成的损坏。

主机及附件

1. 小腿按摩器
2. 主控制器
3. 电源线
4. 足部按摩器连接器
5. 足部按摩器
6. 足部按摩器套（请注意，足部按摩器套不可清洗。）
7. 遥控器

控制器图示

注释：若要使用本功能时请将其关闭，以确保您的安全。

控制器图示

电源/ON/OFF
按下"电源/ON/OFF"按钮时，设备将自动启动默认按摩功能。**开始按摩前，请确保设备处于默认位置。**任何移动都将中断按摩过程。

自动/SAVE（保存）
按下"自动/SAVE（保存）"按钮，即可在"全背部"、"上背部"和"下背部"按摩功能之间切换。

全背部
按下"全背部"按钮，指示灯将亮起。此模式将为您带来从颈部到小腿的按摩体验，仿佛是治疗师的双手在为您按摩。

上背部
按下"上背部"按钮，指示灯将亮起。此模式将为您带来从颈部到上背部的按摩体验。

下背部
按下"下背部"按钮，指示灯将亮起。此模式将为您带来从上背部到小腿的按摩体验。

点穴
按下"点穴"按钮，指示灯将亮起。选择按摩功能后，您可以选择颈部、背部、肩部或小腿。

振动
按下"振动"按钮，可激活脚部、小腿和大腿的振动。再次按下即可关闭振动。

控制器图示

加热
按下"加热"按钮，可开启或关闭按摩加热功能。与强度和速度功能搭配使用，可自定义按摩体验。加热功能将在连续使用30分钟后自动关闭。

强度
按下"强度"按钮，可更改气压范围。根据个人喜好调节气压大小。

停止
按下"停止"按钮，可暂停按摩，指示灯将亮起。

产品保养

储存

- 将按摩器存放在包装盒内或干燥、阴凉的安全场所。
- 将按摩器远离锋利边缘或需要清洁的角落。
- 将按摩器远离热源和明火。
- 请勿将按摩器存放在阳光直射的地方。
- 请勿将按摩器存放在极端温度环境下。

清洁

- 使用干燥无液体的方式清洁按摩单元。
- 请勿使用任何清洁剂或溶剂。
- 请勿将按摩器浸入水中或任何其他液体中。
- 请勿将本产品放置在水或任何液体附近。
- 如果外套已损坏或严重污渍，请勿使用本产品，请联系我们以获取新外套进行更换。

注意事项

- 请勿在将电源线插入控制单元时存放设备。
- 请勿在足部按摩器和小腿按摩器被拉出时存放设备。
- 请勿在拉出足部按摩器和小腿按摩器时对其施加压力。
- 请勿在足部按摩器和小腿按摩器被拉出时存放设备。
- 请勿尝试自行维修按摩器，请联系我们寻求协助。

故障排除

以下简单的解决方案可能会帮助您解决OSIM® uSqueeze XE DUO FOOT无法正常运作的问题。请参考下面的信息表。

问题	解决方案
遥控器无法使用。	必要时更换电池。确保电池安装正确。确保遥控器和感应器之间没有障碍物。
加热功能的指示灯亮起，但没有热量。	为了用户安全，加热功能将自动关闭。请等待加热器冷却后再使用加热功能。
清洁操作：按摩器不工作。使用手动按摩功能。	如果按摩器未连接电源，请检查电源线是否已连接到电源。如果按摩器不工作，请联系我们寻求协助。
自动按摩功能不工作。	请确保电源开关已打开。
橡胶噪音	请确保橡胶未卡住。如果问题仍然存在，请联系我们寻求协助。

产品规格

说明	规格
型号	OZ1007
电源	220-240V
频率	50/60Hz
功率	60W
耗电量	60W
尺寸（长/宽/高）	随机包装尺寸
重量	9.1KG

联系我们

SINGAPORE
OSIM International Pte Ltd
No. 15 Jalan Tenggiri Phase 2 Pioneer
Singapore Industrial Park
Singapore 619965
Tel: +65 6896 7777
Fax: +65 6896 7677

MALAYSIA
OSIM International Sdn Bhd
Unit 1-01, Level 1, Tower 1
Avenue 3, Bangsar South
No. 8, Jalan Kerinchi
59200 Kuala Lumpur
Tel: +603 2282 7777
Fax: +603 2282 7677

HONG KONG
OSIM International Trading (Hong Kong) Limited
Unit 1, 2/F, Tower 1, Enterprise Square Five
38 Wang Chiu Road
Kowloon Bay
Kowloon, Hong Kong
Tel: +852 2976 3777
Fax: +852 2976 3700

THAILAND
OSIM International (Thailand) Co., Ltd.
Unit 1, 2nd Floor, Tower 1
Ocean Tower 1 Building
No. 75/1 Soi Sukhumvit 19 (Wattana)
Sukhumvit Road
Klongtoey Nua, Wattana
Bangkok 10110
Tel: +66 2 207 8999 (107 lines)
Fax: +66 2 207 8900

TAIWAN
OSIM International Taiwan Limited
10F, No. 97, Sec. 2, Dunhua South Road
Da-An District
Taipei City 106
Tel: +886 2 2700 8168
Fax: +886 2 2700 8166

CHINA (P.R.C.), SHANG
OSIM(China) Trading Co.,Ltd.
Unit 1101, Tower 1, Shanghai Kerry Everbright City
No.218 Tianmu West Road
Shanghai
Tel: +86 21 6113 3000 (107 lines)
Fax: +86 21 6113 3001

MACAU
OSIM International Macau Ltd.
Unit No.: A, 19th Floor
Macau Landmark
No. 555 Avenida da Amizade
Macau
Tel: +853 2878 3777
Fax: +853 2878 3700