

STANDARD OPERATING PROCEDURE
STAN MAYFIELD BIOREFINERY PILOT PLANT

Document No.: SOP-3225 Revision: September 21th, 2012

TITLE: Secondary Propagator 3B VS-3203B

AUTHOR: Marco Fernandez DATE: September 21th, 2012

APPROVALS: Process Change Committee DATE: July 31st, 2013

A. Scope

This SOP describes the procedure to clean, sterilize, and operate the Secondary Propagator 3B VS-3203B during normal operation in order to propagate the seed and inoculate the fermentors.

B. Safety and Training Requirements

Refer to UF lab safety policies regarding equipment listed in section D below before starting any process work.

Refer to UF Biosafety guidelines whenever handling biological cultures/genetically modified organisms.

Review the location of fire extinguishers, fire blankets, safety showers, spill cleanup equipment and protective gear before beginning any process work.

When performing any work above 6 feet from the ground, make sure to properly use a harness to prevent injury in case of a fall.

During operations in the plant, the following safety gear will be utilized at all times:

- Safety Goggles
- Protective Gloves
- Hard Hat

C. Related Documents and SOPs

- 1. Experimental Plan
- 2. Ethanol Concentration SOP-0500
- 3. Sugar, Organic Acids and Inhibitors Concentration SOP-0505
- 4. Viable Plate Count SOP-0507
- 5. Sampling SOP-0511
- 6. Optical Density Measurement with Spectrophotometer SOP-0513
- 7. pH Measurement SOP-0514
- 8. Plant pH Probe Calibration SOP-0519



STANDARD OPERATING PROCEDURE STAN MAYFIELD BIOREFINERY PILOT PLANT

TITLE: Secondary Propagator 3B VS-3203B

- 9. C5 Hydrolysate Storage SOP-2135
- 10. Media Preparation SOP-2155
- 11. Primary Propagator 2A SOP-3210
- 12. Primary Propagator 2B SOP-3215
- 13. Fermentation Tank A SOP-3230
- 14. Fermentation Tank B SOP-3235
- 15. Fermentation Tank C SOP-3240
- 16. Trace Elements Storage SOP-3250
- 17. Beer Well SOP-4000
- 18. Decanter Operation SOP-4905
- 19. Phosphoric Acid System Operation SOP-8110
- 20. Clean In Place (CIP) SOP-8205
- 21. Antifoam System Operation SOP-8310
- 22. Lime Slurry System Operation SOP-8405
- 23. Base B System Operation SOP-8565
- 24. Refrigeration System Operation SOP-9210
- 25. Steam Supply System Operation SOP-9305
- 26. Air System Operation SOP-9405
- 27. UV Water System Operation SOP-9555
- 28. Hot Water System Operation SOP-9605
- 29. Potable Water System SOP-9705

D. Detailed Procedure

D.1 Vessel Preparation

- 1. At the HMI ensure that the Secondary Propagator 3B is clean, empty, at atmospheric pressure, and ready for operation.
- 2. Make sure that the Air System is ready according to Air system SOP-9405.
- 3. Make sure that the Potable Water System is ready according to Potable Water System SOP-9705.
- 4. Make sure that the Steam Supply System is ready according to Steam System SOP-9305.

STANDARD OPERATING PROCEDURE STAN MAYFIELD BIOREFINERY PILOT PLANT

TITLE: Secondary Propagator 3B VS-3203B

- 5. Make sure the cooling water is operational according to the Refrigeration System SOP-9210.
- Make sure the hot water is operational according to the Hot Water System Operation SOP-9605.
- 7. Instrument Calibration:
 - a. Pressure Measurement
 - i. Verify that the local indicator is reading ambient conditions (PIT-3203B-33).
 - NOTE: Ambient pressure readings vary per indicator. It's critical to obtain an understanding of what value equals ambient pressure before proceeding with operation. The values can be found on a sheet in the control room.
 - ii. On the HMI, verify the pressure indicator (PI-3203B-33) is working properly and that the pressure value is the same as local indicator.
 - b. Temperature Measurement
 - i. On the HMI, verify that temperature probe (TIC-3203B-10A) is reading current ambient conditions.
 - ii. Verify that the reading of local probe (TI-3203B-18) is the same as displayed on the HMI.
 - c. Vessel Level Measurement
 - i. On the HMI, verify that level indicator LI-3203B-03 is reading zero level.
 - ii. Configure the following valves to the next position to ensure there is no liquid in the vessel:
 - 1) Close valves: 3204-V-32 and V-35.
 - 2) Open valves: 3204-V-56, V-60, V-30, V-33 and V-34.
 - d. pH Measurement
 - i. Calibrate pH probes AE-3203B-01A and AE-3203B-01B according to the Plant pH Probe Calibration SOP-0519.
 - ii. Verify that the pH readings after calibration are the same as displayed on the HMI tag AIC-3203B-01.
- 8. Verify that all side ports on the vessel are filled and secure.
- 9. At the HMI, switch the temperature control TIC-3203B-10B to MANUAL, the OUTPUT to -5 and mode to SIP.
- 10. Verify that the jacket does not have hot/cooling water flowing through it by ensuring that XV-3203B-29, XV-3203B-30, XV-3203B-31 and XV-3203B-32 are closed.

STANDARD OPERATING PROCEDURE STAN MAYFIELD BIOREFINERY PILOT PLANT

TITLE: Secondary Propagator 3B VS-3203B

- 11. Verify that the jacket is at ambient temperature and pressure using PI-3203B-16 and TI-3203B-17.
- 12. Verify the initial valve settings according to the Table 1.

Table 1.Initial valve positions settings.

Line	Application	Valve	Position	Check
CIP Supply	Slurry line cleanse	3204-V-01	Closed	
	Slurry line cleanse	3204-V-02	Closed	
	Spray Ball Valve	3204-V-57	Closed	
	Spray Ball Valve	3204-V-58	Closed	
	Vent line cleanse	3204-V-61	Closed	
	Tank cleanse	3204-V-14	Closed	
UV Sterilizer	To propagator 3B	3204-V-04	Closed	
Primary Propagator 2A	To tank inlet	3204-V-07	Closed	
	To tank inlet	3204-V-32	Closed	
Primary Propagator 2B	To tank inlet	3204-V-09	Closed	
C5 Pump	To tank inlet	3204-V-16	Closed	
Phosphoric Acid	To tank inlet	3204-V-18	Closed	
Vent	Vent valve	3204-V-56	Open	
	To Beer Well	3204-V-60	Closed	
Hydrolyzate pH Adjust	To tank inlet	3204-V-03	Closed	
Trace Metals	To tank inlet	3204-V-17	Closed	
	To tank inlet	3204-V-19	Closed	
Sterile Air	Pressure indicator	3204-V-10	Open	
	To tank inlet	3204-V-11	Closed	
	To the Vent line	3204-V-12	Closed	
	Vacuum relief valve	3204-V-15	Closed	
	Vacuum relief valve	3204-V-64	Closed	
	To tank inlet	3204-V-20	Closed	
	To tank inlet	3204-V-23	Closed	
Vessel Jacket	High Point Vent	3204-V-54	Open	
	Recirculation	3204-V-26	Closed	
	Recirculation	3204-V-55	Closed	
	Recirculation	3214-V-05	Open	

STANDARD OPERATING PROCEDURE
STAN MAYFIELD BIOREFINERY PILOT PLANT

TITLE: Secondary Propagator 3B VS-3203B

L. Secondary Propagator 3D V3-3203B						
	Recirculation	3214-V-06	Open			
	Recirculation	3214-V-08	Open			
	Pressure indicator	3204-V-25	Open			
	Drain	3204-V-29	Open			
	Drain	3204-V-27	Open			
	To steam Trap	3204-V-28	Open			
Low Pressure Steam	Pressure Indicator	3204-V-50	Open			
	To the Jacket	3204-V-52	Closed			
	Tank bottom inlet	3204-V-37	Closed			
	Spare valve	3204-V-48	Closed			
	To Sample Port	3204-V-51	Open			
	To Sample Port	3204-V-22	Closed			
	Pressure Indicator	3204-V-49	Open			
	Spare valve	3204-V-38	Closed			
	To the tank	3204-V-65	Open			
	To steam Trap	3204-V-39	Open			
Cooling / Hot water	Cooling / Hot Water	3204-V-53	Closed			
	Return					
Vacuum Pump	Vacuum System	3204-V-59	Closed			
Base B	To tank inlet	3204-V-62	Closed			
Transfer line	Bottom Drain	3204-V-34	Open			
	Bottom Drain	3204-V-33	Open			
	Bottom Drain	3204-V-30	Open			
	To Fermentors	3204-V-35	Closed			
	To Fermentor A/B	3204-V-44	Closed			
	To Fermentor A	3204-V-46	Closed			
	To Fermentor B	3204-V-45	Closed			
	To Fermentor C	3204-V-42	Closed			
	Spare line	3204-V-40	Closed			

D.2Sterilization (SIP)

- 1. Make sure the Secondary Propagator 3B (VS-3203B) jackethas been drained through the valves 3204-V-27and V-29 by visual inspection.
- 2. Add Low Pressure Steam to the tank jacket by:
 - a. Close the Jacket High Point Vent valve 3204-V-54.
 - b. Open the steam supply valve 3204-V-52.

Page **5** of **17**



STANDARD OPERATING PROCEDURE STAN MAYFIELD BIOREFINERY PILOT PLANT

TITLE: Secondary Propagator 3B VS-3203B

- c. Wait until the steam comes out through drain valve 3204-V-29.
- d. Open the steam trap T1-3204-03 and close the drain valve 3204-V-29.
- e. Verify steam pressure in PI-3203B-15 is 15 ± 2 PSI. If not, contact supervisor.
- 3. Add Low Pressure Steam to the tank by:
 - a. Open the valve 3204-V-37 and verify the pressure in PI-3203B-20 is $\frac{27 \pm 2}{100}$ PSI.
 - b. Close valve 3204-V-34 and open steam trap T1-3204-04.
 - c. On the HMI, set sterilization temperature on TIC-3204B-10B to 250 °F (121 °C), and set MODE to AUTO.
- 4. When the pressure inside the tank reaches 5 PSI, remove the residual air using the Vacuum Pump by:
 - a. On the HMI, stop steam to the tank by setting MODE to MANUAL on TIC-3203B-10B and OUTPUT to -5.
 - b. Close the tank drain valve 3204-V-30.
 - c. Open the vent valves to the vacuum pump (PV-3201) 3204-V-56 and V-59.
 - d. At the HMI,open solenoid valve XV-3201-01 and turn on the vacuum pump (PV-3201).
 - e. At the HMI, monitor the pressure on PI-3203B-33 until it reaches -10 PSI.
 - f. At the HMI, turn off the vacuum pump (PV-3201) and close the solenoid valve XV-3201-01.
 - g. Close the vacuum line valve 3204-V-59.
 - h. On the HMI, set MODE back to AUTO on TIC-3203B-10B.
 - i. Once the pressure on PI-3203B-33 is above 0 PSI, open the tank drain valve 3204-V-30.
- 5. Once the tank temperature reaches 250 °F (121 °C), maintain the temperature for 60 minutes.
- 6. After sterilization is completed, cool the tank by:
 - a. At the HMI, stop steam to the tank by setting MODE to MANUAL on TIC-3203B-10B and OUTPUT to -5.
 - b. Close the steam supply jacket valve 3204-V-52.
 - c. Relieve pressure in the jacket by slowly opening jacket drain valve 3204-V-29.
 - d. Open the jacket high point vent valve 3204-V-54.
 - e. After the jacket has been drained, close the valves 3204-V-27, V-29 and V-54.
 - f. Open valve 3204-V-53.
 - g. At the HMI, switch temperature control TIC-3203B-10B to NORMAL.

Page **6** of **17**

Lab comp 5/8/2013 3:59 PM

Deleted: 30

Deleted: is open



STANDARD OPERATING PROCEDURE STAN MAYFIELD BIOREFINERY PILOT PLANT

TITLE: Secondary Propagator 3B VS-3203B

- h. At the HMI, set the temperature control at TIC-3203B-10A to 98.6 °F (37 °C).
- i. At the HMI, set MODE to AUTO on TIC-3203B-10A and monitor the pressure and temperature.
- At the HMI, monitor the tank pressure and temperature at PI-3203B-33 and TIC-3203B-10A respectively.
- k. When the pressure drops below 10 PSI, open the sterile air valves 3204-V-15 and V-64 to add air to the tank via vacuum breaker.
- I. Once the tank temperature reaches 98.6 °F (37 °C):
 - Open valves 3204-V-26 and V-55 to Secondary Propagator 3B Jacket Pump.
 - ii. At the HMI, start Secondary Propagator 3B Jacket Pump (PT-3213).
- 7. Begin normal operation.

D.3 Operation of Secondary Propagator 3B

D.3.1. Startup

- 1. Make sure the Base B system is functioning properly according to SOP-8565.
- 2. Make sure the Phosphoric Acid system is functioning properly according to SOP-8110.
- 3. Make sure the Antifoam system is functioning properly according to SOP-8310.
- 4. Make sure the UV Water system is functioning properly according to SOP-9555.
- 5. Make sure the Trace Elements Storage system is functioning properly according to SOP-3250.
- 6. Make sure the C5 storage system is ready according to the C5 Hydrolysate Storage SOP-2135
- 7. If needed, make sure the Lime Slurry System Operation is functioning properly according to SOP-8405.
- 8.
- 9. Turn on the air sparger by:
 - a. Open valve 3204-V-11, V-20 and V-23.
 - b. Set the desired sterile air flow rate according to the Experimental Plan using the rotameter FI-3203B-26.
 - c. Monitor the air pressure in PI-3203B-08; should be approximately 30 PSI.
- 10. Close the valves to the Vacuum Breaker 3204-V-15 and V-64.

Lab comp 5/8/2013 4:01 PM

Moved down [1]: Close the valves to the Vacuum Breaker 3204-V-15 and V-64.

Lab comp 5/8/2013 4:01 PM

Moved (insertion) [1]



STANDARD OPERATING PROCEDURE STAN MAYFIELD BIOREFINERY PILOT PLANT

TITLE: Secondary Propagator 3B VS-3203B

- 11. Start Antifoam control by:
 - a. Ensure the antifoam is ready to transfer according to the Antifoam System Operation SOP-8310.
 - b. On the HMI, turn on antifoam control by switching the controller to AUTO.
- 12. Make sure main drain valve 3204-V-30 is closed.
- 13. Open valves 3204-V-56, -60 to the Beer Well vent line.
- 14. Add the specified amount of C5 hydrolysate according to the Experimental Plan by:
 - Make sure C5 hydrolysate is ready to transfer according to C5 Hydrolysate Storage SOP-2135.
 - b. Open the valves 3204-V-16 and 2103-V-19 to open the transfer line.
 - Start adding C5 hydrolysate according to C5 Hydrolysate Storage SOP-2135 and the Experimental Plan.
 - d. At the HMI, set the flow rate of the C5 Pump (PM-2108) according to the Experimental Plan using SIC-2108-04 and switch to AUTO.
 - e. At the HMI monitor the tank level using LI-3203B-03, and stop the addition of C5 hydrolysate when it reaches the desired level as determined by the Experimental Plan.
- 14. Add UV Water necessary for operation by:
 - a. Open the valve 3204-V-04 to add UV water through the side of the tank.
 - b. Once the volume reaches 20%, start the tank agitation by turning on XS-3203B-05 and setting SIC-3203B-05 to 100% in MANUAL.
 - c. On the HMI, monitor the liquid level using LI-3203B-03.
 - d. Close the UV Water valve 3204-V-04 when the desired level is reached as determined by the Experimental Plan.
- 15. Close valve 3204-V-16 to close the C5 line going into the tank.
- 16. Turn on the pH control by:
 - a. Open valves 3204-V-18 and V-62.
 - b. On the HMI, set the pH to §.0 in AIC-3203B-01 and switch to AUTO.
 - c. Once the pH is at set point, turn off the pH control at the HMI by switching to MANUAL and setting the OUTPUT to -5 in AIC-3203B-01.
 - d. Take a sterile sample using sample valve SSP-3204-01 and steam valve 3204-V-22 according to Sampling SOP-0511.
 - e. Measure the pH of the sample according to pH Measurement SOP-0514 to corroborate the field measurement.

Page **8** of **17**

Lab comp 5/8/2013 4:17 PM

Deleted: <#>On the HMI, turn on Antifoam Pump 1 (PT-3214).

-ab comp 5/8/2013 4:18 PM

Deleted: 30 %

Lab comp 5/8/2013 4:19 PM

Deleted: and setting it to AUTO

Lab comp 5/8/2013 4:20 PM

Deleted: <#>On the HMI, open the valve XV-3203B-23.

Christopher R. Self 11/4/2014 10:57 AM

Deleted: 9



STANDARD OPERATING PROCEDURE STAN MAYFIELD BIOREFINERY PILOT PLANT

TITLE: Secondary Propagator 3B VS-3203B

- 17. Maintain the conditions in the tank for $22 \pm 2 h$.
- 18. Open the valves 3204-V-17 and V-19 for the addition of the trace metals and magnesium sulfate/sodium metabisulfite solutions.
- 19. Add the specified amount of Trace Metals and Magnesium Sulfate Sodium Metabisulfite solutions from the 2 gal Trace Metals Tank (TS-3201) and the 2 gal MgSO₄ Storage Tank (TS-3202) respectively according to the Trace Elements Storage SOP-3250 and the Experimental Plan by:
 - a. At the HMI, set the speed of the pump using SIC-3203-02 (according to the experimental plan), switch the pump controller SIC-3203-02 to AUTO, and turn on the Trace Metals Pump 2 (PT-3203).
 - b. At the HMI, monitor the pressure in PI-3203-01 and PI-3203-04.
 - c. At the HMI, turn off the Trace Metals Pump 2 (PT-3203) when the transfer is completed.
- 20. Close the valves 3204-V-17 and V-19 in the Secondary Propagator 3B.
- 21. Start pH control by:
 - a. On the HMI, turn on the pH control by setting the pH to 6.3 in AIC-3203B-01 and switching to AUTO.
 - b. Once the pH reaches the set-point, take a sterile sample using sample valve SSP-3204-01 and the steam valve 3204-V-22 according to Sampling SOP-0511.
 - c. Measure the pH of the sample according to pH Measurement SOP-0514 to corroborate the field measurement.
 - d. If the pH is not 6.3 \pm 0.20, contact the supervisor.
- 22. Close drain valve 3204-V-33.
- 23. In order to inoculate the Secondary Propagator 3B using Primary Propagator 2A:
 - a. Make sure Primary Propagator 2A is ready to provide the culture seed according to Primary Propagator 2A SOP-3210.
 - b. Open the valves 3204-V-07, V-30 and V-32.
 - c. Transfer the contents of the Primary Propagator 2A to Secondary Propagator 3B according to Primary Propagator 2A SOP-3210.
 - d. Close the valves 3204-V-07, V-30 and V-32 after inoculation.
 - e. Record date and time of inoculation in propagator log book.
- 24. In order to inoculate the Secondary Propagator 3B using Primary Propagator 2B:
 - a. Make sure Primary Propagator 2B is ready to provide the culture seed according to Primary Propagator 2B SOP-3215.

Page **9** of **17**

Lab comp 5/8/2013 4:21 PM

Deleted: G

Lab comp 5/8/2013 4:23 PM

Lab comp 5/8/2013 4:23 PM

Deleted: ⊺

STANDARD OPERATING PROCEDURE STAN MAYFIELD BIOREFINERY PILOT PLANT

TITLE: Secondary Propagator 3B VS-3203B

- b. Open the valves 3204-V-09, V-30 and V-32.
- c. Transfer the contents of Primary Propagator 2B to Secondary Propagator 3B according to Primary Propagator 2B SOP-3215.
- d. Close the valves 3204-V-09, V-30 and V-32 after inoculation.
- e. Record date and time of inoculation in propagator log book.
- 25. Take a sterile sample using sample valve SSP-3204-01 and the steam valve 3204-V-22 according to the Sampling SOP-0511.
 - a. Measure sugars, organic acids, and inhibitors concentration according to SOP-
 - b. Measure ethanol according to Ethanol Measurement SOP-0500.
 - c. Measure the Optical Density according to SOP-0513.
 - d. Perform viable plate counts according to SOP-0507.

D.3.2. Operation

- 1. On the HMI, monitor the temperature, pH and agitation speed regularly in TIC-3203B-10A, AIC-3203B-01 and SIC-3203B-05 respectively.
 - a. If the temperature, pH or agitation speed is out of normal ranges (as defined by the Experimental Plan), contact the supervisor.
- 2. Take sterile samples in 12 hour intervals using the sample port valve SSP-3204-01 and the steam valve 3204-V-22 according to the Sampling SOP-0511 and the Experimental Plan.
 - a. Measure sugars, organic acids and inhibitors concentration according to SOP-0505.
 - b. Measure ethanol concentration according to SOP-0500.
 - c. Measure the Optical Density according to SOP-0513.
 - d. Perform viable plate counts according SOP-0507.
- 3. Allow for fermentation to last 24 hours before proceeding to transfer the broth to the Fermentors A, B or C.

Deleted: in 6 h intervals

Deleted: e

D.3.3.Broth Contamination or Disposal



STANDARD OPERATING PROCEDURE STAN MAYFIELD BIOREFINERY PILOT PLANT

TITLE: Secondary Propagator 3B VS-3203B

- 1. In case that the Propagation is not carried out forward to Fermentation, transfer the contents to the Beer Well by:
 - a. Make sure the Beer Well is ready to receive the broth according to the Beer Well SOP-4600.
 - b. On the HMI, turn off the temperature control TIC-3203B-10A and pH control AIC-3203B-01 by switching to MANUAL and setting the OUTPUT to -5.
 - c. Turn off antifoam by switching the antifoam control to OFF.
 - d. Make sure valves 3204-V-40, V-42, and V-45 are closed.
 - e. Make sure valves 3205-V-06, V-07, V-08, V-09, V-10,V-31, V-32, V-36, V-39, V-40, V-41 and V-43 are closed in Fermentor A.
 - f. Open valves 3204-V-30, V-35, V-44 and V-46 in order to transfer the broth to the pipes of Fermentor A and then to Beer Well.
 - g. Open valves3205-V-11, V-29, V-35, V-38 and V-42 in Fermentor A.
 - h. At the HMI, turn on the Fermentor A Pump (PC-3204A) on XS-3204A-21.
 - i. Monitor the pressure in PI-3204A-22.
 - j. Transfer the broth to the Beer Well, and when the transfer is complete, turn off the Fermentor A Pump (PC-3204A) on the HMI (XS-3204A-21).
 - k. Set the valves back to their original positions.
- 2. Dispose of the material through the Beer Well and Decanter according to the SOP-4600 and SOP-4905 respectively.

D.3.4. Transfer to Fermentors A, B or C

- 1. On the HMI, turn off the temperature control TIC-3203B-10A and pH control AIC-3203B-01 by switching to MANUAL and setting the OUTPUT to -5.
- 2. Turn off antifoam by switching the antifoam control to OFF,
- 3. Open the valves 3204-V-30 and V-35.
- 4. Make sure Fermentors A, B or C are ready to receive the broth according to the Fermentation Tank A SOP-3230, Fermentation Tank B SOP-3235, or Fermentation Tank C SOP-3240 respectively.
 - a. In order to transfer the broth to Fermentor A, open the valves 3204-V-44 and V-46.

Lab comp 5/8/2013 4:26 PM

Deleted: control(XIC-3203B-27)

Lab comp 5/8/2013 4:30 PM

Deleted: control (XIC-3203B-27)

STANDARD OPERATING PROCEDURE STAN MAYFIELD BIOREFINERY PILOT PLANT

TITLE: Secondary Propagator 3B VS-3203B

- b. In order to transfer the broth to Fermentor B, open the valves 3204-V-44 and V- 45
- c. In order to transfer the broth to Fermentor C, open the valve 3204-V-42.
- 5. When the transfer is complete, close the valves 3204-V-30 and V-35.

D.4 Cleaning (CIP)

- 1. Make sure that the CIP system is ready according to CIP system SOP-8205.
- 2. Make sure the valves are set according to the Table 2.

NOTE: Before configuring these valves, ensure the CIP system is not supplying pressure to the CIP header but only to the CIP loops. If the CIP header is being pressurized, you must wait for the person who is using the CIP system to finish before you can continue.

Table 2. CIP initial valve positions settings

Secondary Propagator 3A System						
Line	Application	Valve	Position	Check		
CIP Supply	Slurry line cleanse	3204-V-01	Closed			
	Slurry line cleanse	3204-V-02	Open			
	Slurry line cleanse	3204-V-03	Closed			
	Spray Ball Valve	3204-V-57	Closed			
	Spray Ball Valve	3204-V-58	Closed			
	Vent line cleanse	3204-V-61	Open			
	Air Sparger	3204-V-14	Open			
UV Sterilizer	Slurry line cleanse	3204-V-04	Closed			
Primary propagator 2A	To tank inlet	3204-V-07	Closed			
	To tank inlet	3204-V-32	Closed			
Primary propagator 2B	To tank inlet	3204-V-09	Closed			
C5 Pump	To tank inlet	3204-V-16	Open			
Phosphoric Acid	To tank inlet	3204-V-18	Closed			
Vent	Vent valve	3204-V-56	Open			
	To Beer Well	3204-V-60	Closed			
Trace Metals	To tank inlet	3204-V-17	Closed	•		
	To tank inlet	3204-V-19	Closed			

STANDARD OPERATING PROCEDURE STAN MAYFIELD BIOREFINERY PILOT PLANT

TITLE: Secondary Propagator 3B VS-3203B

· · · · ·	agator 35 13 32035		
Base B	To tank inlet	3204-V-62	Closed
Sterile Air	Pressure indicator	3204-V-10	Open
	To tank inlet	3204-V-11	Closed
	To the Vent line	3204-V-12	Closed
	Vacuum relief valve	3204-V-15	Closed
	Vacuum relief valve	3204-V-64	Closed
	To tank inlet	3204-V-20	Open
	To tank inlet	3204-V-23	Closed
Low Pressure Steam	Pressure Indicator	3204-V-50	Open
	To the Jacket	3204-V-52	Closed
	Tank bottom inlet	3204-V-37	Closed
	Spare Valve	3204-V-46	Closed
	To Sample Port	3204-V-51	Closed
	To Sample Port	3204-V-22	Closed
	Pressure Indicator	3204-V-49	Open
Vacuum Pump	Vacuum System	3204-V-59	Closed
Transfer line	Bottom Drain	3204-V-33	Closed
	Bottom Drain	3204-V-34	Closed
	Bottom Drain	3204-V-30	Open
	To Fermentors	3204-V-35	Open
	To Fermentor A	3204-V-44	Open
	To Fermentor A	3204-V-46	Closed
	Spare line	3204-V-40	Closed
	To Fermentor B	3204-V-45	Closed
	To Fermentor C	3204-V-42	Closed

- 3. Clean Secondary Propagator 3B (VS-3203B) by:
 - a. If the broth was transferred to Fermentor A:
 - i. Verify valves 3205-V-11 and V-29 are open, and 3205-V-06 and V-32 are closed from Fermentor A.
 - ii. Open transfer valves 3205-V-35, V-38 and V-41 in Fermentor A.
 - iii. Make sure valves 3205-V-36, V-39, V-40, V-42 and V-43 are closed in Fermentor A.
 - iv. Allow for transfer from Secondary Propagator 3B to Fermentor A pump by opening valves 3204-V-46.
 - b. If the broth was transferred to Fermentor B:
 - i. Verify valves 3206-V-11 and V-29 are open, and 3206-V-06 and V-32 are closed from Fermentor B.



STANDARD OPERATING PROCEDURE STAN MAYFIELD BIOREFINERY PILOT PLANT

TITLE: Secondary Propagator 3B VS-3203B

- ii. Open transfer valves 3206-V-35, V-38 and V-41 in Fermentor B.
- iii. Make sure valves 3206-V-36, V-39, V-40, V-42 and V-43 are closed in Fermentor B.
- iv. Allow for transfer from Secondary Propagator 3B to Fermentor B pump by opening valve 3204-V-41.
- c. If the broth was transferred to Fermentor C:
 - i. Verify valves 3207-V-11 and V-29 are open, and 3207-V-06 and V-32 are closed from Fermentor C.
 - ii. Open transfer valves 3207-V-35, V-38 and V-41 in Fermentor C.
 - iii. Make sure valves 3207-V-36, V-39, V-40, V-42 and V-43 are closed in Fermentor C.
 - iv. Allow for transfer from Secondary Propagator 3B to Fermentor C pump by closing valve 3204-V-44 and opening valve 3204-V-42.
- 4. Set CIP system to deliver Rinse Water to drain by:
 - a. Make sure that the valves 8201-V-04 and V-30 are closed in the CIP system.
 - b. Make sure that the valve 8201-V-31 is open in the CIP system.
 - c. Slowly open valve 8201-V-20 and then closing valve 8201-V-21.
 - d. Turn on the respective fermentor pump (according to step D.4.3) at the HMI.
 - e. To rinse out the vent line, air sparger line and C5 line, let the CIP system run with the current valve configuration for 5 min.
 - i. Monitor the tank levelusing LI-3203B-03.
 - <u>ii.</u> If the level exeeds 15%, open valve 8201-V-21 and then close valve 8201-V-20 until the level of the tank reaches 0.1%.
 - iii. Slowly open valve 8201-V-20 and then close valve 8201-V-21 to continue with the rinse until the 5 min rinse is completed.
 - f.
 - g. Open CIP supply spray ball valves 3204-V-57and V-58.
 - h. Close CIP supply valves 3204-V-02, V-14 and V-61.
 - i. Open vent line valve 3204-V-60.
 - j. 🗼
 - k. Run the rinse cycle for an additional 15 min.
 - I. Open valve 8201-V-21 and then close valve 8201-V-20 and turn off the respective fermentor pump at the HMI.
- 5. Set CIP system to deliver Caustic solution by:
 - a. Close CIP supply spray ball valves 3204-V-57 and V-58.

Lab comp 5/8/2013 4:35 PM

Moved (insertion) [2]

Lab comp 5/8/2013 4:35 PM

Deleted: 10

ab comp 5/8/2013 4:35 PM

Deleted: utes

Lab comp 5/8/2013 4:35 PM

Moved up [2]: Turn on the respective fermentor pump (according to step D.4.3) at the HML.

Lab comp 5/8/2013 4:36 PM

Moved (insertion) [3]

Lab comp 5/8/2013 4:37 PM

Deleted: <#>After 10 minutes, open valve 8201-V-21 and then close valve 8201-V-20. Turn off the respective fermentor pump.

Lab comp 5/8/2013 4:36 PM

Moved up [3]: Open CIP supply spray ball valves 3204-V-57and V-58.

Lab comp 5/8/2013 4:37 PM

Deleted: <#>Re-set CIP system to deliver Rinse Water by slowly open valve 8201-V-20 and then closing valve 8201-V-21. ... [2]

Lab comp 5/8/2013 4:37 PM

Deleted: utes



STANDARD OPERATING PROCEDURE
STAN MAYFIELD BIOREFINERY PILOT PLANT

Document No.: SOP-3225 Revision: September 21th, 2012

TITLE: Secondary Propagator 3B VS-3203B

- b. Close vent valve 3204-V-60.
- c. Open CIP supply valves 3204-V-02, V-14 and V-61 to allow CIP solution into the C5 line, vent line and air sparger line respectively.
- d. Close 8201-V-31 and open 8201-V-04 to return CIP solution to the Dilute Caustic Tank.
- e. Slowly open valve 8201-V-13 and then close 8201-V-14.
- f. Turn on the respective fermentor pump (according to step D.4.3) at the HMI.
- g. To clean the vent line and air sparger line, let the CIP system run with the current valve configuration for 5 min.
 - i. Monitor the tank level using LI-3203B-03.
 - ii. If the level exeeds 15%, open valve 8201-V-14 and then close valve 8201-V-13 until the level of the tank reaches 0.1%.
 - iii. Slowly open valve 8201-V-20 and then close valve 8201-V-21 to continue with the rinse until the 5 min rinse is completed.
- h. Open CIP supply spray ball valves 3204-V-57 and V-58.
- i. Close CIP supply valves 3204-V-14 and V-61.
- j. Open vent line valve 3204-V-60.

k.

- I. Run the CIP system for an additional 15 min.
- m. Open valve 8201-V-14, then close valve 8201-V-13.
- n. Jurn off the respective fermentor pump at the HMI.
- 6. Set CIP system to deliver UV water by:
 - a. Close CIP supply spray ball valves 3204-V-57 and V-58.
 - b. Close vent valve 3204-V-60.
 - c. Open CIP supply valves 3204-V-02, V-14 and V-61 to allow UV Water going into the C5 line, vent line and air sparger line respectively.
 - d. Close valve 8201-V-04 and open valve 8201-V-30 to return UV water to the Rinse Tank.
 - e. Slowly open valve 8201-V-12.
 - f. Turn on the respective fermentor pump (according to step D.4.3) at the HMI.
 - g. To rinse the vent line, let the UV Water run with the current valve configuration for 5 min.
 - i. Monitor the tank levelusing LI-3203B-03.

Lab comp 5/8/2013 4:47 PM

Deleted: <#>Close valve 3204-V-35.

ah comp 5/8/2013 4:38 PM

Deleted: 10

Lab comp 5/8/2013 4:38 PM

Deleted: utes

Lab comp 5/8/2013 4:39 PM

Moved (insertion) [4]

Lab comp 5/8/2013 4:39 PM

Deleted: <#>After 10 minutes, open valve 8201-V-14 and then close 8201-V-13.

Lab comp 5/8/2013 4:39 PM

Moved up [4]: Open CIP supply spray ball valves 3204-V-57 and V-58.

ah comp 5/8/2013 4:39 PM

Deleted: -#>Re-set CIP system to deliverCaustic Water by slowly open valve 8201-V-13and then closing valve 8201-V-14.

Lab comp 5/8/2013 4:40 PM

Deleted: utes

Lab comp 5/8/2013 4:48 PM

Deleted: Close vlave 3204-V-35 and t

Lab comp 5/8/2013 4:52 PM

Deleted: 10

Lab comp 5/8/2013 4:52 PM

Deleted: utes



STANDARD OPERATING PROCEDURE STAN MAYFIELD BIOREFINERY PILOT PLANT

TITLE: Secondary Propagator 3B VS-3203B

- <u>ii.</u> If the level exeeds 15%, close valve 8201-V-12 until the level of the tank reaches 0.1%.
- iii. Slowly open valve 8201-V-12 to continue with the rinse until the 5 min rinse is completed.
- h. Open CIP supply spray ball valves 3204-V-57 and V-58.
- i. Close CIP suppy valves 3204-V-02, V-14 and V-61.
- j. Open vent line valve 3204-V-60.

k.

- I. Run the CIP system for an additional 15 min.
- m. Close valve 8201-V-12 and turn off the respective fermentor pump at the HMI.
- q. Close the CIP supply spray ball valves 3204-V-57 and V-58.
- r. Once the tank is empty, close the valve 3204-V-35.
- 7. Close the valve 3204-V-20.
- 8. Close main drain valve 3204-V-30.
- 9. Secondary Propagator 3B is ready for sterilization.

E. Data Archival and Analysis

Date of inoculation:

Time of inoculation:

Experimental Plan Number:

Date	Time of Day	Time Elapsed	Temp (°F)	рН	Agitation (%)	Air flow rate (L/min)	Comments
•							

Lab comp 5/8/2013 4:54 PM

Moved (insertion) [5]

Lab comp 5/8/2013 4:54 PM

Deleted: <#>Close valve 8201-V-12.

Lab comp 5/8/2013 4:54 PM

Moved up [5]: Open CIP supply spray ball valves 3204-V-57 and V-58.

Lah comp 5/8/2013 4:54 PM

Deleted: <#>Re-set CIP system to deliver UV water by slowly opening valve 8201-V-1....[4]

Lab comp 5/8/2013 4:54 PM

Deleted: utes



STANDARD OPERATING PROCEDURE STAN MAYFIELD BIOREFINERY PILOT PLANT

TITLE: Secondary Propagator 3B VS-3203B

Take notes of all calculations and measurements. Store the data obtained in the appropriate Log Book.