Log Book

Campaign 06A

2014-1	1-05 Prep Day
07:50	Potable, Process, Steam, Chiller, Cooling Water ON
07:55	UV ON
08:20	Start SIP of 2B
08:28	2B @ -10, heating back up
	Kevin retightened all wire lugs on Boiler
08:40	Heating up Hot Water Tank
08:55	2B @ 250°F, hold for 1 ½ hours
09:06	Storage Tank now grounded
10:27	SIP of 2B done, cooling off, air to tank
13:13	Plan is to go 21% Hyd. (20 gallons), then Anti-foam+UV→43% (37 gallons total)
13:30	Running C5 through loop
13:33	Sending C5→2B, adding anti-foam
	Looks like overshot C5, ~24%, letting set
	Level went from 14% up to 24% in a second
	Ismael said OK
14:19	Level going crazy now, going to calculate
	Drop in C5 tank→23 gallons
14:28	Adding UV→2B
14:41	Stopped UV→~43, let sit to see where we end up
·	Bouncing 41→45%, going with average
15:12	Started Pump #5 for conditioning, set @ 75%
15:26	Sending Mix Tank (26%)→Hold (43%)
15:38	pH=8.06, shut off pump
	Taking sample from 2B for analysis because of trouble with level indicator
15:40	Testing Metal Detector
2014-1	
	Starting SIP 3B
	Drawing Vacuum
08:29	Vac Pump OFF
	PLAN FOR 3B: 200-gal Hyd. (22.6%)
	150 gal UV= Final of 36.8%
08:49	3B @ 250°F, hold for 90 minutes
	Overnight 2B Level settled 43%-45% Range
09:10	Steaming Nutrient Lines
09:52	Running separate air for metal detector
	With all air on not fast enough
10:42	SIP done on 3B, cooling down
10:53	"Airing" nutrient Lines→Ferm C.
13:51	Starting SIP of Liq
14:03	Drawing Vacuum on Liq
14:12	Vac Pump OFF-Stea ON
14:52	Liq @ 250°F
15:20	Liq @ 250°F again (Field valves opened too much, restarted timer)

```
Running Peroxide+water from drum through TMP#2
15:44 Sending C5→3B
16:00 Took break from addition, lost level reading.
16:09 Antifoam→3B (level reading 1.6%) using TMP#2
16:16 Resumed C5\rightarrow3B
16:50 Going extra 30 min on Liq SIP, one line got cold.
17:00 Inoculation of Prop 2B
       Pre: 43.2%; pH=6.73; T 98.5°F; 1.61 psi
       After: 44.7%; pH=6.63; T 99.8°F; 1.52 psi
17:13 C5 in loop, tank~20%, going to let sit for a few
17:15 3B Agitator ON, Level went up, let mix a while
17:21 SIP done on Lig, steam OFF, letting cool down on its own
17:30 C5 Pump OFF, possible plug on Recirc Line
18:00 3B now @ 31%, climbed 11%. Not liking it
18:29 3B annoying me [Jeff]. Stopped @ 20% and now it's continually rising. Calculation show ~190
       gallons moved there, so told to wait it out
       C5 Agitator on @ 1% Level, confirmed submerged, C5 Lines from 2B & 3B backflushed with UV
       Water
18:52 Adding UV\rightarrow3B (Even though level off,\rightarrowPER ISMAEL)
19:05 Conditioning C5 in 3B, we know the hydrolyzate is in there, working on correct water addition.
       Going to sample later.
19:27 3B @ 8.08, pump OFF
19:45 3B Sample taken for analysis, level has dropped from 37% to 30% in 25 min
Shift Change
20:35 Beerwell pump ON \rightarrow32 psi (in-line gauge)
20:53 Start steam to pH Adjustment Tank
       When reached 5 psi, turn on Vacuum pump
       When reached -10 psi, turn off Vacuum pump and start steam again
22:17 Reached 250°F in pH Adj. Tank
23:22 Start decanter pump @ 20% speed
2014-11-07
00:01 Increase speed of decanter pump to 25%.
00:05 Completed Sterilization. Connected hoses to the tank drain to sterilize.
00:56 Stopped steam going into pH Adj. Tank
01:00 Metal Detector now works reliably
05:00 Prop 2B Sample Taken
Shift Change
08:10 Recircing/heating CIP
08:40 WW 4.3 pH, adding Caustic 20 min
08:15 Sample pulled from 3B
09:00 Sample of 2B
       Level-43.9%; pH=6.30; T 98.5°F; 0.19 psi
09:15 16hr Sample 2B 3.31 g/L
10:04 WW pH~5.0 adding another 10 min
11:15 Still LOW pH, trying calcium hydroxide?
       From Lab into Sump with decanter running hard to keep up with caustic
       NOPE, all calcs show it would take two boxes
```

12:20	Put Caustic Straight from Barrel into Sump
13:07	BW→DFT, adjusted valve going into DFT, running heater in Auto~90%
13:19	WW only 5.34 after all this. Tank @ 87%
13:53	Topping 3B off with remaining water, level settled out overnight
14:02	WW going out
14:04	Nutrients→3B
14:05	3B Ready, 37%
14:13	Conveyors/steam ON to Metso
14:57	Beerwell pump OFF
	Burned up coupling.
15:22	Nutrents done.
15:30	Draining down Cooling Water Tank
15:37	Handling ON
15:42	Feeding Metso, started PSBLB @90→100%, PSF→100%
15:48	Sample of 2B; 6.76 g/L ~22hr
15:52	Inoculating 3B
	Level-40.0%; pH=6.69; (T)98.7°F; 11.54 psi
16:15	Started off Great, lost PSB TC in a HURRY. Feed OFF, steam. Had PSF→130%
16:30	Rinsing 2B (just a rinse, going to focus on Metso)
16:52	Sending BW→DFT
17:32	
17:42	BW Pump OFF (Looks like flow stopped, temp went up)
	Sprayball Rinse 2B
18:00	BW pumping again
18:10	Flipping header to Caustic through 2B Sprayballs
	Plan is to restart with PSBLB @ 80% and <u>SLOWLY</u> walk up.
	Chute/TC were totally plugged with PSF @ 130%
18:17	Caustic of C5 Line into 2B
18:28	Finisheding Caustic Cycle of 2B.
	Someone @ sightglass because level is stuck @ 19%
18:31	Stopped BW→DFT. DFT-85.7% BW-33.7%
40.47	Goal is BW below 30%
18:47	
	Steam blew past Blow-Back Damper ~ 58 psi, decision was to push biomass in and form plug.
10.50	PSBLB→80; PSF→100%
18:59	Starting UV Cycle of 2B
19:12	PSBLB→85% Big slug through system because of untreated (low temp/press) feed
19:30	I [Jeff] made the call to stop
19.50	Same thing was happening. It was [coming in big clumps]
Shift Ch	
19:42	Knifegate and C5 Discharger Overrides ON; Depressurizing Metso @ 17 psi
19:58	Venting some pressure from Liq Tank
20:02	Steam ON to Metso and PSB
20:02	All Metso Overrides OFF
20:20	pH probe ' B' 'A' put into Liq Tank
20:26	Metso T&P flatlining @ 296°F and 48 psi respectively
20.20	Having some minor issues with Metso Boiler apparently
	That the some thin is issues with the too boiler apparently

	Getting ODD bumps in PSF current too-Probably Biomass
20:51	Metso @ 107 psi, PSB LBs ON @ 70%; Feeding Metso
20:53	PSB LBs→60%; Compromise!
20:56	PSF→95→90%
21:00	FBLBs ON @ 80→50%
	Leaking steam from Bottom Knifegate
21:03	Metso T&P bouncing back now; FBLBs→75%
21:14	Liq Tank Temp Control→'Normal'→Auto @ 150°F Set Point
21:15	Liq Tank Temp Control→SIP
	PSB TC Backplate OFF and OPEN
21:16	Work being done on Liq Tank Jacket lines
	PSF→87%
	FBLBs→85%
	FBLBs → 100%; PSF → 85%
21:24	Metso at Temp and Pressure!
	Prop 3B pH Control ON @6.42SP; Base B Pump#8 @ 45%
	Liq Tank Temp Control→"Normal" in Auto
21:25	Began adding UV Water to Liq Tank (Target Level=24.9%)
	Stepping Metso SV down manually
24.20	Consider adding NEW Campaign procedure of emptying PSB at the end
21:30	
	Metso Settings
	Temp=185°C~365°F; Press~150 psi(A)
	FBLBs=90%(MAN); PSF=85%(MAN)
	CV#1&2=100%(MAN); Acid~4.00 GPH (CAS)
	Screw Press=5.0 RPMs; PSB LBs=60%(MAN) PreSteamBin=72%(A) & 110°F (A)
21:33	
21:36	Liq Tank Agitator ON
21:40	Stopped UV Addition to Liq Tank from bottom. Adding last% via UV water line
21:44	PSB LBs→65%; Acid→4.33 GPH
21:47	
21:54	FBLBs→20%
22:03	PSB LBs→70%; Acid→4.67 GPH
	Adding steam into Ferm C jacket
22:05	FBLBs→40%
22:08	Noticeably more biomass coming out of PSB TC chute
	Not enough to be concerned at this time
	PSF→88%
22:11	FBLBs→65%
22:19	FBLBs→80%
22:20	PSB LBs→75%
22:23	FBLBs→100%
22:27	Ferm C Sparger Valves CLOSED
	Jacket Pressure for any tank during SIP should 15 psi
22:29	Prop 3B pH SP @ 6.37; Base B Pump#8 running GOOD
	Ferm C SV→15%→Auto; Began SIP Procedures on Fermentor C
22:34	PSF→85%

22:37	PSF→82%
	Ferm C @ +5 psi; SV CLOSED; Vac Pump ON
22:42	FBLBs→90%
22:46	PSF→78→74%; FBLBs→80%
	All Liq Tank Transfer Lines are set
	Lig Tank Temp Control set @ 122°F
22:54	
22:58	FBLBs > 40%; Might be having a slight stacking starting in PSB TC
23:00	PSF→70%
	Most biomass coming out of chute so far
23:02	LOTS of PSF numbers due to bridging in PSB TC
23:03	PSB LBs→75%; Acid→5.00 GPH
	PSF→80→75%
23:06	PSB LBs→70%; Hopefully will help clear out PSB TC
	Need to include how PSB LBs adjust should be done for Pretreatment SOP
23:08	PSB LBs→65%; PSF→75% (all over the place really)
23:11	Vacuum Pump OFF; Ferm C SV→15%→Auto
	o 23:26 Speeding PSF up to 80%
23:29	PSB LBs→60%; Still trying to get TC to settle out
	REALLY compacted right now according to Joe
23:31	PSB LBs to PSF, Metso Steam, and FBLBs OFF
23:36	C5 Discharger Override ON
23:38	Opening up Ferm C Steam to Transfer Lines
	Ferm C @ 250.0°F. Hold for minimum of 90 minutes
23:44	PSF ON @ 100%
23:47	Both Knifegates OPEN; PSF OFF
	Since May of 2014 when we got back the Plug Screw
	We have more than doubled the run-time for the Plug Screw. Strange but interesting.
2014-1	1-08
00:04	Knifegate cycle started; Overrides OFF
00:05	PSB TC ON and OFF. BAD Squealing
00:06	WW Pump OFF. Flushed Pump and Tank Valve CLOSED
00:07	PSB TC ON and OFF. Much better this time
	Metso Steam ON
00:14	CIP Systems OFF; DFT @ 17% level; Mental FYI
00:19	All Metso Vents CLOSED
00:40	PSF (100%) and PSB TC ON
00:42	PSB SV→CAS (and ON)
00:52	DFP OFF
00:58	Bottom Knifegate or PSF at Blowback Damper leaking
	Feeding Metso; PSB LBs ON @ 60%. Feeding at 70 psi!
	FBLBs ON @ 40%
01:02	PSF→90%; FBLBs→CAS
01:10	Finished Ferm C SIP
	And back to +10% for Vacuum Breaker Sterilization
	Will run another 30 minutes
01:13	PSB TC chute gap "Looks good" according to Joe

```
01:16 "Good Flow of Biomass" from chute under Screw Press
       Top (Knifegate) Valve a bit sluggish for a moment
01:21 PSF→86%
01:30 PSF→82%
01:37 At Temp and Pressure in Metso
       All settings same as earlier except PSF @ 82% and FBLBs → 100% (CAS)
       Temp=185°C~365°F; Press~150 psi(A)
       FBLBs=100%(CAS); PSF=82%(MAN)
       CV#1&2=100%(MAN); Acid~4.00 GPH (CAS)
       Screw Press=5.0 RPMs; PSB LBs=60%(MAN)
       PreSteamBin=72%(A) & 110°F (A)
01:47 PSF→78%
01:53 PSF→74%
02:06 PSB LBs \rightarrow 65%; Acid \rightarrow 4.33 GPH
02:14 Ended Ferm C SIP for good now. SV CLOSED
02:38 PSB LBs\rightarrow70%; Acid\rightarrow4.67 GPH; FBLBs\rightarrow45%
02:39 PSF→78%
02:43 CLOSED drain on Cooling Water Tank. Had been overflowing
02:46 PSF\rightarrow82\rightarrow74\rightarrow70\rightarrow80%; Issues with PSB TC
       PSB LBs \rightarrow 65%
02:48 PSF\rightarrow85\rightarrow80%; Starting a really Bad Patch
       Holy CRUD these Amps.
02:49 PSF→90→95%
02:51 PSF\rightarrow100: FBLBs\rightarrow85\rightarrowCAS
02:52 PSF\rightarrow110\rightarrow95\rightarrow85%
02:54 PSF→90%
       We might need to just empty and clean out PreStream Bin itself
02:55 PSF→85%
02:57 FBLBs MAN @ 120%; PSF→90%
03:02 PSB LBs to PSF, Metso Steam, and FBLBs OFF
       PER ISMAEL-Shutting down to clean out
       Going to remove chute and examine it
03:19 Biomass Handling OFF
03:32 C5 Discharger and Knifegate Overrides ON; Both Knifegates OPEN
03:36 Peter blowing down boiler
03:39 Getting FALSE readings for Ferm C level
03:45 Acid Systems OFF
03:47 Steam ON to Prop 3B Sample Port
04:03 T=12hr Prop 3B Sample Taken
       (L) 39.5%; pH=6.31; (T) 98.6^{\circ}F; (P) 0.03 psi
04:07 Liq Tank Temp Control OFF; draining tank to floor
04:10 Boiler OFF
04:21 Liq Tank Agitator OFF
04:27 PSB TC Chute REMOVED
       Apparently, Joe and Peter were pumping Caustic Soda into sump to raise WW pH
04:31 PSB TC ON and OFF. Loads were okay!
       PSF ON @ 100%
04:42 PSF to C5 Discharger (and Overrides) OFF
```

```
04:47 Rest of Metso, HP Seal Water Pump, and CO<sub>2</sub> Scrubber Pump OFF
04:49 WW pH=9.9; Cond=1.42 mS/cm
04:54 WW Pump ON; Level=64.8%
06:32 Noticed that Metso's PSB TC spikes went crazy after between 80 and 90 minutes after reaching
       Temperature and Pressure settings for Metso.
06:49 C5 Agitator ON
07:03 Drains on Screw Press were BADLY clogged.
       Joe and Peter cleared them though.
07:42 WW Pump OFF
Shift Change
08:51 Boiler/HP Pump ON, starting conveyors
09:06 Handling ON/Scrubbers ON
09:51 Feeding Metso, PSB LB-65%, PSF-100%
10:09 Started 140°F Kill of 3B
10:19 PSF→95%
10:34 Metso @ Temp and Pressure
10:41 PSBLB→70%
11:10 PSBLB\rightarrow75%, PSF\rightarrow98%
11:18 Filled two 55-gallon drums from C5 tank, dumped rest.
       Going to open and pressure-wash, introduce Caustic to it (somehow) and steam it
11:30 3B @ 140°F
       PSBLB→80%
11:36 PSBLB→85%
11:41 PSBLB→90%
       Changed PSB Level to 80% in (A), Bin (C)
11:50 PSBLB→95%
11:59 Hit Rough Spot. PSB→85%. PSF→95%
12:07 PSF→110%
12:12 About noon, EVERYTHING Went to Hell.
12:20 Shut OFF feed and steam to Metso.
       High spikes in TC and PSF was @ 8.0
       Lose-Lose situation. Going to do normal shutdown
12:47 System depressurized
13:13 WW pH=11.69
13:27 Going to start back up and try to stay steady @ 85% PSBLB
       WW going out
13:40 Heating up Caustic/Rinse
13:44 BW Pump OFF
13:50 Change of plans. Possible plug where Rinse goes to PSF, going to investigate
14:12 Metso down, CO<sub>2</sub> Scrubber OFF
15:55 Rinse Water→C5 Tank through Hydrolyzate header
16:15 Transferring 3B→BW
16:30 UV Pump ON
16:35 Start Rinse Cycle of 3B
       Stopped Fill of C5 (25.4%)
16:52 Chiller OFF, Cooling Water OFF, Hot Water OFF
17:20 All but Potable/Process OFF
```

Log Book Keys

Color Coding

blue text tank refill log (i.e., bleach, caustic acid)

green text notes from field

purple text problems

red text sampling/inoculation-related information

yellow highlight process notes, major issues

Abbreviations

AAP Aqueous Ammonia Pump

AG Agitator
BT Blow Tank
BW Beerwell
BWP Beerwell Pump

C5 Discharger Hydrolyzer Discharge Screw

CIP Clean in Place

CV CableVey-Cable conVeyors
DFP Decanter Feed Pump
FBLBs Feed Bin Live Bottoms

FBTC/FBCC Feed Bin Transfer/Collection Conveyor

GP Gluconase Pump

HPSWP High Pressure Seal Water Pump HSMC High Shear Mixing Conveyor

LIQ Liquefaction Tank

LP/LIQP Liquefaction Tank Pump

PA Phosphoric Acid

PAHT Phosphoric Acid Holding Tank
PAMP Phosphoric Acid Metering Pump
PAMT Phosphoric Acid Mix Tank

pAP pH Adjustment Tank Pump
PATP Phosphoric Acid Mix Tank

pHA pH Adjustment Tank

Prop Propagator

PSBLBs Pre-Steam Bin Live Bottoms

PSF Plug Screw Feeder
RevSc Reversing Screw
ScPr Screw Press
SIP Sterilize in Place
SV Steam Valve
WW Waste Water