

mini9P health read

Shell

cluster_vfs

session

STM32

cat /mcu1/sys/health

resolve mcu1 + local path

attach / walk / open / read

Rread: health text

complete typed pending

status=ok

Only the owner host performs the UART transaction; remote hosts proxy the same path.