

# Mesh2 control-plane exchange

Host authority

Relay node

Joining node

HELLO / ACK

NODE\_REGISTER (UID + boot\_id)

ADDR\_ASSIGN (address + lease)

LEASE\_RENEW + LINK\_STATE

LEASE\_ACK + ROUTE\_UPDATE

HOST\_ADVERTISE + TIME\_SYNC

Only the elected authority may assign addresses, leases and route versions.