DELTA 3 MAX

HTTP Connection Mode

Set Device Functions and Get Corresponding Heartbeat

Use HTTP to set or get device function fields. The settings and requests provided in this section are open-access functions. Other non-open functions can also obtain field metrics in the same way, but cannot be used to set device functions.

PUT: /iot-open/sign/device/quota — Set device function fields (SetCmdRequest).

POST: /iot-open/sign/device/quota — Get specified heartbeat fields of the device (GetCmdRequest, GetCmdResponse).

Examples

Function	Set Parameter Example	Request Parameter Example	Request Response Example

Set AC output switch (true: on, false: off)	<pre>{
	"sn": "D3N1ZE1A9HCE0009",
	"cmdId": 17,
	"cmdFunc": 254,
	"dest": 2,
	"dirDest": 1,
	"dirSrc": 1,
	"needAck": true,
	"params": {
	"cfgAcOutOpen": true
	}
	}</pre>
		<pre>{
		"sn": "D3N1ZE1A9HCE0009",
		"params": {
		"quotas": [
		"flowInfoAcOut"
		]
		}
		}</pre>
			<pre>{
			"code": "0",
			"message": "Success",
			"data": {
			"flowInfoAcOut": 4
			},
			"eagleEyeTraceId": "",
			"tid": ""
			}</pre>

Set DC output switch (true: on, false: off)	<pre>{
	"sn": "D3N1ZE1A9HCE0009",
	"cmdId": 17,
	"cmdFunc": 254,
	"dest": 2,
	"dirDest": 1,
	"dirSrc": 1,
	"needAck": true,
	"params": {
	"cfgDc12vOutOpen": true
	}
	}</pre>
		<pre>{
		"sn": "D3N1ZE1A9HCE0009",
		"params": {
		"quotas": [
		"flowInfo12v"
		]
		}
		}</pre>
			<pre>{
			"code": "0",
			"message": "Success",
			"data": {
			"flowInfo12v": 14
			},
			"eagleEyeTraceId": "",
			"tid": ""
			}</pre>

Set energy backup switch (true: on, false: off)	<pre>{
	"sn": "D3N1ZE1A9HCE0009",
	"cmdId": 17,
	"cmdFunc": 254,
	"dest": 2,
	"dirDest": 1,
	"dirSrc": 1,
	"needAck": true,
	"params": {
	"cfgEnergyBackup": {
	"energyBackupEn": true
	}
	}
	}</pre>
		<pre>{
		"sn": "D3N1ZE1A9HCE0009",
		"params": {
		"quotas": [
		"energyBackupEn"
		]
		}
		}</pre>
			<pre>{
			"code": "0",
			"message": "Success",
			"data": {
			"energyBackupEn": false
			},
			"eagleEyeTraceId": "",
			"tid": ""
			}</pre>

Function	Set Parameter Example	Request Parameter Example	Request Response Example

Set energy backup ratio (range: 0-50)	{
	"sn": "D3N1ZE1A9HCE0009",
	"cmdId": 17,
	"cmdFunc": 254,
	"dest": 2,
	"dirDest": 1,
	"dirSrc": 1,
	"needAck": true,
	"params": {
	"cfgBackupReverseSoc": 41
	}
	}
		{
		"sn": "D3N1ZE1A9HCE0009",
		"params": {
		"quotas": [
		"backupReverseSoc"
		]
		}
		}
			{
			"code": "0",
			"message": "Success",
			"data": {
			"backupReverseSoc": 0
			},
			"eagleEyeTraceId": "",
			"tid": ""
			}

Set buzzer switch (true: on, false: off)	{
	"sn": "D3N1ZE1A9HCE0009",
	"cmdId": 17,
	"cmdFunc": 254,
	"dest": 2,
	"dirDest": 1,
	"dirSrc": 1,
	"needAck": true,
	"params": {
	"cfgBeepEn": true
	}
	}
		{
		"sn": "D3N1ZE1A9HCE0009",
		"params": {
		"quotas": [
		"enBeep"
		]
		}
		}
			{
			"code": "0",
			"message": "Success",
			"data": {
			"enBeep": true
			},
			"eagleEyeTraceId": "",
			"tid": ""
			}

Set X-Boost switch (true: on, false: off)	{
	"sn": "D3N1ZE1A9HCE0009",
	"cmdId": 17,
	"cmdFunc": 254,
	"dest": 2,
	"dirDest": 1,
	"dirSrc": 1,
	"needAck": true,
	"params": {
	"cfgXboostEn": true
	}
	}
		{
		"sn": "D3N1ZE1A9HCE0009",
		"params": {
		"quotas": [
		"xboostEn"
		]
		}
		}
			{
			"code": "0",
			"message": "Success",
			"data": {
			"xboostEn": true
			},
			"eagleEyeTraceId": "",
			"tid": ""
			}

Set bypass output disable switch (true: on, false: off)	{
	"sn": "D3N1ZE1A9HCE0009",
	"cmdId": 17,
	"cmdFunc": 254,
	"dest": 2,
	"dirDest": 1,
	"dirSrc": 1,
	"needAck": true,
	"params": {
	"cfgBypassOutDisable": true
	}
	}
		{
		"sn": "D3N1ZE1A9HCE0009",
		"params": {
		"quotas": [
		"bypassOutDisable"
		]
		}
		}
			{
			"code": "0",
			"message": "Success",
			"data": {
			"bypassOutDisable": false
			},
			"eagleEyeTraceId": "",
			"tid": ""
			}

Set charge upper limit (range: 50-100)	{
	"sn": "D3N1ZE1A9HCE0009",
	"cmdId": 17,
	"cmdFunc": 254,
		{
		"sn": "D3N1ZE1A9HCE0009",
		"params": {
		"quotas": [
			{
			"code": "0",
			"message": "Success",
			"data": {

Function	Set Parameter Example	Request Parameter Example	Request Response Example

	<pre>"dest": 2,
	"dirDest": 1,
	"dirSrc": 1,
	"needAck": true,
	"params": {
	"cfgMaxChgSoc": 80
	}
	}</pre>
		<pre>"cmsMaxChgSoc"
		]
		}
		}</pre>
			<pre>"cmsMaxChgSoc": 90
			},
			"eagleEyeTraceId": "",
			"tid": ""
			}</pre>

Set discharge lower limit (range: 0-30)	<pre>{
	"sn": "D3N1ZE1A9HCE0009",
	"cmdId": 17,
	"cmdFunc": 254,
	"dest": 2,
	"dirDest": 1,
	"dirSrc": 1,
	"needAck": false,
	"params": {
	"cfgMinDsgSoc": 30
	}
	}</pre>
		<pre>{
		"sn": "D3N1ZE1A9HCE0009",
		"params": {
		"quotas": [
		"cmsMinDsgSoc"
		]
		}
		}</pre>
			<pre>{
			"code": "0",
			"message": "Success",
			"data": {
			"cmsMinDsgSoc": 20
			},
			"eagleEyeTraceId": "",
			"tid": ""
			}</pre>

Complete Heartbeat Response

Field	Type	Description
pow_get_ac_in	float	Real-time power of AC input port (W)
pow_get_pv	float	Real-time power of PV/car input (W)
pow_get_ac_out	float	Real-time power of AC output port (W)
pow_get_12v	float	Real-time power of 12V DC output port (W)
pow_get_12v_list.pow_get_12v_item	<pre>[float]</pre>	Real-time output power of Anderson port (W)
pow_get_typec1	float	Real-time power of USB-C output port USB-C1 (W)
pow_get_typec2	float	Real-time power of USB-C output port USB-C2 (W)
pow_get_typec3	float	Real-time power of USB-C output port USB-C3 (W)
pow_get_qcusb1	float	Real-time power of USB-A output port USB-1 (W)
pow_get_qcusb2	float	Real-time power of USB-A output port USB-2 (W)
flow_info_ac_out	uint	AC output switch (on when value is not 4)
flow_info_12v	uint	DC output switch (on when value is not 4)
pow_in_sum_w	float	Real-time input power of the device (W)
pow_out_sum_w	float	Real-time output power of the device (W)
cms_batt_soc	float	Current battery level (%)
cms_chg_dsg_state	uint	Current charging/discharging/idle status (0-idle, 1-discharging, 2-charging)
cms_dsg_rem_time	uint	Remaining usable time at current battery level (min)
cms_chg_rem_time	uint	Time required to fully charge the battery (min)
energy_backup_en	bool	Energy backup switch status (0-off, 1-on)

Field	Type	Description
backup_reverse_soc	uint	Backup ratio setting (%)
en_beep	bool	Buzzer switch status (0-off, 1-on)
xboost_en	bool	X-Boost switch status (0-off, 1-on)
bypass_out_disable	bool	Bypass output disable switch status (0-not disabled by default, 1-disabled)
cms_max_chg_soc	uint	Charge upper limit setting range (%)
cms_min_dsg_soc	uint	Discharge lower limit setting range (%)

Example


```
{
    "cmsChgRemTime": 12927,
    "energyBackupEn": true,
    "powGetAcIn": 0,
    "flowInfoAcOut": 4,
    "bypassOutDisable": false,
    "powGet12v": 0,
    "cmsBattSoc": 6,
    "backupReverseSoc": 23,
    "powOutSumW": 0,
    "xboostEn": true,
    "cmsMaxChgSoc": 66,
    "cmsMinDsgSoc": 30,
    "flowInfo12v": 4,
    "cmsChgDsgState": 0,
    "enBeep": true,
    "powGetQcusb1": 0,
    "powGetQcusb2": 0,
    "powGet12vList.powGet12vItem": [
        0,
        0
    ],
    "powGetTypec3": 0,
    "powInSumW": 0,
    "powGetTypec1": 0,
    "powGetTypec2": 0,
    "cmsDsgRemTime": 437,
    "powGetAcOut": 0,
    "powGetPv": 0
}
```


MQTT Connection Mode

Command Set Topic & Response Topic

Purpose	Topic	From	To
Set device function	/open/${certificateAccount}/${sn}/set	app	device
Device responds with set result	/open/${certificateAccount}/${sn}/set_reply	device	app

Example

Set command format


```
{
    "sn": "D3M1ZA1A9H7H0136",
    "id": 1715152800124,
    "version": "1.0",
    "cmdId": 17,
    "cmdFunc": 254,
```

Set command format


```
    "dest": 2,
    "dirDest": 1,
    "dirSoc": 1,
    "needAck": true,
    "params": {
        "cfgBeepEn": true
    }
}
```


Heartbeat Report

Purpose	Topic	From	To
Device heartbeat report	/open/${certificateAccount}/${sn}/quota	device	app

Example


```
{
    "powGet12vList": {
        "powGet12vItem": [
            0,
            0
        ]
    },
    "powGetPv": 0,
    "cmsChgRemTime": 12927,
    "energyBackupEn": true,
    "powGetAcIn": 0,
    "flowInfoAcOut": 4,
    "bypassOutDisable": false,
    "powGet12v": 0,
    "powOutSumW": 0,
    "cmsBattSoc": 41,
    "backupReverseSoc": 30,
    "xboostEn": false,
    "cmsMaxChgSoc": 50,
    "cmsMinDsgSoc": 3,
    "flowInfo12v": 4,
    "cmsChgDsgState": 0,
    "enBeep": true,
    "powGetQcusb1": 0,
    "powGetQcusb2": 0,
    "powGetTypec3": 0,
    "powInSumW": 0,
    "powGetTypec1": 0,
    "powGetTypec2": 0,
    "cmsDsgRemTime": 2981,
    "powGetAcOut": 0
}
```


Device Status

Purpose	Topic	From	To
Device status report	/open/${certificateAccount}/${sn}/status	device	app

Example


```
{
    "id": "945718406",
    "params": {
        "status": 0
    },
    "timestamp": 1778308183516,
```

```
    "version": "1.0"
}
```

Was this page helpful?