



OVP Guide to Using Processor Models

Model specific information for ARM_Cortex-M4F

Imperas Software Limited
Imperas Buildings, North Weston
Thame, Oxfordshire, OX9 2HA, U.K.
docs@imperas.com



Author	Imperas Software Limited
Version	20250716.0
Filename	OVP_Model_Specific_Information_armm.Cortex-M4F.pdf
Created	16 July 2025
Status	OVP Standard Release

Copyright Notice

Copyright (c) 2024 Imperas Software Limited. All rights reserved. This software and documentation contain information that is the property of Imperas Software Limited. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Imperas Software Limited, or as expressly provided by the license agreement.

Right to Copy Documentation

The license agreement with Imperas permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the readers responsibility to determine the applicable regulations and to comply with them.

Disclaimer

IMPERAS SOFTWARE LIMITED, AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Model Release Status

This model is released as part of OVP releases and is included in OVPworld packages. Please visit OVPworld.org.

Contents

1	Overview	1
1.1	Description	1
1.2	Licensing	1
1.3	Limitations	2
1.4	Verification	2
1.5	Features	2
1.6	Unpredictable Behavior	3
1.6.1	Equal Target Registers	3
1.6.2	Floating Point Load/Store Multiple Lists	3
1.6.3	If-Then (IT) Block Constraints	3
1.6.4	Use of R13	3
1.6.5	Use of R15	3
1.7	Integration Support	4
1.7.1	Memory Transaction Query	4
1.7.2	Halt Reason Introspection	4
1.7.3	Automatic WFI Wake Up	4
2	Configuration	5
2.1	Location	5
2.2	GDB Path	5
2.3	Semi-Host Library	5
2.4	Processor Endian-ness	5
2.5	QuantumLeap Support	5
2.6	Processor ELF code	5
3	All Variants in this model	6
4	Bus Master Ports	7
5	Bus Slave Ports	8
6	Net Ports	9
7	FIFO Ports	11
8	Formal Parameters	12
8.1	Parameter values and limits	13

9 Execution Modes	15
10 Exceptions	16
11 Hierarchy of the model	17
11.1 Level 1	17
12 Model Commands	18
12.1 Level 1	18
12.1.1 debugflags	18
12.1.2 isync	18
12.1.3 itrace	18
13 Registers	20
13.1 Level 1	20
13.1.1 Core	20
13.1.2 Control	20
13.1.3 System	21
13.1.4 VFP	22
13.1.5 Integration_support	22

Chapter 1

Overview

This document provides the details of an OVP Fast Processor Model variant.

OVP Fast Processor Models are written in C and provide a C API for use in C based platforms. The models also provide a native interface for use in SystemC TLM2 platforms.

The models are written using the OVP VMI API that provides a Virtual Machine Interface that defines the behavior of the processor. The VMI API makes a clear line between model and simulator allowing very good optimization and world class high speed performance. Most models are provided as a binary shared object and also as source. This allows the download and use of the model binary or the use of the source to explore and modify the model.

The models are run through an extensive QA and regression testing process and most model families are validated using technology provided by the processor IP owners. There is a companion document (OVP Guide to Using Processor Models) which explains the general concepts of OVP Fast Processor Models and their use. It is downloadable from the OVPworld website documentation pages.

1.1 Description

ARMM Processor Model

1.2 Licensing

Usage of binary model under license governing simulator usage.

Note that for models of ARM CPUs the license includes the following terms:

Licensee is granted a non-exclusive, worldwide, non-transferable, revocable licence to:

If no source is being provided to the Licensee: use and copy only (no modifications rights are granted) the model for the sole purpose of designing, developing, analyzing, debugging, testing, verifying, validating and optimizing software which: (a) (i) is for ARM based systems; and (ii) does not incorporate the ARM Models or any part thereof; and (b) such ARM Models may not be used

to emulate an ARM based system to run application software in a production or live environment.

If source code is being provided to the Licensee: use, copy and modify the model for the sole purpose of designing, developing, analyzing, debugging, testing, verifying, validating and optimizing software which: (a) (i) is for ARM based systems; and (ii) does not incorporate the ARM Models or any part thereof; and (b) such ARM Models may not be used to emulate an ARM based system to run application software in a production or live environment.

In the case of any Licensee who is either or both an academic or educational institution the purposes shall be limited to internal use.

Except to the extent that such activity is permitted by applicable law, Licensee shall not reverse engineer, decompile, or disassemble this model. If this model was provided to Licensee in Europe, Licensee shall not reverse engineer, decompile or disassemble the Model for the purposes of error correction.

The License agreement does not entitle Licensee to manufacture in silicon any product based on this model.

The License agreement does not entitle Licensee to use this model for evaluating the validity of any ARM patent.

The License agreement does not entitle Licensee to use the model to emulate an ARM based system to run application software in a production or live environment.

Source of model available under separate Imperas Software License Agreement.

1.3 Limitations

Performance Monitors are not implemented.

Debug Extension and related blocks are not implemented.

1.4 Verification

Models have been extensively tested by Imperas. ARM Cortex-M models have been successfully used by customers to simulate the Micrium uC/OS-II kernel and FreeRTOS.

1.5 Features

The model is configured with 16 interrupts and 3 priority bits (use `override_numInterrupts` and `override_priorityBits` parameters to change these).

Thumb-2 instructions are supported.

MPU is present. Use parameter `override_MPU_TYPE` to disable it or change the number of MPU regions if required.

SysTick timer is present. Use parameter `SysTickPresent` to disable it if required.

FPU extension is present. Use parameter override.MVFR0 to disable it if required.

DSP extension is present. Use parameter override.InstructionAttributes3 to disable it if required.

Bit-band region is not present. Use parameter BitBandPresent to enable it if required.

A 20-bit PPB bus port can be connected. If it is, then any loads or stores to address range 0xE0040000:0xE00FFFFF will be visible on this bus at address range 0x00040000:0x000FFFFF.

1.6 Unpredictable Behavior

Many instruction behaviors are described in the ARM ARM as CONSTRAINED UNPREDICTABLE. This section describes how such situations are handled by this model.

1.6.1 Equal Target Registers

Some instructions allow the specification of two target registers (for example, double-width SMULL, or some VMOV variants), and such instructions are CONSTRAINED UNPREDICTABLE if the same target register is specified in both positions. In this model, such instructions are treated as UNDEFINED.

1.6.2 Floating Point Load/Store Multiple Lists

Instructions that load or store a list of floating point registers (e.g. VSTM, VLDM, VPUSH, VPOP) are CONSTRAINED UNPREDICTABLE if either the uppermost register in the specified range is greater than 32 or (for 64-bit registers) if more than 16 registers are specified. In this model, such instructions are treated as UNDEFINED.

1.6.3 If-Then (IT) Block Constraints

Where the behavior of an instruction in an if-then (IT) block is described as CONSTRAINED UNPREDICTABLE, this model treats that instruction as UNDEFINED.

1.6.4 Use of R13

Use of R13 is described as CONSTRAINED UNPREDICTABLE in many circumstances. This model allows R13 to be used like any other GPR.

1.6.5 Use of R15

Use of R15 is described as CONSTRAINED UNPREDICTABLE in many circumstances. This model allows such use to be configured using the parameter “unpredictableR15” as follows:

Value “undefined”: any reference to R15 in such a situation is treated as UNDEFINED;

Value “nop”: any reference to R15 in such a situation causes the instruction to be treated as a NOP;

Value “raz_wi”: any reference to R15 in such a situation causes the instruction to be treated as a RAZ/WI (that is, R15 is read as zero and write-ignored);

Value “execute”: any reference to R15 in such a situation is executed using the current value of R15 on read, and writes to R15 are allowed.

Value “assert”: any reference to R15 in such a situation causes the simulation to halt with an assertion message (allowing any such unpredictable uses to be easily identified).

In this variant, the default value of “unpredictableR15” is “execute”.

1.7 Integration Support

This model implements a number of non-architectural pseudo-registers and other features to facilitate integration.

1.7.1 Memory Transaction Query

Two registers are intended for use within memory callback functions to provide additional information about the current memory access. Register `executionPri` indicates the current processor execution priority. Register `atomicType` indicates whether the current instruction has any special atomic constraints (0 indicates no constraint, 1 indicates atomic, 2 indicates exclusive access).

1.7.2 Halt Reason Introspection

An artifact register `HaltReason` can be read to determine the reason or reasons that a processor is halted. This register is a bitfield, with the following encoding: bit 0 indicates the processor has executed a wait-for-event (WFE) instruction; bit 1 indicates the processor has executed a wait-for-interrupt (WFI) instruction; bit 2 indicates the processor has entered lockup state; and bit 3 indicates the processor is held in reset.

1.7.3 Automatic WFI Wake Up

A simulation environment can cause a core to wake up from the WFI state by writing to the artifact register `WakeWFINow`.

Chapter 2

Configuration

2.1 Location

This model's VLVN is `arm.ovpworld.org/processor/armmm/1.0`.

The model source is usually at:

`$IMPERAS_HOME/ImperasLib/source/arm.ovpworld.org/processor/armmm/1.0`

The model binary is usually at:

`$IMPERAS_HOME/lib/$IMPERAS_ARCH/ImperasLib/arm.ovpworld.org/processor/armmm/1.0`

2.2 GDB Path

The default GDB for this model is: `$IMPERAS_HOME/lib/$IMPERAS_ARCH/gdb/arm-none-eabi-gdb`.

2.3 Semi-Host Library

The default semi-host library file is `arm.ovpworld.org/semihosting/armNewlib/1.0`

2.4 Processor Endian-ness

This is a LITTLE endian model.

2.5 QuantumLeap Support

This processor is qualified to run in a QuantumLeap enabled simulator.

2.6 Processor ELF code

The ELF code supported by this model is: `0x28`.

Chapter 3

All Variants in this model

This model has these variants

Variant	Description
ARMv6-M	
ARMv7-M	
Cortex-M0	
Cortex-M0plus	
Cortex-M1	
Cortex-M3	
Cortex-M4	
Cortex-M4F	(described in this document)
Cortex-M7	
Cortex-M7F	
Cortex-M23	
Cortex-M33	
Cortex-M33F	
Cortex-M55	
Cortex-M55F	

Table 3.1: All Variants in this model

Chapter 4

Bus Master Ports

This model has these bus master ports.

Name	min	max	Connect?	Description
INSTRUCTION	32	32	mandatory	
DATA	32	32	optional	
PPB	20	20	optional	PPB interface
SAHB	32	32	optional	AHB-Lite System port

Table 4.1: Bus Master Ports

Chapter 5

Bus Slave Ports

This model has no bus slave ports.

Chapter 6

Net Ports

This model has these net ports.

Name	Type	Connect?	Description
sysResetReq	output	optional	Indicates that a reset is required
intISS	output	optional	Indicates that an interrupt service has started
eventOut	output	optional	EVENTO output signal (SEV)
lockup	output	optional	Indicates fatal lockup state entered
haltReason	output	optional	Indicates why core is halted
currPri	output	optional	Current execution priority
currNS	output	optional	Current security state
intnum	output	optional	Exception number of current execution context
int	input	optional	Raise or lower interrupt by index
reset	input	optional	RESET (active high)
cpuWait	input	optional	CPUWAIT (active high at reset only)
nmi	input	optional	NMI (posedge-triggered)
eventIn	input	optional	EVENTI input (posedge-triggered)
auxfault	input	optional	Specifies additional system fault information
initvtor	input	optional	VTOR reset configuration
fpxxc	output	optional	Cumulative floating point exception flags
int0	input	optional	Scalar interrupt input 0
int1	input	optional	Scalar interrupt input 1
int2	input	optional	Scalar interrupt input 2
int3	input	optional	Scalar interrupt input 3
int4	input	optional	Scalar interrupt input 4
int5	input	optional	Scalar interrupt input 5
int6	input	optional	Scalar interrupt input 6
int7	input	optional	Scalar interrupt input 7
int8	input	optional	Scalar interrupt input 8
int9	input	optional	Scalar interrupt input 9
int10	input	optional	Scalar interrupt input 10

int11	input	optional	Scalar interrupt input 11
int12	input	optional	Scalar interrupt input 12
int13	input	optional	Scalar interrupt input 13
int14	input	optional	Scalar interrupt input 14
int15	input	optional	Scalar interrupt input 15

Table 6.1: Net Ports

Chapter 7

FIFO Ports

This model has no FIFO ports.

Chapter 8

Formal Parameters

Name	Type	Description
verbose	Boolean	Specify verbosity of output
showHiddenRegs	Boolean	Show hidden registers during register tracing
UAL	Boolean	Disassemble using UAL syntax
enableVFPAtReset	Boolean	Enable vector floating point (SIMD and VFP) instructions at reset. (Enables cp10/11 in CPACR and sets FPEXC.EN)
compatibility	Enumeration	Specify compatibility mode
	ISA	
	gdb	
	nopBKPT	
unpredictableR15	Enumeration	Specify behavior for UNPREDICTABLE uses of R15
	undefined	
	nop	
	raz_wi	
	execute	
	assert	
override_debugMask	Uns32	Specifies debug mask, enabling debug output for model components
instructionEndian	Endian	The architecture specifies that instruction fetch is always little endian; this attribute allows the defined instruction endianness to be overridden if required
resetAtTime0	Boolean	Reset the model at time=0 (default=1)
SysTickPresent	Uns32	Specify number of SysTick timers present
BitBandPresent	Boolean	Specify presence of bit-band region
override_PFR0	Uns32	Override ID_PFR0 register
override_PFR1	Uns32	Override ID_PFR1 register
override_DFR0	Uns32	Override ID_DFR0 register
override_AFR0	Uns32	Override ID_AFR0 register
override_MMFR0	Uns32	Override ID_MMFR0 register
override_MMFR1	Uns32	Override ID_MMFR1 register
override_MMFR2	Uns32	Override ID_MMFR2 register
override_MMFR3	Uns32	Override ID_MMFR3 register
override_ISAR0	Uns32	Override ID_ISAR0 register
override_ISAR1	Uns32	Override ID_ISAR1 register
override_ISAR2	Uns32	Override ID_ISAR2 register
override_ISAR3	Uns32	Override ID_ISAR3 register
override_ISAR4	Uns32	Override ID_ISAR4 register
override_ISAR5	Uns32	Override ID_ISAR5 register
override_MVFR0	Uns32	Override ID_MVFR0 register
override_MVFR1	Uns32	Override ID_MVFR1 register

override_MVFR2	Uns32	Override ID_MVFR2 register
override_CPUID	Uns32	Override system CPUID register
override_MPU_TYPE	Uns32	Override system MPU_TYPE register
override_VTOR	Uns32	Override VTOR register reset value
override_deviceStrongAligned	Boolean	Force accesses to Device and Strongly Ordered regions to be aligned
override_STRoffsetPC12	Uns32	Specifies that STR/STR of PC should do so with 12:byte offset from the current instruction (if 1), otherwise an 8:byte offset is used
override_ERG	Uns32	Specifies exclusive reservation granule
override_priorityBits	Uns32	Specifies number of priority bits in BASEPRI etc (1-8, default is 3)
override_numInterrupts	Uns32	Specifies number of external interrupt lines
override_InstructionAttributes0	Uns32	Override ID_ISAR0 register (deprecated, use override_ISAR0)
override_InstructionAttributes1	Uns32	Override ID_ISAR1 register (deprecated, use override_ISAR1)
override_InstructionAttributes2	Uns32	Override ID_ISAR2 register (deprecated, use override_ISAR2)
override_InstructionAttributes3	Uns32	Override ID_ISAR3 register (deprecated, use override_ISAR3)
override_InstructionAttributes4	Uns32	Override ID_ISAR4 register (deprecated, use override_ISAR4)
override_InstructionAttributes5	Uns32	Override ID_ISAR5 register (deprecated, use override_ISAR5)

Table 8.1: Parameters

8.1 Parameter values and limits

These are the formal parameter limits and actual parameter values

Name	Min	Max	Default	Actual
(Others)				
variant				Cortex-M4F
verbose			t	t
showHiddenRegs			f	f
UAL			t	t
enableVFPAtReset			f	f
compatibility			ISA	ISA
unpredictableR15			execute	execute
override_debugMask	0	0xffffffff	0	0
endian			none	none
instructionEndian			none	none
resetAtTime0			t	t
SysTickPresent	0	0	1	1
BitBandPresent			f	f
override_PFR0	0	0xffffffff	48	48
override_PFR1	0	0xffffffff	0x200	0x200
override_DFR0	0	0xffffffff	0	0
override_AFR0	0	0xffffffff	0	0
override_MMFR0	0	0xffffffff	48	48
override_MMFR1	0	0xffffffff	0	0
override_MMFR2	0	0xffffffff	0	0
override_MMFR3	0	0xffffffff	0	0

override_ISAR0	0	0xffffffff	0x1141110	0x1141110
override_ISAR1	0	0xffffffff	0x2112000	0x2112000
override_ISAR2	0	0xffffffff	0x20232231	0x20232231
override_ISAR3	0	0xffffffff	0x1111131	0x1111131
override_ISAR4	0	0xffffffff	0x1310132	0x1310132
override_ISAR5	0	0xffffffff	0	0
override_MVFR0	0	0xffffffff	0x10110021	0x10110021
override_MVFR1	0	0xffffffff	0x11000011	0x11000011
override_MVFR2	0	0xffffffff	0	0
override_CPUID	0	0xffffffff	0x410fc241	0x410fc241
override_MPU_TYPE	0	0xffffffff	0x800	0x800
override_VTOR	0	0xffffffff	0	0
override_deviceStrongAligned			f	f
override_STROffsetPC12	0	1	0	0
override_ERG	0	0x400	0	0
override_priorityBits	1	8	3	3
override_numInterrupts	0	0x1f0	16	16
override_InstructionAttributes0	0	0xffffffff	0x1141110	0x1141110
override_InstructionAttributes1	0	0xffffffff	0x2112000	0x2112000
override_InstructionAttributes2	0	0xffffffff	0x20232231	0x20232231
override_InstructionAttributes3	0	0xffffffff	0x1111131	0x1111131
override_InstructionAttributes4	0	0xffffffff	0x1310132	0x1310132
override_InstructionAttributes5	0	0xffffffff	0	0

Table 8.2: Parameter values and limits

Chapter 9

Execution Modes

Mode	Code
Thread	0
Handler	1

Table 9.1: Modes implemented in this processor

Chapter 10

Exceptions

Exception	Code
None	0
Reset	1
NMI	2
HardFault	3
MemManage	4
BusFault	5
UsageFault	6
SVCall	11
DebugMonitor	12
PendSV	14
SysTick	15
ExternalInt000	16
ExternalInt001	17
ExternalInt002	18
ExternalInt003	19
ExternalInt004	20
ExternalInt005	21
ExternalInt006	22
ExternalInt007	23
ExternalInt008	24
ExternalInt009	25
ExternalInt00a	26
ExternalInt00b	27
ExternalInt00c	28
ExternalInt00d	29
ExternalInt00e	30
ExternalInt00f	31

Table 10.1: Exceptions implemented by this processor

Chapter 11

Hierarchy of the model

A CPU core may be configured to instance many processors of a Symmetrical Multi Processor (SMP). A CPU core may also have sub elements within a processor, for example hardware threading blocks.

OVP processor models can be written to include SMP blocks and to have many levels of hierarchy. Some OVP CPU models may have a fixed hierarchy, and some may be configured by settings in a configuration register. Please see the register definitions of this model.

This model documentation shows the settings and hierarchy of the default settings for this model variant.

11.1 Level 1

This level in the model hierarchy has 3 commands.

This level in the model hierarchy has 5 register groups:

Group name	Registers
Core	16
Control	8
System	64
VFP	17
Integration_support	5

Table 11.1: Register groups

This level in the model hierarchy has no children.

Chapter 12

Model Commands

A Processor model can implement one or more **Model Commands** available to be invoked from the simulator command line, from the OP API or from the Imperas Multiprocessor Debugger.

12.1 Level 1

12.1.1 debugflags

show or modify the processor debug flags

Argument	Type	Description
-get	Boolean	print current processor flags value
-mask	Boolean	print valid debug flag bits
-set	Int32	new processor flags (only flags 0x0000008c can be modified)

Table 12.1: debugflags command arguments

12.1.2 isync

specify instruction address range for synchronous execution

Argument	Type	Description
-addresshi	Uns64	end address of synchronous execution range
-addresslo	Uns64	start address of synchronous execution range

Table 12.2: isync command arguments

12.1.3 itrace

enable or disable instruction tracing

Argument	Type	Description
-access	String	show memory accesses by this instruction. Argument can be any combination of X (execute), A (load or store access) and S (system)

-after	Uns64	apply after this many instructions
-enable	Boolean	enable instruction tracing
-full	Boolean	turn on all trace features
-instructioncount	Boolean	include the instruction number in each trace
-memory	String	(Alias for access). show memory accesses by this instruction. Argument can be any combination of X (execute), A (load or store access) and S (system)
-mode	Boolean	show processor mode changes
-off	Boolean	disable instruction tracing
-on	Boolean	enable instruction tracing
-processorname	Boolean	Include processor name in all trace lines
-registerchange	Boolean	show registers changed by this instruction
-registers	Boolean	show registers after each trace

Table 12.3: itrace command arguments

Chapter 13

Registers

13.1 Level 1

13.1.1 Core

Registers at level:1, group:Core

Name	Bits	Initial-Hex	RW	Description
r0	32	0	rw	
r1	32	0	rw	
r2	32	0	rw	
r3	32	0	rw	
r4	32	0	rw	
r5	32	0	rw	
r6	32	0	rw	
r7	32	0	rw	
r8	32	0	rw	
r9	32	0	rw	
r10	32	0	rw	
r11	32	0	rw	frame pointer
r12	32	0	rw	
sp	32	0	rw	stack pointer
lr	32	0	rw	
pc	32	0	rw	program counter

Table 13.1: Registers at level 1, group:Core

13.1.2 Control

Registers at level:1, group:Control

Name	Bits	Initial-Hex	RW	Description
fps	32	0	rw	archaic FPSCR view (for gdb)
cpsr	32	0	rw	xPSR register. Includes APSR, IPSR and EPSR
control	32	0	rw	
primask	32	0	rw	
faultmask	32	0	rw	
basepri	32	0	rw	
sp_process	32	0	rw	stack pointer
sp_main	32	0	rw	stack pointer

Table 13.2: Registers at level 1, group:Control

13.1.3 System

Registers at level:1, group:System

Name	Bits	Initial-Hex	RW	Description
ICTR	32	0	rw	0xe000e004: Interrupt Controller Type
ACTLR	32	0	rw	0xe000e008: Auxiliary Control
SYST_CSR	32	4	rw	0xe000e010: SysTick Control and Status
SYST_RVR	32	0	rw	0xe000e014: SysTick Reload Value
SYST_CVR	32	0	rw	0xe000e018: SysTick Current Value
SYST_CALIB	32	0	rw	0xe000e01c: SysTick Calibration Value
NVIC_ISER0	32	0	rw	0xe000e100: Interrupt Set Enable 0
NVIC_ICER0	32	0	rw	0xe000e180: Interrupt Clear Enable 0
NVIC_ISPR0	32	0	rw	0xe000e200: Interrupt Set Pending 0
NVIC_ICPR0	32	0	rw	0xe000e280: Interrupt Clear Pending 0
NVIC_IABR0	32	0	r-	0xe000e300: Interrupt Active Bit 0
NVIC_IPR0	32	0	rw	0xe000e400: Interrupt Priority 0
NVIC_IPR1	32	0	rw	0xe000e404: Interrupt Priority 1
NVIC_IPR2	32	0	rw	0xe000e408: Interrupt Priority 2
NVIC_IPR3	32	0	rw	0xe000e40c: Interrupt Priority 3
CPUID	32	410fc241	r-	0xe000ed00: CPUID Base
ICSR	32	1000	rw	0xe000ed04: Interrupt Control and State
VTOR	32	0	rw	0xe000ed08: Vector Table Offset
AIRCR	32	fa050000	rw	0xe000ed0c: Application Interrupt and Reset Control
SCR	32	0	rw	0xe000ed10: System Control
CCR	32	200	rw	0xe000ed14: Configuration and Control
SHPR1	32	0	rw	0xe000ed18: System Handler Priority 1
SHPR2	32	0	rw	0xe000ed1c: System Handler Priority 2
SHPR3	32	0	rw	0xe000ed20: System Handler Priority 3
SHCSR	32	0	rw	0xe000ed24: System Handler Control and State
CFSR	32	0	rw	0xe000ed28: Configurable Fault Status
HFSR	32	0	rw	0xe000ed2c: HardFault Status
DFSR	32	0	rw	0xe000ed30: Debug Fault Status Register
MMAR	32	0	rw	0xe000ed34: MemManage Fault Address
BFAR	32	0	rw	0xe000ed38: BusFault Address
AFSR	32	0	rw	0xe000ed3c: Auxiliary Fault Status
ID_PFR0	32	30	rw	0xe000ed40: Processor Feature 0
ID_PFR1	32	200	rw	0xe000ed44: Processor Feature 1
ID_DFR0	32	0	rw	0xe000ed48: Debug Feature 0
ID_AFR0	32	0	rw	0xe000ed4c: Auxiliary Feature 0
ID_MMFR0	32	30	rw	0xe000ed50: Memory Model Feature 0
ID_MMFR1	32	0	rw	0xe000ed54: Memory Model Feature 1
ID_MMFR2	32	0	rw	0xe000ed58: Memory Model Feature 2
ID_MMFR3	32	0	rw	0xe000ed5c: Memory Model Feature 3
ID_ISAR0	32	11411110	rw	0xe000ed60: Instruction Set Attributes 0
ID_ISAR1	32	2112000	rw	0xe000ed64: Instruction Set Attributes 1
ID_ISAR2	32	20232231	rw	0xe000ed68: Instruction Set Attributes 2
ID_ISAR3	32	11111131	rw	0xe000ed6c: Instruction Set Attributes 3
ID_ISAR4	32	1310132	rw	0xe000ed70: Instruction Set Attributes 4
ID_ISAR5	32	0	rw	0xe000ed74: Instruction Set Attributes 5
CPACR	32	0	rw	0xe000ed88: Coprocessor Access Control
MPU_TYPE	32	800	rw	0xe000ed90: MPU Type

MPU_CONTROL	32	0	rw	0xe000ed94: MPU Control
MPU_RNR	32	0	rw	0xe000ed98: MPU Region Number
MPU_RBAR	32	0	rw	0xe000ed9c: MPU Region Base Address
MPU_RASR	32	0	rw	0xe000eda0: MPU Region Attribute and Size
MPU_RBAR_A1	32	0	rw	0xe000eda4: MPU Region Base Address Alias 1
MPU_RASR_A1	32	0	rw	0xe000eda8: MPU Region Attribute and Size Alias 1
MPU_RBAR_A2	32	0	rw	0xe000edac: MPU Region Base Address Alias 2
MPU_RASR_A2	32	0	rw	0xe000edb0: MPU Region Attribute and Size Alias 2
MPU_RBAR_A3	32	0	rw	0xe000edb4: MPU Region Base Address Alias 3
MPU_RASR_A3	32	0	rw	0xe000edb8: MPU Region Attribute and Size Alias 3
DEMCR	32	0	rw	0xe000edfc: Debug Exception and Monitor Control
STIR	32	-	-w	0xe000ef00: Software Triggered Interrupt
FPCCR	32	c0000000	rw	0xe000ef34: Floating Point Context Control
FPCAR	32	0	rw	0xe000ef38: Floating Point Context Address
FPDSCR	32	0	rw	0xe000ef3c: Floating Point Default Status Control
MVFR0	32	10110021	r-	0xe000ef40: Media and VFP Feature 0
MVFR1	32	11000011	r-	0xe000ef44: Media and VFP Feature 1

Table 13.3: Registers at level 1, group:System

13.1.4 VFP

Registers at level:1, group:VFP

Name	Bits	Initial-Hex	RW	Description
d0	64	0	rw	
d1	64	0	rw	
d2	64	0	rw	
d3	64	0	rw	
d4	64	0	rw	
d5	64	0	rw	
d6	64	0	rw	
d7	64	0	rw	
d8	64	0	rw	
d9	64	0	rw	
d10	64	0	rw	
d11	64	0	rw	
d12	64	0	rw	
d13	64	0	rw	
d14	64	0	rw	
d15	64	0	rw	
FPSCR	32	0	rw	floating-point status/control

Table 13.4: Registers at level 1, group:VFP

13.1.5 Integration_support

Registers at level:1, group:Integration_support

Name	Bits	Initial-Hex	RW	Description
executionPri	32	7fffffff	r-	current execution priority level
stackDomain	64	7fff ecb5d020	r-	stack domain for current execution level
HaltReason	8	0	r-	bit field indicating halt reason
atomicType	8	0	r-	current atomic instruction type (1:atomic, 2:exclusive)

WakeWFINow	8	0	-w	wake up core from WFI state
------------	---	---	----	-----------------------------

Table 13.5: Registers at level 1, group:Integration_support