

# OVP Guide to Using Processor Models

Model specific information for ARM\_ARM7TDMI

---

X-2025.12 December,2025



## Copyright and Proprietary Information Notice

© 2025 Synopsys, Inc. This Synopsys software and all associated documentation are proprietary to Synopsys, Inc. and may only be used pursuant to the terms and conditions of a written license agreement with Synopsys, Inc. All other use, reproduction, modification, or distribution of the Synopsys software or the associated documentation is strictly prohibited.

## Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

## Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

## Trademarks

Synopsys and certain Synopsys product names are trademarks of Synopsys, as set forth at <https://www.synopsys.com/company/legal/trademarks-brands.html>. All other product or company names may be trademarks of their respective owners.

## Free and Open-Source Licensing Notices

If applicable, Free and Open-Source Software (FOSS) licensing notices are available in the product installation.

## Third-Party Links

Any links to third-party websites included in this document are for your convenience only. Synopsys does not endorse and is not responsible for such websites and their practices, including privacy practices, availability, and content.

[www.synopsys.com](http://www.synopsys.com)

## Document Status

|          |                                                 |
|----------|-------------------------------------------------|
| Author   | Synopsys Inc                                    |
| Version  | X-2025.12                                       |
| Filename | OVP_Model_Specific_Information_arm_ARM7TDMI.pdf |
| Created  | 10 December 2025                                |
| Status   | OVP Standard Release                            |

## Model Release Status

This model is included in all general releases.

# Contents

|          |                                                           |           |
|----------|-----------------------------------------------------------|-----------|
| <b>1</b> | <b>Overview</b>                                           | <b>1</b>  |
| 1.1      | Description . . . . .                                     | 1         |
| 1.2      | Licensing . . . . .                                       | 1         |
| 1.3      | Limitations . . . . .                                     | 2         |
| 1.4      | Verification . . . . .                                    | 2         |
| 1.5      | Features . . . . .                                        | 3         |
| 1.5.1    | Core Features . . . . .                                   | 3         |
| 1.5.2    | Memory System . . . . .                                   | 3         |
| 1.6      | Debug Mask . . . . .                                      | 3         |
| 1.7      | AArch32 Unpredictable Behavior . . . . .                  | 3         |
| 1.7.1    | Equal Target Registers . . . . .                          | 3         |
| 1.7.2    | Floating Point Load/Store Multiple Lists . . . . .        | 3         |
| 1.7.3    | Floating Point VLD[2-4]/VST[2-4] Range Overflow . . . . . | 4         |
| 1.7.4    | If-Then (IT) Block Constraints . . . . .                  | 4         |
| 1.7.5    | Use of R13 . . . . .                                      | 4         |
| 1.7.6    | Use of R15 . . . . .                                      | 4         |
| 1.7.7    | Unpredictable Instructions in Some Modes . . . . .        | 4         |
| 1.8      | Integration Support . . . . .                             | 5         |
| 1.8.1    | Halt Reason Introspection . . . . .                       | 5         |
| 1.8.2    | Automatic WFI Wake Up . . . . .                           | 5         |
| 1.8.3    | System Register Access Monitor . . . . .                  | 5         |
| 1.8.4    | System Register Implementation . . . . .                  | 6         |
| <b>2</b> | <b>Configuration</b>                                      | <b>7</b>  |
| 2.1      | Location . . . . .                                        | 7         |
| 2.2      | GDB Path . . . . .                                        | 7         |
| 2.3      | Semi-Host Library . . . . .                               | 7         |
| 2.4      | Processor Endian-ness . . . . .                           | 7         |
| 2.5      | QuantumLeap Support . . . . .                             | 7         |
| 2.6      | Processor ELF code . . . . .                              | 7         |
| <b>3</b> | <b>All Variants in this model</b>                         | <b>8</b>  |
| <b>4</b> | <b>Bus Master Ports</b>                                   | <b>12</b> |
| <b>5</b> | <b>Bus Slave Ports</b>                                    | <b>13</b> |
| <b>6</b> | <b>Net Ports</b>                                          | <b>14</b> |

|           |                                       |           |
|-----------|---------------------------------------|-----------|
| <b>7</b>  | <b>FIFO Ports</b>                     | <b>15</b> |
| <b>8</b>  | <b>Formal Parameters</b>              | <b>16</b> |
| 8.1       | Parameter values and limits . . . . . | 18        |
| <b>9</b>  | <b>Execution Modes</b>                | <b>20</b> |
| <b>10</b> | <b>Exceptions</b>                     | <b>21</b> |
| <b>11</b> | <b>Hierarchy of the model</b>         | <b>22</b> |
| 11.1      | Level 1: CPU . . . . .                | 22        |
| <b>12</b> | <b>Model Commands</b>                 | <b>23</b> |
| 12.1      | Level 1: CPU . . . . .                | 23        |
| 12.1.1    | debugflags . . . . .                  | 23        |
| 12.1.2    | isync . . . . .                       | 23        |
| 12.1.3    | itrace . . . . .                      | 23        |
| 12.1.4    | listSysRegsAA32 . . . . .             | 24        |
| 12.1.4.1  | Argument description . . . . .        | 24        |
| <b>13</b> | <b>Registers</b>                      | <b>25</b> |
| 13.1      | Level 1: CPU . . . . .                | 25        |
| 13.1.1    | Core . . . . .                        | 25        |
| 13.1.2    | Control . . . . .                     | 25        |
| 13.1.3    | User . . . . .                        | 25        |
| 13.1.4    | FIQ . . . . .                         | 26        |
| 13.1.5    | IRQ . . . . .                         | 26        |
| 13.1.6    | Supervisor . . . . .                  | 26        |
| 13.1.7    | Undefined . . . . .                   | 26        |
| 13.1.8    | Abort . . . . .                       | 27        |
| 13.1.9    | Coprocessor_32_bit . . . . .          | 27        |
| 13.1.10   | Integration_support . . . . .         | 27        |

# Chapter 1

## Overview

This document provides the details of an OVP Fast Processor Model variant.

OVP Fast Processor Models are written in C and provide a C API for use in C based platforms. The models also provide a native interface for use in SystemC TLM2 platforms.

The models are written using the OVP VMI API that provides a Virtual Machine Interface that defines the behavior of the processor. The VMI API makes a clear line between model and simulator allowing very good optimization and world class high speed performance. Most models are provided as a binary shared object and also as source. This allows the download and use of the model binary or the use of the source to explore and modify the model.

The models are run through an extensive QA and regression testing process and most model families are validated using technology provided by the processor IP owners. There is a companion document (OVP Guide to Using Processor Models) which explains the general concepts of OVP Fast Processor Models and their use. It is downloadable from the OVPworld website documentation pages.

### 1.1 Description

ARM Processor Model

### 1.2 Licensing

Usage of binary model under license governing simulator usage.

Note that for models of ARM CPUs the license includes the following terms:

Licensee is granted a non-exclusive, worldwide, non-transferable, revocable licence to:

If no source is being provided to the Licensee: use and copy only (no modifications rights are granted) the model for the sole purpose of designing, developing, analyzing, debugging, testing, verifying, validating and optimizing software which: (a) (i) is for ARM based systems; and (ii) does not incorporate the ARM Models or any part thereof; and (b) such ARM Models may not be used

to emulate an ARM based system to run application software in a production or live environment.

If source code is being provided to the Licensee: use, copy and modify the model for the sole purpose of designing, developing, analyzing, debugging, testing, verifying, validating and optimizing software which: (a) (i) is for ARM based systems; and (ii) does not incorporate the ARM Models or any part thereof; and (b) such ARM Models may not be used to emulate an ARM based system to run application software in a production or live environment.

In the case of any Licensee who is either or both an academic or educational institution the purposes shall be limited to internal use.

Except to the extent that such activity is permitted by applicable law, Licensee shall not reverse engineer, decompile, or disassemble this model. If this model was provided to Licensee in Europe, Licensee shall not reverse engineer, decompile or disassemble the Model for the purposes of error correction.

The License agreement does not entitle Licensee to manufacture in silicon any product based on this model.

The License agreement does not entitle Licensee to use this model for evaluating the validity of any ARM patent.

Source of model available under separate Imperas Software License Agreement.

## 1.3 Limitations

Instruction pipelines are not modeled in any way. All instructions are assumed to complete immediately. This means that instruction barrier instructions (e.g. ISB, CP15ISB) are treated as NOPs, with the exception of any undefined instruction behavior, which is modeled. The model does not implement speculative fetch behavior. The branch cache is not modeled.

Caches and write buffers are not modeled in any way. All loads, fetches and stores complete immediately and in order, and are fully synchronous (as if the memory was of Strongly Ordered or Device-nGnRnE type). Data barrier instructions (e.g. DSB, CP15DSB) are treated as NOPs, with the exception of any undefined instruction behavior, which is modeled. Cache manipulation instructions are implemented as NOPs, with the exception of any undefined instruction behavior, which is modeled.

Real-world timing effects are not modeled: all instructions are assumed to complete in a single cycle.

## 1.4 Verification

Models have been extensively tested by Imperas. ARM7TDMI models have been successfully used by customers to simulate ucLinux on Atmel virtual platforms.

## 1.5 Features

The precise set of implemented features in the model is defined by ID registers. Use overrides to modify these if required (for example `override_PFR0` or `override_AA64PFR0_EL1`).

### 1.5.1 Core Features

Thumb instructions are supported.

### 1.5.2 Memory System

## 1.6 Debug Mask

It is possible to enable model debug features in various categories. This can be done statically using the “`override_debugMask`” parameter, or dynamically using the “`debugflags`” command. Enabled debug features are specified using a bitmask value, as follows:

Value 0x080: enable debugging of all system register accesses.

Value 0x100: enable debugging of all traps of system register accesses.

Value 0x200: enable verbose debugging of other miscellaneous behavior (for example, the reason why a particular instruction is undefined).

All other bits in the debug bitmask are reserved and must not be set to non-zero values.

## 1.7 AArch32 Unpredictable Behavior

Many AArch32 instruction behaviors are described in the ARM ARM as **CONSTRAINED UNPREDICTABLE**. This section describes how such situations are handled by this model.

### 1.7.1 Equal Target Registers

Some instructions allow the specification of two target registers (for example, double-width **SMULL**, or some **VMOV** variants), and such instructions are **CONSTRAINED UNPREDICTABLE** if the same target register is specified in both positions. In this model, such instructions are treated as **UNDEFINED**.

### 1.7.2 Floating Point Load/Store Multiple Lists

Instructions that load or store a list of floating point registers (e.g. **VSTM**, **VLDM**, **VPUSH**, **VPOP**) are **CONSTRAINED UNPREDICTABLE** if either the uppermost register in the specified range is greater than 32 or (for 64-bit registers) if more than 16 registers are specified. In this model, such instructions are treated as **UNDEFINED**.



### 1.7.3 Floating Point VLD[2-4]/VST[2-4] Range Overflow

Instructions that load or store a fixed number of floating point registers (e.g. VST2, VLD2) are CONSTRAINED UNPREDICTABLE if the upper register bound exceeds the number of implemented floating point registers. In this model, these instructions load and store using modulo 32 indexing (consistent with AArch64 instructions with similar behavior).

### 1.7.4 If-Then (IT) Block Constraints

Where the behavior of an instruction in an if-then (IT) block is described as CONSTRAINED UNPREDICTABLE, this model treats that instruction as UNDEFINED.

### 1.7.5 Use of R13

In architecture variants before ARMv8, use of R13 was described as CONSTRAINED UNPREDICTABLE in many circumstances. From ARMv8, most of these situations are no longer considered unpredictable. This model allows R13 to be used like any other GPR, consistent with the ARMv8 specification.

### 1.7.6 Use of R15

Use of R15 is described as CONSTRAINED UNPREDICTABLE in many circumstances. This model allows such use to be configured using the parameter “unpredictableR15” as follows:

Value “undefined”: any reference to R15 in such a situation is treated as UNDEFINED;

Value “nop”: any reference to R15 in such a situation causes the instruction to be treated as a NOP;

Value “raz\_wi”: any reference to R15 in such a situation causes the instruction to be treated as a RAZ/WI (that is, R15 is read as zero and write-ignored);

Value “execute”: any reference to R15 in such a situation is executed using the current value of R15 on read, and writes to R15 are allowed (but are not interworking).

Value “assert”: any reference to R15 in such a situation causes the simulation to halt with an assertion message (allowing any such unpredictable uses to be easily identified).

In this variant, the default value of “unpredictableR15” is “execute”.

### 1.7.7 Unpredictable Instructions in Some Modes

Some instructions are described as CONSTRAINED UNPREDICTABLE in some modes only (for example, MSR accessing SPSR is CONSTRAINED UNPREDICTABLE in User and System modes). This model allows such use to be configured using the parameter “unpredictableModal”, which can have values “undefined” or “nop”. See the previous section for more information about the meaning of these values.

In this variant, the default value of “unpredictableModal” is “nop”.

## 1.8 Integration Support

This model implements a number of non-architectural pseudo-registers and other features to facilitate integration.

### 1.8.1 Halt Reason Introspection

An artifact register HaltReason can be read to determine the reason or reasons that a processor is halted. This register is a bitfield, with the following encoding: bit 0 indicates the processor has executed a wait-for-event (WFE) instruction; bit 1 indicates the processor has executed a wait-for-interrupt (WFI) instruction; and bit 2 indicates the processor is held in reset.

### 1.8.2 Automatic WFI Wake Up

A simulation environment can cause a core to wake up from the WFI state by writing to the artifact register WakeWFINow.

### 1.8.3 System Register Access Monitor

If parameter “enableSystemMonitorBus” is True, an artifact 32-bit bus “SystemMonitor” is enabled for each PE. Every system register read or write by that PE is then visible as a read or write on this artifact bus, and can therefore be monitored using callbacks installed in the client environment (use opBusReadMonitorAdd/opBusWriteMonitorAdd or icmAddBusReadCallback-/icmAddBusWriteCallback, depending on the client API). The format of the address on the bus is as follows:

bits 31:26 - zero

bit 25 - 1 if AArch64 access, 0 if AArch32 access

bit 24 - 1 if non-secure access, 0 if secure access

bits 23:20 - CRm value

bits 19:16 - CRn value

bits 15:12 - op2 value

bits 11:8 - op1 value

bits 7:4 - op0 value (AArch64) or coprocessor number (AArch32)

bits 3:0 - zero

As an example, to view non-secure writes to writes to CNTFRQ\_EL0 in AArch64 state, install a write monitor on address range 0x020e0330:0x020e0333.

### 1.8.4 System Register Implementation

If parameter “enableSystemBus” is True, an artifact 32-bit bus “System” is enabled for each PE. Slave callbacks installed on this bus can be used to implement modified system register behavior (use opBusSlaveNew or icmMapExternalMemory, depending on the client API). The format of the address on the bus is the same as for the system monitor bus, described above.

## Chapter 2

# Configuration

### 2.1 Location

This model's VLVN is `arm.ovpworld.org/processor/arm/1.0`.

The model source is usually at:

`$IMPERAS_HOME/ImperasLib/source/arm.ovpworld.org/processor/arm/1.0`

The model binary is usually at:

`$IMPERAS_HOME/lib/$IMPERAS_ARCH/ImperasLib/arm.ovpworld.org/processor/arm/1.0`

### 2.2 GDB Path

The default GDB for this model is: `$IMPERAS_HOME/lib/$IMPERAS_ARCH/gdb/arm-none-eabi-gdb`.

### 2.3 Semi-Host Library

The default semi-host library file is `arm.ovpworld.org/semihosting/armNewlib/1.0`

### 2.4 Processor Endian-ness

This is a LITTLE endian model.

### 2.5 QuantumLeap Support

This processor is qualified to run in a QuantumLeap enabled simulator.

### 2.6 Processor ELF code

The ELF code supported by this model is: `0x28`.

## Chapter 3

# All Variants in this model

This model has these variants

| Variant     | Description                  |
|-------------|------------------------------|
| ARMv4T      |                              |
| ARMv4xM     |                              |
| ARMv4       |                              |
| ARMv4TxM    |                              |
| ARMv5xM     |                              |
| ARMv5       |                              |
| ARMv5TxM    |                              |
| ARMv5T      |                              |
| ARMv5TExP   |                              |
| ARMv5TE     |                              |
| ARMv5TEJ    |                              |
| ARMv6       |                              |
| ARMv6K      |                              |
| ARMv6T2     |                              |
| ARMv6KZ     |                              |
| ARMv7       |                              |
| ARM7TDMI    | (described in this document) |
| ARM7EJ-S    |                              |
| ARM720T     |                              |
| ARM920T     |                              |
| ARM922T     |                              |
| ARM926EJ-S  |                              |
| ARM940T     |                              |
| ARM946E     |                              |
| ARM966E     |                              |
| ARM968E-S   |                              |
| ARM1020E    |                              |
| ARM1022E    |                              |
| ARM1026EJ-S |                              |
| ARM1136J-S  |                              |
| ARM1156T2-S |                              |

|                 |  |
|-----------------|--|
| ARM1176JZ-S     |  |
| Cortex-R4       |  |
| Cortex-R4F      |  |
| Cortex-R5MPx1   |  |
| Cortex-R5MPx2   |  |
| Cortex-R8MPx1   |  |
| Cortex-R8MPx2   |  |
| Cortex-R8MPx3   |  |
| Cortex-R8MPx4   |  |
| Cortex-R52MPx1  |  |
| Cortex-R52MPx2  |  |
| Cortex-R52MPx3  |  |
| Cortex-R52MPx4  |  |
| Cortex-R52+MPx1 |  |
| Cortex-R52+MPx2 |  |
| Cortex-R52+MPx3 |  |
| Cortex-R52+MPx4 |  |
| Cortex-R82MPx1  |  |
| Cortex-R82MPx2  |  |
| Cortex-R82MPx3  |  |
| Cortex-R82MPx4  |  |
| Cortex-R82MPx5  |  |
| Cortex-R82MPx6  |  |
| Cortex-R82MPx7  |  |
| Cortex-R82MPx8  |  |
| Cortex-A5UP     |  |
| Cortex-A5MPx1   |  |
| Cortex-A5MPx2   |  |
| Cortex-A5MPx3   |  |
| Cortex-A5MPx4   |  |
| Cortex-A8       |  |
| Cortex-A9UP     |  |
| Cortex-A9MPx1   |  |
| Cortex-A9MPx2   |  |
| Cortex-A9MPx3   |  |
| Cortex-A9MPx4   |  |
| Cortex-A7UP     |  |
| Cortex-A7MPx1   |  |
| Cortex-A7MPx2   |  |
| Cortex-A7MPx3   |  |
| Cortex-A7MPx4   |  |
| Cortex-A15UP    |  |
| Cortex-A15MPx1  |  |
| Cortex-A15MPx2  |  |
| Cortex-A15MPx3  |  |

|                  |  |
|------------------|--|
| Cortex-A15MPx4   |  |
| Cortex-A17MPx1   |  |
| Cortex-A17MPx2   |  |
| Cortex-A17MPx3   |  |
| Cortex-A17MPx4   |  |
| AArch32          |  |
| AArch64          |  |
| Cortex-A32MPx1   |  |
| Cortex-A32MPx2   |  |
| Cortex-A32MPx3   |  |
| Cortex-A32MPx4   |  |
| Cortex-A35MPx1   |  |
| Cortex-A35MPx2   |  |
| Cortex-A35MPx3   |  |
| Cortex-A35MPx4   |  |
| Cortex-A53MPx1   |  |
| Cortex-A53MPx2   |  |
| Cortex-A53MPx3   |  |
| Cortex-A53MPx4   |  |
| Cortex-A55MPx1   |  |
| Cortex-A55MPx2   |  |
| Cortex-A55MPx3   |  |
| Cortex-A55MPx4   |  |
| Cortex-A57MPx1   |  |
| Cortex-A57MPx2   |  |
| Cortex-A57MPx3   |  |
| Cortex-A57MPx4   |  |
| Cortex-A65AEMPx1 |  |
| Cortex-A65AEMPx2 |  |
| Cortex-A65AEMPx3 |  |
| Cortex-A65AEMPx4 |  |
| Cortex-A72MPx1   |  |
| Cortex-A72MPx2   |  |
| Cortex-A72MPx3   |  |
| Cortex-A72MPx4   |  |
| Cortex-A73MPx1   |  |
| Cortex-A73MPx2   |  |
| Cortex-A73MPx3   |  |
| Cortex-A73MPx4   |  |
| Cortex-A75MPx1   |  |
| Cortex-A75MPx2   |  |
| Cortex-A75MPx3   |  |
| Cortex-A75MPx4   |  |
| Cortex-A76MPx1   |  |
| Cortex-A76MPx2   |  |

|                |  |
|----------------|--|
| Cortex-A76MPx3 |  |
| Cortex-A76MPx4 |  |
| Cortex-A78MPx1 |  |
| Cortex-A78MPx2 |  |
| Cortex-A78MPx3 |  |
| Cortex-A78MPx4 |  |
| MultiCluster   |  |

Table 3.1: All Variants in this model



## Chapter 4

# Bus Master Ports

This model has these bus master ports.

| <b>Name</b> | min | max | Connect?  | Description |
|-------------|-----|-----|-----------|-------------|
| INSTRUCTION | 32  | 32  | mandatory |             |
| DATA        | 32  | 32  | optional  |             |

Table 4.1: Bus Master Ports

## Chapter 5

# Bus Slave Ports

This model has no bus slave ports.

## Chapter 6

# Net Ports

This model has these net ports.

| Name       | Type   | Connect? | Description                                                      |
|------------|--------|----------|------------------------------------------------------------------|
| reset      | input  | optional | Processor reset, active high                                     |
| fiq        | input  | optional | FIQ interrupt, active high (negation of nFIQ)                    |
| irq        | input  | optional | IRQ interrupt, active high (negation of nIRQ)                    |
| sei        | input  | optional | System error interrupt, active on rising edge (negation of nSEI) |
| haltReason | output | optional | Indicates why core is halted                                     |

Table 6.1: Net Ports

## Chapter 7

# FIFO Ports

This model has no FIFO ports.

## Chapter 8

# Formal Parameters

| Name                   | Type        | Description                                                                                                                                                               |
|------------------------|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| verbose                | Boolean     | Specify verbosity of output                                                                                                                                               |
| suppressCPSWarnings    | Boolean     | Suppress duplicate warnings generated using ARM_CP_CPSI or ARM_CP_CPSD message identifiers                                                                                |
| showHiddenRegs         | Boolean     | Show hidden registers during register tracing                                                                                                                             |
| UAL                    | Boolean     | Disassemble using UAL syntax                                                                                                                                              |
| enableSystemBus        | Boolean     | Add 32-bit artifact System bus port, allowing system registers to be externally implemented                                                                               |
| enableSystemMonitorBus | Boolean     | Add 32-bit artifact SystemMonitor bus port, allowing system register accesses to be externally monitored                                                                  |
| compatibility          | Enumeration | Specify compatibility mode                                                                                                                                                |
|                        | ISA         |                                                                                                                                                                           |
|                        | gdb         |                                                                                                                                                                           |
|                        | nopSVC      |                                                                                                                                                                           |
| unpredictableR15       | Enumeration | Specify behavior for UNPREDICTABLE uses of AArch32 R15 register                                                                                                           |
|                        | undefined   |                                                                                                                                                                           |
|                        | nop         |                                                                                                                                                                           |
|                        | raz_wi      |                                                                                                                                                                           |
|                        | execute     |                                                                                                                                                                           |
|                        | assert      |                                                                                                                                                                           |
| unpredictableModal     | Enumeration | Specify behavior for UNPREDICTABLE instructions in certain AArch32 modes (for example, MRS using SPSR in System mode)                                                     |
|                        | undefined   |                                                                                                                                                                           |
|                        | nop         |                                                                                                                                                                           |
|                        | assert      |                                                                                                                                                                           |
| maxSIMDUnroll          | Uns32       | If SIMD operations are supported, specify the maximum number of parallel SIMD operations to unroll (unrolled operations can be faster, but produce more verbose JIT code) |
| override_debugMask     | Uns32       | Specifies debug mask, enabling debug output for model components                                                                                                          |
| ASIDCacheSize          | Uns32       | Specifies the number of different ASIDs for which TLB entries are cached; a value of 0 implies no limit                                                                   |
| thumbNoCond            | Boolean     | Specify whether trapped Thumb instructions set CV=1 and COND field in syndrome (if False, both are zero)                                                                  |

|                                |         |                                                                                                                                                   |
|--------------------------------|---------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| enableHostAtomics              | Boolean | Enable use of host atomic instructions to emulate load/store exclusive operations (not architecturally accurate, accelerates parallel simulation) |
| enableWFEHostAtomics           | Boolean | Enable WFE and SEV instructions when using host atomics (does nothing otherwise)                                                                  |
| override_fcsePresent           | Boolean | Specifies that FCSE is present (if true)                                                                                                          |
| allowMSRToCurrentBank          | Boolean | Allow access to the current mode registers via the MSR/MRS (Banked Register) instructions                                                         |
| override_SCTLR_V               | Boolean | Override SCTLR.V with the passed value (enables high vectors; also configurable using VINITHI pin)                                                |
| override_SCTLR_IE              | Boolean | Override SCTLR.IE with the passed value (configures instruction endianness; also configurable using CFGIE pin)                                    |
| override_SCTLR_EE              | Boolean | Override SCTLR.EE with the passed value (configures exception data endianness; also configurable using CFGEE pin)                                 |
| override_SCTLR_TE              | Boolean | Override SCTLR.TE with the passed value (configures Thumb state for exception handling; also configurable using TEINIT pin)                       |
| override_SCTLR_NMFI            | Boolean | Override SCTLR.NMFI with the passed value (configures NMFI state for exception handling; also configurable using CFGNMFI pin)                     |
| override_SCTLR_CP15BEN_Present | Boolean | Enable ARMv7 SCTLR.CP15BEN bit (CP15 barrier enable)                                                                                              |
| override_MIDR                  | Uns32   | Override MIDR/MIDR_EL1 register                                                                                                                   |
| override_CTR                   | Uns32   | Override CTR/CTR_EL0 register                                                                                                                     |
| override_TLBTR                 | Uns32   | Override TLBTR register                                                                                                                           |
| override_CLIDR                 | Uns32   | Override CLIDR/CLIDR_EL1 register                                                                                                                 |
| override_AIDR                  | Uns32   | Override AIDR/AIDR_EL1 register                                                                                                                   |
| override_ERG                   | Uns32   | Specifies exclusive reservation granule                                                                                                           |
| override_STRoffsetPC12         | Boolean | Specifies that STR/STR of PC should do so with 12:byte offset from the current instruction (if true), otherwise an 8:byte offset is used          |
| override_fcseRequiresMMU       | Boolean | Specifies that FCSE is active only when MMU is enabled (if true)                                                                                  |
| override_ignoreBadCp15         | Boolean | Specifies whether invalid coprocessor 15 access should be ignored (if true) or cause Invalid Instruction exceptions (if false)                    |
| override_SGIDisable            | Boolean | Override whether GIC SGIs may be disabled (if true) or are permanently enabled (if false)                                                         |
| override_condUndefined         | Boolean | Force undefined instructions to take Undefined Instruction exception even if they are conditional                                                 |
| override_deviceStrongAligned   | Boolean | Force accesses to Device and Strongly Ordered regions to be aligned                                                                               |
| override_Control_V             | Boolean | Override SCTLR.V with the passed value (deprecated, use override_SCTLR.V)                                                                         |
| override_MainId                | Uns32   | Override MIDR register (deprecated, use override_MIDR)                                                                                            |
| override_CacheType             | Uns32   | Override CTR register (deprecated, use override_CTR)                                                                                              |
| override_TLBType               | Uns32   | Override TLBTR register (deprecated, use override_TLBTR)                                                                                          |

Table 8.1: Parameters that can be set in: CPU

## 8.1 Parameter values and limits

These are the formal parameter limits and actual parameter values

| Name                           | Min | Max        | Default    | Actual     |
|--------------------------------|-----|------------|------------|------------|
| <b>(Others)</b>                |     |            |            |            |
| variant                        |     |            |            | ARM7TDMI   |
| verbose                        |     |            | t          | t          |
| suppressCPSWarnings            |     |            | f          | f          |
| showHiddenRegs                 |     |            | f          | f          |
| UAL                            |     |            | t          | t          |
| enableSystemBus                |     |            | f          | f          |
| enableSystemMonitorBus         |     |            | f          | f          |
| compatibility                  |     |            | ISA        | ISA        |
| unpredictableR15               |     |            | execute    | execute    |
| unpredictableModal             |     |            | nop        | nop        |
| maxSIMDUnroll                  | 1   | 16         | 2          | 2          |
| override_debugMask             | 0   | 0xffffffff | 0          | 0          |
| ASIDCacheSize                  | 0   | 0x100      | 8          | 8          |
| thumbNoCond                    |     |            | f          | f          |
| enableHostAtomics              |     |            | f          | f          |
| enableWFEHostAtomics           |     |            | f          | f          |
| endian                         |     |            | none       | none       |
| override_fcsePresent           |     |            | f          | f          |
| allowMSRToCurrentBank          |     |            | f          | f          |
| override_SCTLR_V               |     |            | f          | f          |
| override_SCTLR_IE              |     |            | f          | f          |
| override_SCTLR_EE              |     |            | f          | f          |
| override_SCTLR_TE              |     |            | f          | f          |
| override_SCTLR_NMFI            |     |            | f          | f          |
| override_SCTLR_CP15BEN_Present |     |            | f          | f          |
| override_MIDR                  | 0   | 0xffffffff | 0x41807000 | 0x41807000 |
| override_CTR                   | 0   | 0xffffffff | 0          | 0          |
| override_TLBTR                 | 0   | 0xffffffff | 0          | 0          |
| override_CLIDR                 | 0   | 0xffffffff | 0          | 0          |
| override_AIDR                  | 0   | 0xffffffff | 0          | 0          |
| override_ERG                   | 3   | 11         | 3          | 3          |
| override_STROffsetPC12         |     |            | t          | t          |
| override_fcseRequiresMMU       |     |            | f          | f          |
| override_ignoreBadCp15         |     |            | t          | t          |
| override_SGIDisable            |     |            | f          | f          |
| override_condUndefined         |     |            | f          | f          |

|                              |   |            |            |            |
|------------------------------|---|------------|------------|------------|
| override_deviceStrongAligned |   |            | f          | f          |
| override_Control_V           |   |            | f          | f          |
| override_MainId              | 0 | 0xffffffff | 0x41807000 | 0x41807000 |
| override_CacheType           | 0 | 0xffffffff | 0          | 0          |
| override_TLBType             | 0 | 0xffffffff | 0          | 0          |

Table 8.2: Parameter values and limits



## Chapter 9

# Execution Modes

| Mode       | Code |
|------------|------|
| User       | 16   |
| FIQ        | 17   |
| IRQ        | 18   |
| Supervisor | 19   |
| Abort      | 23   |
| Undefined  | 27   |
| System     | 31   |

Table 9.1: Modes implemented in: CPU

## Chapter 10

# Exceptions

| <b>Exception</b> | Code |
|------------------|------|
| Reset            | 0    |
| Undefined        | 1    |
| SupervisorCall   | 2    |
| PrefetchAbort    | 5    |
| DataAbort        | 6    |
| IRQ              | 8    |
| FIQ              | 9    |

Table 10.1: Exceptions implemented in: CPU

# Chapter 11

## Hierarchy of the model

A CPU core may be configured to instance many processors of a Symmetrical Multi Processor (SMP). A CPU core may also have sub elements within a processor, for example hardware threading blocks.

OVP processor models can be written to include SMP blocks and to have many levels of hierarchy. Some OVP CPU models may have a fixed hierarchy, and some may be configured by settings in a configuration register. Please see the register definitions of this model.

This model documentation shows the settings and hierarchy of the default settings for this model variant.

### 11.1 Level 1: CPU

This level in the model hierarchy has 4 commands.

This level in the model hierarchy has 10 register groups:

| Group name          | Registers |
|---------------------|-----------|
| Core                | 16        |
| Control             | 3         |
| User                | 7         |
| FIQ                 | 8         |
| IRQ                 | 3         |
| Supervisor          | 3         |
| Undefined           | 3         |
| Abort               | 3         |
| Coprocessor_32_bit  | 2         |
| Integration_support | 6         |

Table 11.1: Register groups

This level in the model hierarchy has no children.

# Chapter 12

## Model Commands

A Processor model can implement one or more **Model Commands** available to be invoked from the simulator command line, from the OP API or from the Imperas Multiprocessor Debugger.

### 12.1 Level 1: CPU

#### 12.1.1 debugflags

show or modify the processor debug flags

| Argument | Type    | Description                                                 |
|----------|---------|-------------------------------------------------------------|
| -get     | Boolean | print current processor flags value                         |
| -mask    | Boolean | print valid debug flag bits                                 |
| -set     | Int32   | new processor flags (only flags 0x000003e4 can be modified) |

Table 12.1: debugflags command arguments

#### 12.1.2 isync

specify instruction address range for synchronous execution

| Argument   | Type  | Description                                  |
|------------|-------|----------------------------------------------|
| -addresshi | Uns64 | end address of synchronous execution range   |
| -addresslo | Uns64 | start address of synchronous execution range |

Table 12.2: isync command arguments

#### 12.1.3 itrace

enable or disable instruction tracing

| Argument | Type   | Description                                                                                                                       |
|----------|--------|-----------------------------------------------------------------------------------------------------------------------------------|
| -access  | String | show memory accesses by this instruction. Argument can be any combination of X (execute), A (load or store access) and S (system) |

|                   |         |                                                                                                                                                       |
|-------------------|---------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| -after            | Uns64   | apply after this many instructions                                                                                                                    |
| -enable           | Boolean | enable instruction tracing                                                                                                                            |
| -full             | Boolean | turn on all trace features                                                                                                                            |
| -instructioncount | Boolean | include the instruction number in each trace                                                                                                          |
| -memory           | String  | (Alias for access). show memory accesses by this instruction. Argument can be any combination of X (execute), A (load or store access) and S (system) |
| -mode             | Boolean | show processor mode changes                                                                                                                           |
| -off              | Boolean | disable instruction tracing                                                                                                                           |
| -on               | Boolean | enable instruction tracing                                                                                                                            |
| -processorname    | Boolean | Include processor name in all trace lines                                                                                                             |
| -registerchange   | Boolean | show registers changed by this instruction                                                                                                            |
| -registers        | Boolean | show registers after each trace                                                                                                                       |

Table 12.3: itrace command arguments

## 12.1.4 listSysRegsAA32

### 12.1.4.1 Argument description

List all AArch32 system registers

# Chapter 13

## Registers

### 13.1 Level 1: CPU

#### 13.1.1 Core

Registers at level:1, type:CPU group:Core

| Name | Bits | Initial-Hex | RW | Description     |
|------|------|-------------|----|-----------------|
| r0   | 32   | 0           | rw |                 |
| r1   | 32   | 0           | rw |                 |
| r2   | 32   | 0           | rw |                 |
| r3   | 32   | 0           | rw |                 |
| r4   | 32   | 0           | rw |                 |
| r5   | 32   | 0           | rw |                 |
| r6   | 32   | 0           | rw |                 |
| r7   | 32   | 0           | rw |                 |
| r8   | 32   | 0           | rw |                 |
| r9   | 32   | 0           | rw |                 |
| r10  | 32   | 0           | rw |                 |
| r11  | 32   | 0           | rw | frame pointer   |
| r12  | 32   | 0           | rw |                 |
| sp   | 32   | 0           | rw | stack pointer   |
| lr   | 32   | 0           | rw |                 |
| pc   | 32   | 0           | rw | program counter |

Table 13.1: Registers at level 1, type:CPU group:Core

#### 13.1.2 Control

Registers at level:1, type:CPU group:Control

| Name | Bits | Initial-Hex | RW | Description                  |
|------|------|-------------|----|------------------------------|
| fps  | 32   | 0           | rw | archaic FPSCR view (for gdb) |
| cpsr | 32   | d3          | rw |                              |
| spsr | 32   | 0           | rw |                              |

Table 13.2: Registers at level 1, type:CPU group:Control

#### 13.1.3 User

Registers at level:1, type:CPU group:User

| Name    | Bits | Initial-Hex | RW | Description |
|---------|------|-------------|----|-------------|
| r8_usr  | 32   | 0           | rw |             |
| r9_usr  | 32   | 0           | rw |             |
| r10_usr | 32   | 0           | rw |             |
| r11_usr | 32   | 0           | rw |             |
| r12_usr | 32   | 0           | rw |             |
| sp_usr  | 32   | 0           | rw |             |
| lr_usr  | 32   | 0           | rw |             |

Table 13.3: Registers at level 1, type:CPU group:User

### 13.1.4 FIQ

Registers at level:1, type:CPU group:FIQ

| Name     | Bits | Initial-Hex | RW | Description |
|----------|------|-------------|----|-------------|
| r8_fiq   | 32   | 0           | rw |             |
| r9_fiq   | 32   | 0           | rw |             |
| r10_fiq  | 32   | 0           | rw |             |
| r11_fiq  | 32   | 0           | rw |             |
| r12_fiq  | 32   | 0           | rw |             |
| sp_fiq   | 32   | 0           | rw |             |
| lr_fiq   | 32   | 0           | rw |             |
| spsr_fiq | 32   | 0           | rw |             |

Table 13.4: Registers at level 1, type:CPU group:FIQ

### 13.1.5 IRQ

Registers at level:1, type:CPU group:IRQ

| Name     | Bits | Initial-Hex | RW | Description |
|----------|------|-------------|----|-------------|
| sp_irq   | 32   | 0           | rw |             |
| lr_irq   | 32   | 0           | rw |             |
| spsr_irq | 32   | 0           | rw |             |

Table 13.5: Registers at level 1, type:CPU group:IRQ

### 13.1.6 Supervisor

Registers at level:1, type:CPU group:Supervisor

| Name     | Bits | Initial-Hex | RW | Description |
|----------|------|-------------|----|-------------|
| sp_svc   | 32   | 0           | rw |             |
| lr_svc   | 32   | 0           | rw |             |
| spsr_svc | 32   | 0           | rw |             |

Table 13.6: Registers at level 1, type:CPU group:Supervisor

### 13.1.7 Undefined

Registers at level:1, type:CPU group:Undefined

| Name | Bits | Initial-Hex | RW | Description |
|------|------|-------------|----|-------------|
|------|------|-------------|----|-------------|

|            |    |   |    |  |
|------------|----|---|----|--|
| sp_undef   | 32 | 0 | rw |  |
| lr_undef   | 32 | 0 | rw |  |
| spsr_undef | 32 | 0 | rw |  |

Table 13.7: Registers at level 1, type:CPU group:Undefined

### 13.1.8 Abort

Registers at level:1, type:CPU group:Abort

| Name     | Bits | Initial-Hex | RW | Description |
|----------|------|-------------|----|-------------|
| sp_abt   | 32   | 0           | rw |             |
| lr_abt   | 32   | 0           | rw |             |
| spsr_abt | 32   | 0           | rw |             |

Table 13.8: Registers at level 1, type:CPU group:Abort

### 13.1.9 Coprocessor\_32\_bit

Registers at level:1, type:CPU group:Coprocessor\_32\_bit

| Name  | Bits | Initial-Hex | RW | Description    |
|-------|------|-------------|----|----------------|
| MIDR  | 32   | 41807000    | r- | Main ID        |
| SCTLR | 32   | 70          | rw | System Control |

Table 13.9: Registers at level 1, type:CPU group:Coprocessor\_32\_bit

### 13.1.10 Integration\_support

Registers at level:1, type:CPU group:Integration\_support

| Name         | Bits | Initial-Hex | RW | Description                                             |
|--------------|------|-------------|----|---------------------------------------------------------|
| transactPL   | 32   | 1           | r- | privilege level of current memory transaction           |
| transactAT   | 32   | 0           | r- | current memory transaction type: PA=1, VA=0             |
| HaltReason   | 8    | 0           | r- | bit field indicating halt reason                        |
| atomicType   | 8    | 0           | r- | current atomic instruction type (1:atomic, 2:exclusive) |
| WakeWFINow   | 8    | 0           | -w | wake up core from WFI state                             |
| ambaResponse | 64   | 0           | rw | external AMBA-PV response                               |

Table 13.10: Registers at level 1, type:CPU group:Integration\_support