
1. Go to:


http://fr.mygeoposition.com/

and note your position (latitude + longitude)


- 2. Power your cociclo
- 3. Log in to the 'cociclo' access point, the password is 'placecommune'



4. Open a new web page or enter this address: 192.168.4.1. Choose 'Configure WIFI':



5. Select your home access point and enter your password, choose a name for your cociclo (no special characters or spaces) the latitude and longitude of your cociclo.



- 6. Restart your cociclo
- 7. Wait for 25 minutes (to heat the CO sensor and avoid false readings) skip this point if the cociclo is not configured with this long pause.
- 8. Go to http://cociclo.io/carte.php and see your cocíclo on the map.
- 9. Send an image of your installation.

If there's a problem, send a mail to: acastonguay@artengine.ca