

EE5132 - Wireless and Sensor Networks EE5023 - Wireless Networks

Assoc Prof <u>Tham</u> Chen Khong (CK Tham)
E-mail: eletck@nus.edu.sg

(Part I based on slides by Prof Lawrence Wong, ECE)

CK Tham/Lawrence Wong



- Part I Wireless Network Systems
 - Wireless channel characteristics
 - Medium Access Control (MAC) techniques
 - Routing protocols and wireless ad-hoc networks
 - TCP over wireless networks
 - Wireless mesh networks
- Part II Wireless Sensor Networks
 - Recent Advances: Internet of Things (IoT)
 - Energy models for sensor networks
 - Routing protocols for sensor networks
 - Collaborative Signal Processing and Data Fusion
 - Collaborative Signal & Information Processing and Tracking
- 2 Assignments corresponding to Parts I and II of the module



Wireless Channel Characteristics

Chapter 1

Reference book:

Wireless Communications: Principles and Practice (2nd Edition)

by Theodore S. Rappaport (Prentice Hall)

CK Tham/Lawrence Wong 3



Wireless Comes of Age

Guglielmo Marconi invented wireless telegraph in 1896


Communication by encoding alphanumeric characters in analog signal

- Sent telegraphic signals across the Atlantic Ocean
- Communications satellites launched in 1960s
- Advances in wireless technology
 - Radio, television, mobile telephone, communication satellites
- More recently
 - Satellite communications
 - Mobile cellular networks
 - Wireless Local Area Networks (LANs)
 - Personal Area Networks (PAN) & Body Area Networks (BAN)
 - Mobile ad hoc networks (MANET)
 - Wireless mesh networks
 - Wireless sensor networks
 - Vehicular networks





Types of Wireless Networks



Cellular Technologies

2nd Generation : GSM

3rd Generation: WCDMA

4th Generation: LTE

5th Generation

Personal Area Networks (PANs)

Bluetooth (IEEE 802.15.3)

Zigbee (IEEE 802.15.4)

Wireless LAN

IEEE 802.11 a/b/g/n/ac/ax

Wireless Broadband

WiMAX (IEEE 802.16)

Others

- RFID
- Ultra WideBand (UWB)
- Sigfox
- LoRa & LoRaWAN

CK Tham/Lawrence Wong

5



Network Characteristics

	Wireless Network	Fixed (Wired) Network	
Terminal-to-network channel	Unpredictable, time varying, poor at times	Constant, high quality	
Transmission medium	Shared	Dedicated to 1 terminal	
Privacy, security	Vulnerable: signals radiated in the air	Wiretapping requires special measures	
Bandwidth allocation	Policy-based (radio spectrum) e.g. 4G, 5G	Technology-based and cost-based (e.g. optical fibre)	
Network configuration	Frequent changes during calls, e.g. due to mobility	Rarely changes	

<u>Note</u>: Cellular networks have better assured service levels

- Understanding of how radio propagates provide insights to challenges and limitations
- Factors that affect radio propagation:
 - Antenna type and height

 - Line-of-Sight vs Non-Line-of-Sight propagation
 - Shadowing
 - Multipath fading
 - Obstacles and corners

 - Frequency band
 - Signal bandwidth
 - Speed of mobility

CK Tham/Lawrence Wong 7



Signal Attenuation

- Strength of signal falls off with <u>distance over transmission medium</u>
- Attenuation factors for unguided media:
 - Received signal must have sufficient strength so that circuitry in the receiver can interpret the signal
 - Signal must maintain a level sufficiently higher than noise to be received without error
 - Attenuation is greater at higher frequencies, causing distortion

I. Large Scale Path Loss Signal Attenuation

Average received signal power S is:

```
S=kr-a < assume transmit power = |
```

 $k = \text{constant (function of } \lambda, \text{ antenna heights,}$ antenna gains, effective areas, etc.)

r = transmitter-receiver distance


a = signal attenuation or path loss factor

```
Or in dB: S_{dB} = 10 \log_{10} S dB = 10 \log_{10} kr^{-10}
```

Typical values of a:



a = 3.0-6.2 : residential houses




received Signal is 0.0001 if original Bignal is l

CK Tham/Lawrence Wong



- Fading is variation of the attenuation of a signal with various variables such as time, position and radio frequency.
- It is often modeled as a random process.



→time-varying received signal

- Shadowing is caused by the nature of the terrain and local geographical features, where the signal is blocked by natural obstacles.
- Each terminal *i* receives a signal of power T_i and the distribution of this signal power is Gaussian, i.e.


p(
$$T_i$$
) = $\frac{1}{\sigma\sqrt{2\pi}} \exp\left[-\frac{(T_i - \overline{T})^2}{2\sigma^2}\right]$

where \bar{T} and σ are the mean and standard deviation of T_i , respectively.

• Typically σ is in the range of 6 to 12 dB.

109-normal Shadowing

Variation of T_i with location is called shadowing




CK Tham/Lawrence Wong

11




II. Small-Scale Fading / Multipath Fading

- Multipath fading
 - Line of Sight (LOS) or non-LOS
 - Rayleigh fading when there is no dominant propagation along a line of sight (LOS) between the transmitter and receiver, i.e. non-LOS



- Rician fading when there is a dominant line of sight (LOS)
- Fast fading, Slow fading (wrt symbol period)
- Frequency-dependent fading: <u>Flat fading</u>, Frequency-Selective fading (wrt bandwidth of signal)

- Reflection occurs when signal encounters a surface that is large relative to the wavelength of the signal
- Diffraction occurs at the edge of an impenetrable body that is large compared to wavelength of the signal
- Scattering occurs when incoming signal hits an object whose size is in the order of the wavelength of the signal or less



Sketch of 3 important propagation mechanisms:

- Reflection (R),
- Diffraction (D),
- Scattering (S)

CK Tham/Lawrence Wong




13



Effects of Multipath Propagation

- Multiple copies of a signal arrive at different phases at the receiver
 - If phases add destructively, the signal level relative to noise declines, making detection more difficult
- Inter Symbol Interference (ISI)
 - One or more <u>delayed</u> copies of a pulse may arrive at the same time as the primary pulse for a subsequent bit



Multipath Fading

- E Z
- Consider vertically polarised transmission & vertical component of EM field E_z.
 Suppose no strong LOS path between transmitter and receiver, i.e. receiver receives many scattered or reflected waves from all directions.
- Consider 1 ray, $\cos \omega_c t$, arriving at angle θ w.r.t. direction of motion. Received

$$e(t) = C\cos(\omega_c t + \omega_\theta t + \psi)$$

$$= C\cos(\omega_\theta t + \psi)\cos\omega_c t - C\sin(\omega_\theta t + \psi)\sin\omega_c t$$

$$= x(t)\cos\omega_c t + y(t)\sin\omega_c t$$


where: $\underline{f_{\theta}} = \underline{f_{d} \cos \theta} = \text{Doppler shift due to mobile antenna movement}$ $\underline{\omega_{\theta}} = 2\pi f_{d} \cos \theta$

 $\underbrace{f_d}_{d} = maximum Doppler Shift (freq) = v/\lambda$ $\lambda = \text{wavelength of carrier} = c/f_c$

 $\lambda =$ wavelength of carrier = ϵ

c = speed of light (3 x 10 8 m/s)

psi w = path delay phose change



e.g. if v = 100 km/h (27.8 m/s) & $f_c = 850$ MHz, then $f_d = v/\lambda = v.f_c/c = 78.7$ Hz

CK Tham/Lawrence Wong 15



Multipath Fading (cont.)

• Next, consider N rays arriving at different θ 's. All the rays add to give:

$$E_{z}(t) = \sum_{n=1}^{N} C_{n} \cos(\omega_{n}t + \psi_{n}) \cos \omega_{c}t - \sum_{n=1}^{N} C_{n} \sin(\omega_{n}t + \psi_{n}) \sin \omega_{c}t$$

$$= A_{c}(t) \cos \omega_{c}t - A_{s}(t) \sin \omega_{c}t$$

$$= r(t) \cos[\omega_{c}t + \phi(t)]$$

where $\omega_n = 2\pi f_d \cos \theta_n$ is the Doppler shift of the n^{th} ray


• As the sum of many independent terms, $A_{\zeta}(t)$ and $A_{\zeta}(t)$ have Gaussian distributions [*Central Limit Theorem*], with zero mean and variance

$$\sigma^2 = E\{A_c^2(t)\} = E\{A_s^2(t)\} = \sum_{n=1}^N C_n^2 / N$$

• The received envelope $\star r(t) = [A_c^2(t) + A_s^2(t)]^{1/2}$, has a **Rayleigh distribution**:

$$p(r) = \frac{r}{\sigma^2} \exp \left[-\frac{r^2}{2\sigma^2} \right]$$

*received signal amplitude





Multipath Fading (cont.)

Mean:


$$\bar{r} = E[r] = \int_0^\infty rp(r)dr = 1.2533\sigma$$

Mean square:
$$E[r^2] = E\{A_c^2(t)\} + E\{A_s^2(t)\} = \int_0^\infty r^2 p(r) dr = 2\sigma^2$$

Variance:

$$\sigma_r^2 = E[r^2] - (E[r])^2 = 0.4292\sigma^2$$

- Phase $\phi(t)$ has a **uniform distribution** over range of $\pm \pi$.
- **Fast fading** occurs when many fades occur within a symbol duration, which is the time to send one symbol. For binary data, a symbol is just a bit.



- **Slow fading** occurs when a fade occurs over several symbol durations.
- **Diversity reception** is a way to overcome fading adversities:
 - Space diversity
 - Time diversity
 - Frequency diversity
 - Code diversity



CK Tham/Lawrence Wong

17



Rayleigh Fading - Level Crossing Rate

The *level crossing rate* is the no. of times per second the signal envelope fades below the *fade margin*, A. The level crossing rate is a 2nd-order statistic given by: Signal level (dB)




$$N_{A} = \int_{0}^{\infty} \dot{r} p(r = A, \dot{r}) d\dot{r} = \sqrt{2\pi} f_{d}$$

$$\sqrt{2\sigma} \exp \left[-\frac{A^{2}}{2\sigma^{2}} \right]$$

where $\dot{r}={}^{dr}/_{dt}$, and $p(r={\it A},\dot{r})$ is the joint distribution

$$p(r,\dot{r}) = \frac{r}{\sqrt{2\pi v^2}\sigma^2} \exp\left[-\frac{1}{2}\left(\frac{r^2}{\sigma^2} + \frac{\dot{r}^2}{v^2}\right)\right]$$
 (no need to worry)



and v^2 is the variance of the derivative of the quadrature components, i.e.

$$v^2 = E\{\dot{A}_c^2(t)\} = E\{\dot{A}_s^2(t)\} = 2\pi^2 f_d^2 \sigma^2$$

- The *fade margin* is the minimum received signal level for successful recovery of the information/message
- Suppose $f_d = 10$ and $A^2/(2\sigma^2) = 0.1$, then $N_A = 7.17$
- Suppose $f_d = 10$ and $A^2/(2\sigma^2) = 0.01$, then $N_A = 2.48$


NUS National University of Singapore

Rayleigh Fading – Ave. Fade Duration

- Number to do duration
 - Average fade duration in seconds (time that envelop is < A) is: $N_A = 5$

$$\bar{t}_F = \frac{P(r \le A)}{N_A} = \frac{1}{\sqrt{2\pi}f_d} \frac{\sqrt{2}\sigma}{A} \left[\exp\left(\frac{A^2}{2\sigma^2}\right) - 1 \right]$$

- Suppose $f_d = 10$ and $A^2/(2\sigma^2) = 0.1$, then $\bar{t}_F = 13.3$ ms
- Suppose $f_d = 10$ and $A^2/(2\sigma^2) = 0.01$, then $\bar{t}_F = 4.0$ ms



Mean fade duration (s)

1000

100 - f_d = 10 Hz

10 - 1 - 13.3 vos
0.01 - 140 - 30 - 20 - 10 0 10
Fade level/R M S envelope (dB)

 $(A^2) \longrightarrow$

19



CK Tham/Lawrence Wong

Rayleigh Fading – Inter-fade Duration

- Good part
- Ave. inter-fade duration in seconds (time that envelope is > A) is:

$$\bar{t}_{IF} = \frac{1}{N}$$

$$\bar{t}_{IF} = \frac{1}{N_A} - \bar{t}_F = \frac{1}{N_A} - \frac{P(r \le A)}{N_A}$$


$$= \frac{1}{N_A} [1 - P(r \le A)]$$

$$= \frac{1}{\sqrt{2\pi} f_d} \frac{A}{\sqrt{2\sigma}} \exp\left(-\frac{A^2}{2\sigma^2}\right) \left[1 - \left[1 - \exp\left(-\frac{A^2}{2\sigma^2}\right)\right]\right]$$

$$= \frac{1}{\sqrt{2\pi} f_d} \frac{\sqrt{2\sigma}}{A}$$


$$= \frac{1}{\sqrt{2\pi} f_d} \frac{\sqrt{2\sigma}}{A}$$

where $P(r \le A)$ is the prob. that the envelope $r \le A$, is:



- Suppose $f_d = 10$ and $A^2/(2\sigma^2) = 0.1$, then = 126 ms
- Suppose $f_d = 10$ and $A^2/(2\sigma^2) = 0.01$, then = 399 ms


Delay spread occurs when the base station transmits a signal, say, an impulse $s_0(t) = a_0 \delta(t)$, and because of multipath scattering, many delayed versions of the scattered signals are received.




$$s(t) = a_0 \sum_{i=1}^{n} a_i \delta(t - \tau_i) \cdot e^{j\omega t} = E(t)e^{j\omega t}$$

where n = no. of paths, $a_i = \text{attenuation}$ of the i^{th} path; and $\tau_i = \text{delay.}$

- As no. of scatterers increases, discrete impulses merge into a continuous pulse of length Δ , commonly known as the delay spread.
- Delay spread limits data rate to below $1/\Delta$ to avoid *inter-symbol interference*, beyond which special measures are required to overcome data error.





CK Tham/Lawrence Wong 21



Delay Spread (cont.)

Mean delay spread is:

$$\overline{\tau} = \int_0^\infty t E(t) dt$$

Delay spread variance is:

$$\sigma_{\tau}^{2} = \int_{0}^{\infty} t^{2} E(t) dt - (\tau)^{2}$$

Note: Mean delay spread in urban environment generally higher because of scattering effects arising from building surfaces causing rays to decay more slowly.

Parameter	Urban	Suburban
Mean delay spread, $\bar{\tau}$	1.5 - 2.5 μs	0.1 - 2.0 μs
Corresponding path length	450 - 750 m	30 - 600 m
Maximum delay time (-30 dB)	5.0 - 12.0 μs	0.3 - 7.0 μs
Corresponding path length	1.5 - 3.6 km	0.9 - 2.1 km
Range of delay spread, Δ_i	1.0 - 3.0 μs	0.2 - 2.0 μs



- Several path loss models have been proposed for outdoor and indoor environments.
- Basically, follow the standard path loss model with modifications to include adjustment factors for:
 - Terrain
 - Type of environment (e.g. rural/urban)
 - Adjustment factors for the type of building materials and floors in the case of indoor environments.
- Other multi-path fading models (distribution of received signal amplitude):
 - Rician distribution: when strong Line of Sight (LOS) is present
 - Nakagami etc.

multiple random Rayleigh fading Signals

CK Tham/Lawrence Wong 23



Error Compensation Mechanisms

- To compensate for channel impairments
 - 1. Forward error correction
 - 2. Adaptive equalization
 - 3. Diversity techniques



1. Forward Error Correction

- Transmitter adds error-correcting code to data block
 - Code is a function of the data bits
- Receiver calculates error-correcting code from incoming data bits
 - If calculated code matches incoming code, no error occurred
 - If error-correcting codes do not match, receiver attempts to determine bits in error and correct

CK Tham/Lawrence Wong 25



2. Adaptive Equalization

- Adapts filter coefficients in response to time-varying communications channel
- Can be applied to transmissions that carry analog or digital information
 - Analog voice or video
 - Digital data, digitized voice or video
- Used to combat inter-symbol interference
- Involves gathering dispersed symbol energy back into its original time interval
- Techniques
 - Lumped analog circuits
 - Sophisticated digital signal processing algorithms



3. Diversity Techniques

- Diversity is based on the fact that individual channels experience independent fading events
- Types of diversity techniques:
 - Space diversity techniques involving physical transmission path, e.g. multiple antennas (MIMO is an example of this)
 - Frequency diversity techniques where the signal is spread out over a larger frequency bandwidth, or carried on multiple frequency carriers, e.g.
 spread spectrum and OFDM (Orthogonal Frequency Division Multiplexing)
 - Time diversity techniques aimed at spreading the data out over time
 - Code diversity e.g. CDMA (Code Division Multiple Access)

CK Tham/Lawrence Wong

27




Signal-to-Noise Ratio (per bit) Normalized SNR

• Ratio of signal energy per bit (E_b) to noise power density per Hertz (N_0) :

$$\frac{E_b}{N_0} = \frac{S/R}{N_0}$$

- Bit Error Rate (BER) for digital data transmission is a function of E_b/N_0
 - as bit rate R increases, transmitted signal power S must increase to maintain required E_b/N_0



- Atmospheric absorption water vapor and oxygen contribute to attenuation
- Refraction bending of radio waves as they propagate through the atmosphere
- Adjacent channel interference disturbances from radio signals at adjacent frequency channels
- RF frontends quality of RF electronics and antenna design
- Thermal noise in electronic devices and transmission media

The End Questions?