

Update Assembly Instruction

Software installation

With the operating system „Trixie“, opencv cannot be installed anymore with the pip command as described in the original Assembly Instruction.

Therefore, the opencv installation was included in *install.py*; thus, a manual installation is not required.

This opencv is only required for the Operational qualifications, while the software has its own opencv package.