

Demorad Setup Guide

- Installing drivers for Demorad
 - Power up the Demorad and connect to it via Mini USB port.
 - Unzip the ADI_Demo_Driver.zip in the Software folder.
 - Find the "BF707 Bulk Device" in your Control Panel Devices and Printers window.
 - Open the Properties of the device.
 - Edit the properties to manually install the drivers from the unzipped folder of drivers.
 - More detail on page 2.
 - Run the DemoRadTool-x32.exe file.






Demorad Setup GuideMore detailed Driver Installation*



1


Find the device in the Printers and Devices window.

"BF707 Bulk Device"




2

Select properties in the Hardware Tab.




3

Change Settings in the Device Properties. This requires administration rights.



4

Install Drivers for the device



5

Browse my computer for driver software



6

Select the unzipped ADI_Demo_Driver folder and click next.



^{*}This guide is done on Windows 7. There may be differences on other OS.