Chapter 3 CPU


Module 3- Cer	ntral Processing Unit
3.1	CPU architecture, Register organization, Instruction formats and addressing modes(Intel processor).,Basic instruction cycle. Control unit Operation ,Micro operations: Fetch, Indirect, Interrupt, Execute cycle Control of the processor, Functioning of micro programmed control unit, Micro instruction Execution and Sequencing, Applications of Micro programming
3.2	RISC v/s CISC processors, RISC and CISC Architecture, RISC pipelining, Case study on SPARC

## **CPU Structure**

#### • CPU must:

- Fetch instructions-reads an instruction from memory
- Interpret instructions-instruction is decoded to determine what action is required.
- Fetch data-The execution of an instruction may require reading data from memory or an I/O module
- Process data-The execution of an instruction may require performing some arithmetic or logical operation on data
- Write data-the results of an execution may require writing data to memory or an I/O module.


# **CPU With Systems Bus**



- The ALU does the actual computation or processing of data.
- The control unit controls the movement of data and instructions into and out of the processor and controls the operation of the ALU.

• In addition, there is a small working space(temporary storage) called as register.

## **CPU Internal Structure**



- The data transfer and logic control paths are indicated, including an element labeled internal processor bus.
- This element is needed to transfer data between the various registers and the ALU because the ALU in fact operates only on data in the internal processor memory.

## Registers

- CPU must have some working space (temporary storage)-Called registers
- Number and function vary between processor designs
- One of the major design decisions
- Top level of memory hierarchy
- The registers in the processor perform two roles:
- User-visible registers: Enable the machine- or assembly language programmer to minimize main memory references by optimizing use of registers.
- Control and status registers: Used by the control unit to control the operation of the processor and by privileged, operating system programs to control the execution of programs.

## User Visible Registers

- may be referenced by means of the machine language that the processor executes
- General Purpose-can be assigned to a variety of functions by the programmer
- Data-used only to hold data and cannot be employed in the calculation of an operand address
- Address-somewhat general purpose, or they may be devoted to a particular addressing mode.
  - Segment pointers: In a machine with segmented addressing, a segment register holds the address of the base of the segment.
    - •Index registers: These are used for indexed addressing and may be auto indexed.
    - •Stack pointer-there is a dedicated register that points to the top of the stack.
- Condition Codes- (Refer next slides)

# **Example Register Organizations**

	Data Registers
D0	
D1	
D2	
D3	
D4	
D5	
D6	
D7	
	Address Registers
A0	
A1	
A2	
A3	
A4	
A5	
A6	
A7	
А7'	
	Program Status
	Program Counter
•	Status Register

General Registe	
$\mathbf{AX}$	Accumulator
$\mathbf{B}\mathbf{X}$	Base
$\mathbf{C}\mathbf{X}$	Count
$\mathbf{D}\mathbf{X}$	Data

Po	inter & Index	
SP	Stack Pointer	
ЗP	Base Pointer	
SI	Source Index	
Ν	Dest Index	

CS	Code
DS	Data
SS	Stack
ES	Extra

SI $\mathbf{DI}$ 

Instr Ptr
Flags

**Program Status** 

(b) 8086

#### General Registers

EAX	AX	
EBX	BX	
ECX	CX	
EDX	DX	

ESP	SP
EBP	BP
ESI	SI
EDI	DI

	Program Status	
916	FLAGS Register	
	Instruction Pointer	

(c) 80386 - Pentium II

- The MC68000 partitions its 32-bit registers into eight data registers and nine address registers.
- The eight data registers are used primarily for data manipulation and are also used in addressing as index registers.
- The address registers contain 32-bit addresses; two of these registers are also used as stack pointers, one for users and one for the operating system
- 32-bit program counter and a 16-bit status register.

- Intel-special purpose and general purpose registers
- four 16-bit data registers that are addressable on a byte or 16-bit basis, and four 16-bit pointer and index registers.
- The data registers can be used as general purpose in some instructions.
- four 16-bit segment registers
- Compact encoding at the cost of reduced flexibility.
- The 8086 also includes an instruction pointer and a set of 1-bit status and control flags

- user-visible register organization for the Intel 80386, which is a 32-bit microprocessor designed as an extension of the 8086.
- The 80386 uses 32-bit registers.
- However, to provide upward compatibility for programs written on the earlier machine, the 80386 retains the original register organization embedded in the new organization

## General Purpose Registers

- May be true general purpose
- May be restricted
- May be used for data or addressing
- Data
  - Accumulator
- Addressing
  - Segment

Why make them general purpose?

Increase flexibility and programmer options

Increase instruction size & complexity

# How big?

- Large enough to hold full address
- Large enough to hold full word
- Often possible to combine two data registers
  - C programming
  - double int a;
  - long int a;

# Condition Code Registers(Flag Reg)

- Condition codes are bits set by the processor hardware as the result of operations.
- In addition to the result itself being stored in a register or memory, a condition code is also set
- Condition code bits are collected into one or more registers
- Sets of individual bits
  - e.g. result of last operation was zero
- Can be read (implicitly) by programs
  - e.g. Jump if zero
- Can not (usually) be set by programs

## ADV vs DISADV of Condition Code

Table 12.1 Condition Codes

Advantages	Disadvantages
Because condition codes are set by normal arithmetic and data movement instructions, they should reduce the number of COM-PARE and TEST instructions needed.     Conditional instructions, such as BRANCH are simplified relative to composite instruc-	<ol> <li>Condition codes add complexity, both to the hardware and software. Condition code bits are often modified in different ways by different instructions, making life more difficult for both the microprogrammer and compiler writer.</li> </ol>
tions, such as TEST AND BRANCH.  3. Condition codes facilitate multiway branch-	<ol><li>Condition codes are irregular; they are typi- cally not part of the main data path, so they require extra hardware connections.</li></ol>
es. For example, a TEST instruction can be followed by two branches, one on less than or equal to zero and one on greater than zero.	Often condition code machines must add special non-condition-code instructions for special situations anyway, such as bit checking, loop control, and atomic semaphore operations.
	<ol> <li>In a pipelined implementation, condition codes require special synchronization to avoid conflicts.</li> </ol>

#### Control & Status Registers

- Program Counter (PC)-Contains the address of an instruction to be fetched
- Instruction Decoding Register(IR)-Contains the instruction most recently fetched
- Memory Address Register(MAR)-Contains the address of a location in memory
- Memory Buffer Register(MBR)-Contains a word of data to be written to memory or the word most recently read

movement of data between the processor and memory
Within the processor, data must be presented to the ALU for processing.
The ALU may have direct access to the MBR and user-visible registers

#### Memory Address Register (MAR)

- Connected to address bus
- Specifies address for read or write op

#### Memory Buffer Register (MBR)

- Connected to data bus
- Holds data to write or last data read

## Program Counter (PC)

- Holds address of next instruction to be fetched
- Instruction Register (IR)
  - Holds last instruction fetched/current instruction being executed

## **Program Status Word**

program status word (PSW) contain status information.

The PSW typically contains condition codes plus other status information.

Common fields or flags include the following:

- A set of bits
- Includes Condition Codes
- Sign of last result
- Zero-set when result is 0
- Carry
- Equal
- Overflow
- Interrupt enable/disable-enable or disable interrupts.
- Supervisor-Indicates whether the processor is executing in supervisor or user mode.

- The user state is the default (normal) state of operation, in which user programs are executed.
- The supervisor state is a special mode of operation to which the user has no access.
- When it is in the supervisor state, the processor and its actions are entirely controlled by the Operating System (OS).

- Processor operations mostly involve processing data.
- This data can be stored in memory and accessed from thereon.
- However, reading data from and storing data into memory slows down the processor
- To speed up the processor operations, the processor includes some internal memory storage locations, called **registers**.
- The registers store data elements for processing without having to access the memory. A limited number of registers are built into the processor chip.

The registers are grouped into three categories —
General registers,
Control registers, and
Segment registers.
The general registers are further divided into the following groups —
Data registers,
Pointer registers, and
Index registers.

#### **General Registers**

- **AX is the primary accumulator**; it is used in input/output and most arithmetic instructions. For example, in multiplication operation, one operand is stored in EAX or AX or AL register according to the size of the operand.
- **BX is known as the base register**, as it could be used in indexed addressing (the content of a given index register gets added to an instruction's address part so as to obtain the effective address.).
- **CX is known as the count register**, as the ECX, CX registers store the loop count in iterative operations.
- **DX is known as the data register**. It is also used in input/output operations. It is also used with AX register along with DX for multiply and divide operations involving large values.

#### Pointer Registers

- Instruction Pointer (IP) The 16-bit IP register stores the offset address (*The offset address, which is a part of the address, is added to the start of the segment to address a memory location within the memory segment*) of the next instruction to be executed. IP in association with the CS register (as CS:IP) gives the complete address of the current instruction in the code segment.
- Stack Pointer (SP) The 16-bit SP register provides the offset value within the program stack. SP in association with the SS register (SS:SP) refers to be current position of data or address within the program stack.
  - The stack is a block of memory that may be used for temporarily storing the contents of registers inside CPU. Stack is accessed by using SP and SS

- **Base Pointer (BP)** The 16-bit BP register mainly helps in referencing the parameter variables passed to a subroutine.
  - It is primarily used in accessing parameters passed by the stack.
  - The address in SS (Stack) register is combined with the offset in BP to get the location of the parameter.
  - BP can also be combined with DI (Destination index-16 bit register) and SI (Source index-16 bit register) as base register for special addressing.

## **Index Registers**

SI and DI, are used for indexed addressing and sometimes used in addition and subtraction.

There are two sets of index pointers –


**Source Index (SI)** – It is used as source index for string operations. It is used in the **pointer addressing of data** and as a source in some string-related operations

**Destination Index (DI)** – It is used as destination index for string operations. It is used in the **pointer addressing of data** and as a destination in some string-related operations.

## **Control Registers**

- The 32-bit instruction pointer register and the 32-bit flags register combined are considered as the control registers.
- Many instructions involve comparisons and mathematical calculations and change the status of the flags and some other conditional instructions test the value of these status flags to take the control flow to other location.
- Flags-Condition of the microprocessor and control its operation
- The common flag bits are:

## FLAG REGISTER 8086



- Overflow Flag (OF) It indicates the overflow of a high-order bit (leftmost bit) of data after a signed arithmetic operation.
- **Direction Flag (DF)** It determines left or right direction for moving or comparing string data. When the DF value is 0, the string operation takes left-to-right direction and when the value is set to 1, the string operation takes right-to-left direction.

- Trap Flag (TF) It allows setting the operation of the processor in single-step mode.
  - The DEBUG program we used sets the trap flag, so we could step through the execution one instruction at a time.
- **Sign Flag (SF)** It shows the sign of the result of an arithmetic operation. This flag is set according to the sign of a data item following the arithmetic operation. The sign is indicated by the high-order of leftmost bit. A positive result clears the value of SF to 0 and negative result sets it to 1.
- **Zero Flag (ZF)** It indicates the result of an arithmetic or comparison operation. A nonzero result clears the zero flag to 0, and a zero result sets it to 1.

• Interrupt Flag (IF) – It determines whether the external interrupts like keyboard entry, etc., are to be ignored or processed. It disables the external interrupt when the value is 0 and enables interrupts when set to 1.

- Auxiliary Carry Flag (AF) It contains the carry from bit 3 to bit 4 following an arithmetic operation; used for specialized arithmetic. The AF is set when a 1- byte arithmetic operation causes a carry from bit 3 into bit 4.
- Parity Flag (PF) It indicates the total number of 1-bits in the result obtained from an arithmetic operation. An even number of 1-bits clears the parity flag to 0 and an odd number of 1-bits sets the parity flag to 1.
- Carry Flag (CF) It contains the carry of 0 or 1 from a high-order bit (leftmost) after an arithmetic operation. It also stores the contents of last bit of a *shift* or *rotate* operation.

## Segment Registers

- Segments are specific areas defined in a program for containing data, code and stack. There are three main segments —
- Code Segment It contains all the instructions to be executed. A 16-bit Code
   Segment register or CS register stores the starting address of the code segment.
- Data Segment(DS,ES) It contains data, constants and work areas. A 16-bit Data Segment register or DS register stores the starting address of the data segment.
- Stack Segment It contains data and return addresses of procedures or subroutines. It is implemented as a 'stack' data structure. The Stack Segment register or SS register stores the starting address of the stack.

# INSTRUCTION FORMAT (PENTIUM)

- An instruction format defines the layout of the bits of an instruction, in terms of its constituent fields
- Opcodes-Operation Code
- Operands-Data
- ☐ Instruction=Opcodes+Operands.
- Instruction :- MOV A (Destination), B(Source)
  - Examples:

MOV AX,BX

Add AX,4

**JMP** 

MUL 3,5

#### **Instruction Formats**

- Layout of bits in an instruction
- Includes opcode
- Includes (implicit or explicit) operand(s)
- Usually more than one instruction format in an instruction set

#### Instruction Length

- Affected by and affects:
  - Memory size
  - Memory organization
  - Bus structure
  - CPU complexity
  - CPU speed

User wants more opcodes, operands (greater flexibility in implementing certain functions), addressing modes, address range

All of these things (opcodes, operands, addressing modes, address range) require bits and push in the direction of longer instruction length-more space

#### Allocation of Bits

- Number of addressing modes-
- Number of operands


•Register versus memory-A machine must have registers so that data can be brought into the processor for processing. The more that registers can be used for operand references, the fewer bits are needed

•Number of register sets-Some architectures, including that of the x86, have a collection of two or more specialized sets (data & addressing). a functional split requires fewer bits to be used in the instruction.

• Address range-the range of addresses that can be referenced is related to the number of address bits. it is still convenient to allow rather large displacements from the register address, which requires a relatively large number of address bits in the instruction.

• Address Granularity-In a system with 16- or 32-bit words, an address can reference a word or a byte at the designer's choice. Byte addressing is convenient for character manipulation but requires, for a fixed size memory, more address bits.

#### Pentium Instruction Format



- Instructions are made up of from zero to four optional instruction prefixes, a 1- or 2-byte opcode, an optional address specifier (which consists of the ModR/m byte and the Scale Index byte) an optional displacement, and an optional immediate field.
- **Instruction Prefixes-LOCK** prefix (ensure the use of shared memory in multiprocessor environments.) or one of the **REPEAT** prefixes(REP,REPE,REPNE,REPZ,REPNZ.... specify repeated operation of a string, which enables the x86 to process strings much faster)

• **Segment Override**-explicitly specifies which segment register an instruction should use if not the default

#### PENTIUM INSTRUCTION FORMAT

• Address Size- The Pentium can use a 16 or 32 bit address, this specifies which is being used.

• Operand- The operand size can be either 16 or 32 bits, this specifies which is being used.

#### PENTIUM INSTRUCTION FORMAT

**Opcode-** The opcode can be either one or two bytes.

The opcode can also specify if the data is 16 or 32 bit.

The opcode specifies which way the data is going (to or from memory). The opcode specifies if an immediate value is signed or not.

#### Mod R/m-addressing information

The Mod R/M specifies addressing information. It specifies whether an operand is in a register or in memory.

The Mod and R/M fields are combined to form the means in which the memory is indexed.

The Reg/Opcode specifies either the register being used or 3 bits for more opcode.

- SIB-specify fully the addressing mode
  - Scale (2 bits)-scale factor for scaled indexing
  - Index (3 bits)-specifies index register(SI,DI)
  - Base (3 bits)-specifies base register(BX)
- **Displacement**-When the addressing-mode specifier indicates that a displacement is used, an 8-, 16-, or 32-bit signed integer displacement field is added.
- **Immediate** This is where an immediate value is stored if one is used. It can hold an 8, 16, or 32 bit operand.

# William Stallings Computer Organization and Architecture 6th Edition

Chapter III Instruction Sets:

Addressing Modes and Formats

#### Addressing modes

- The way in which an operand is specified in an instruction in the accumulator, in a general purpose register or in memory location, is called **addressing mode**.
- Different opcodes will use different addressing modes.
- one or more bits in the instruction format can be used as a mode field. The value of the mode field determines which addressing mode is to be used.
- In a system without virtual memory, the effective address will be either a main memory address or a register. In a virtual memory system, the effective address is a virtual address or a register

# Addressing Modes

- Immediate
- Direct
- Indirect
- Register
- Register Indirect
- Displacement (Indexed)
- Stack

These modes are illustrated in Figure 11.1. In this section, we use the following notation:

A = contents of an address field in the instruction

R = contents of an address field in the instruction that refers to a register

EA = actual (effective) address of the location containing the referenced operand


(X) = contents of memory location X or register X

# Immediate Addressing

- In this mode data is present in address field of instruction.
- Designed like one address instruction format
  - Note:Limitation in the immediate mode is that the range of constants are restricted by size of address field.

#### FEATURES

- Operand is part of instruction
- Operand = address field
- No memory reference to fetch datasaving memory
- Fast
- Limited range-size of the number is restricted to the size of the address field



#### MOV AX, 2000

MOV CL, 0A

ADD AL, 45


ADD AX, 0000

MOV CX, 4929 H

(source operand-16 bit-


part of instruction)

ADD AX, 2387 H,



MOV AL, FFH (15 bit data)

# Direct(M) Addressing Diagram




### Direct Addressing

- Address field contains address of operand
- EFFECTIVE ADDRESS EA = address field (A)
  - Look in memory at address value for operand
- Single memory reference to access data
- No additional calculations to work out effective address
- Limited address space


- Address of the memory location is given directly
- The operand's offset is given in the instruction as an 8 bit or 16 bit displacement element.
- In this addressing mode the 16 bit effective address of the data is the part of the instruction.
- Here only one memory reference operation is required to access the data.

MOV AX, [0500]

ADD AL,[0301]



# Indirect Addressing Diagram



- In this mode address field of instruction contains the address of effective address.
- Here two references are required.
   1st reference to get effective address.

2nd reference to access the data.

•

# Indirect Addressing

 Memory cell pointed to by address field contains the address

of (pointer to) the operand

- EA =(A)
  - Look in A, find address (A) and look there for operand
- e.g. ADD AX, (A)
  - Add contents of cell pointed to by contents of A to accumulator

Based on the availability of Effective address, Indirect mode is of two kind:


• <u>REGISTER INDIRECT</u>: In this mode effective address is in the register, and corresponding register name will be maintained in the address field of an instruction.

Here one register reference, one memory reference is required to access

 MEMORY INDIRECT: In this mode effective address is in the memory, and corresponding memory address will be maintained in the address field of an instruction.

Here two memory reference is required to access the data

# Register Addressing Diagram



- In register addressing the operand is placed in one of 8 bit or 16 bit general purpose registers.
- The data is in the register that is specified by the instruction.
  - Here one register reference is required to access the data.




# Register Addressing (1/2)

- Operand is held in register named in address filed
- EA = R
- Limited number of registers
- Very small address field needed
  - Shorter instructions
  - Faster instruction fetch
  - MOV AX, BX
  - ADD AX, BX

# Register Addressing (2/2)

- No memory access
- Very fast execution
- Very limited address space
- Multiple registers helps performance
  - Requires good assembly programming or compiler writing
- Similar to Direct addressing

#### Register Indirect Addressing Diagram



- In this addressing the operand's offset is placed in any one of the registers BX,BP,SI,DI as specified in the instruction.
- The effective address of the data is in the base register or an index register that is specified by the instruction.
  - Here two register reference is required to access the data.



#### Register Indirect Addressing

MOV AX, [BX]

(move the contents of memory location s addressed by the register BX to the register AX)

MOV AX, [DI]


ADD AL, [BX]

MOV AX, [SI]

- Operand is in memory cell pointed to by contents of register R
- Large address space (2<sup>n</sup>)
- One fewer memory access than indirect addressing

- the address space limitation (limited range of addresses) of the address field is overcome by having that field refer to a wordlength location containing an address.
- In addition, register indirect addressing uses one less memory reference than indirect addressing.

# Displacement Addressing Diagram



# Displacement Addressing

- Combination of direct and register indirect
- EA = A + (R)
- Effective address=start address + displacement
- Effective address=Offset + (Segment Register)
- Address field hold two values
  - A = base value
  - R = register that holds displacement
  - or vice versa

- The value contained in one address field is used directly. (A)
- The other address field, or an implicit reference based on opcode, refers to a register whose contents are added to A to produce the effective address.
- EA = A + (R)

- Three of the most common uses of displacement addressing:
- Relative addressing
- Base-register addressing
- Indexing

#### Relative addressing

- PC-relative addressing,
- the implicitly referenced register is the program counter (PC).
- That is, the next instruction address is added to the address field to produce the EA.

# Base-Register Addressing

- Base register addressing mode is used to implement inter segment transfer of control.
- The referenced register contains a main memory address, and the address field contains a displacement
- In this mode effective address is obtained by adding base register value to address field value.
- EA= Base register + Address field value.

# Indexed Addressing

- •The address field references a main memory address, and the referenced register contains a positive displacement from that address.
- •The operand's offset is the sum of the content of an index register SI or DI and an 8 bit or 16 bit displacement.

- •efficient mechanism for performing iterative operations
- Auto indexing-typical INC/DEC

$$EA = A + (R)$$
$$(R) \leftarrow (R) + 1$$

# Stack Addressing

- •stack is a linear array of locations. It is sometimes referred to as a pushdown list or last-in-first-out queue
- •stack pointer whose value is the address of the top of the stack.
- •form of implied addressing () instructions that comprise only an opcode without an operand

Operand is (implicitly) on top of stack

- e.g.
  - ADD Pop top two items from stack and add and push

-PUSH AX

**POPAX** 

No memory reference





Table 11.1 Basic Addressing Modes

Mode	Algorithm	Principal Advantage	Principal Disadvantage
Immediate	Operand = A	No memory reference	Limited operand magnitude
Direct	EA = A	Simple	Limited address space
Indirect	EA = (A)	Large address space	Multiple memory references
Register	EA = R	No memory reference	Limited address space
Register indirect	EA = (R)	Large address space	Extra memory reference
Displacement	EA = A + (R)	Flexibility	Complexity
Stack	EA = top of stack	No memory reference	Limited applicability

- Two steps:
  - Fetch
  - Execute

- •The processor reads ( fetches) instructions from memory one at a time and executes each instruction.
- •Program execution consists of repeating the process of instruction fetch and instruction execution



The processing required for a single instruction is called an *instruction cycle* 

- At the beginning of each instruction cycle the processor fetches an instruction from memory.
- Program counter (PC) -holds the address of the instruction to be fetched next
- The fetched instruction is loaded into a register in the processor known as the instruction register (IR).
- The instruction contains bits that **specify the action the processor** is to take.
- The processor interprets the instruction and performs the required action

- It is the time in which a single instruction is fetched from memory, decoded, and executed
- An Instruction Cycle requires the following subcycle:
  - FETCH
  - EXECUTE
  - INDIRECT
  - INTERRUPT




Figure 12.4 The Instruction Cycle

#### Fetch

Read next instruction from memory into the processor

#### Indirect Cycle (Decode Cycle)

May require memory access to fetch operands, therefore more memory accesses.

#### Interrupt

Save current instruction and service the interrupt


#### Execute


Interpret the opcode and perform the indicated operation

- all computers provide a mechanism by which other modules (I/O, memory) may interrupt the normal processing of the processor
- To accommodate interrupts, an interrupt cycle is added to the instruction cycle
- In the interrupt cycle, the processor checks to see if any interrupts have occurred, indicated by the presence of an interrupt signal.
- If no interrupts are pending, the processor proceeds to the fetch cycle and fetches the next instruction of the current program

- If an interrupt is pending, the processor does the following:
- It suspends execution of the current program being executed and saves its context. This means saving the address of the next instruction to be executed
- It sets the program counter to the starting address of an interrupt handler routine.
- The processor now proceeds to the fetch cycle and fetches the first instruction in the interrupt handler program, which will service the interrupt
- When the interrupt handler routine is completed, the processor can resume execution of the user program at the point of interruption.

# Instruction Cycle with Interrupts





Instruction Cycle State Diagram




Figure 10.1 Instruction Cycle State Diagram

## Instruction Cycle State Diagram

- This illustrates more correctly the nature of the instruction cycle.
- Once an instruction is fetched, its operand specifiers must be identified.
- Each input operand in memory is then fetched, and this process may require indirect addressing.
- Register-based operands need not be fetched.
- Once the opcode is executed, a similar process may be needed to store the result in main memory.

- Instruction address calculation (iac): Determine the address of the next instruction to be executed
- Instruction fetch (if): Read instruction from its memory location into the processor.
- Instruction operation decoding (iod): Analyze instruction to determine type of operation to be performed and operand(s) to be used.
- Operand address calculation (oac): If the operation involves reference to an operand in memory or available via I/O, then determine the address of the operand
- **Operand fetch (of):** Fetch the operand from memory or read it in from I/O.
- **Data operation (do):** Perform the operation indicated in the instruction.
- **Operand store (os):** Write the result into memory or out to I/O.

- Each instruction is executed during an instruction cycle made up of shorter subcycles (e.g., fetch, indirect, execute, interrupt).
- The execution of each subcycle involves one or more shorter operations, that is, micro- operations.
- Micro-operations are the functional, or atomic, operations of a processor

## Fetch Cycle-Registers

- Memory Address Register (MAR)
  - Connected to address bus
  - Specifies address for read or write op
- Memory Buffer Register (MBR)
  - Connected to data bus
  - Holds data to write or last data read
- Program Counter (PC)
  - Holds address of next instruction to be fetched
- Instruction Register (IR)
  - Holds last instruction fetched/current instruction being executed


## Fetch Cycle

- Program Counter (PC) holds address of next instruction to be fetched
- Processor fetches instruction from memory location pointed to by
   PC
- Increment PC
  - Unless told otherwise
- Instruction loaded into Instruction Register (IR)
- Processor interprets instruction and performs required actions

#### The Fetch Cycle –

-At the beginning of the fetch cycle, the address of the next instruction to be executed is in the *Program Counter*(PC).


-address is 1100100



BEGINNING


## Step 1:

• The address in the program counter is moved to the memory address register(MAR), as this is the only register which is connected to address lines of the system bus.



## Step 2:

- The address in MAR is placed on the address bus, now the control unit issues a READ command on the control bus, and the result appears on the data bus and is then copied into the memory buffer register(MBR).
- **Program counter is incremented by one**, to get ready for the next instruction. (These two action can be performed simultaneously to save time)



## Step 3:

• The content of the MBR is moved to the instruction register(IR)

MAR 000000001100100

MBR 0001000000100000

PC 000000001100100

IR 0001000000100000

AC

## Fetch Sequence (symbolic)

```
t1: MAR ← PC
t2: MBR ← MEMORY
PC ← (PC) + I
t3: IR ← (MBR)
```

- •three steps and four micro-operations
- •Each micro-operation involves the movement of data into or out of a register-no interference-saves time
- •(t1, t2, t3) represents successive time units
- •I —instruction length

#### **Indirect Cycle-fetch source operands**

#### Step 1:

The address field of the instruction is transferred to the MAR.

This is used to fetch the address of the operand.

#### Step 2:

The address field of the IR is updated from the MBR. (So that it now contains a direct addressing rather than indirect addressing)

#### Step 3:

The IR is now in the state, as if indirect addressing has not been occurred.

## **Interrupt Cycle**

- At the completion of the Execute Cycle, a **test** is made to determine whether **any enabled interrupt has occurred or not.**
- If an enabled interrupt has occurred then Interrupt Cycle occurs.
- The nature of this cycle varies greatly from one machine to another.

t1: MBR

t2: MAR

PC

t3: MEMORY - (MBR)

**←** (PC)

- SAVE ADDRESS

- ROUTINE ADDRESS

- Step 1: Contents of the PC is transferred to the MBR, so that they can be saved for return.
  - Step 2: MAR is loaded with the address at which the contents of the PC are to be saved.
  - PC is loaded with the address of the start of the interrupt- processing routine.
  - Step 3: MBR, containing the old value of PC, is stored in memory.
    - Note: In step 2, two actions are implemented as one micro-operation. However, most processor provide multiple types of interrupts, it may take one or more micro- operation to obtain the save\_address and the routine\_address before they are transferred to the MAR and PC respectively.

## Execute Cycle (ADD)

- Different for each instruction
- •The control unit examines the opcode and generates a sequence of micro-operations based on the value of the opcode-Instruction decoding.
- e.g. ADD R1,X add the contents of location X to Register 1, result in R1


```
t<sub>1</sub>: MAR ← (IR(address))
t<sub>2</sub>: MBR ← Memory
t<sub>3</sub>: R1 ← (R1) + (MBR)
```

- •IR contains the ADD instruction.
- •In the first step, the address portion of the IR is loaded into the MAR.
- •Then the referenced memory location is read.
- •Finally, the contents of R1 and MBR are added by the ALU

#### **Micro-Operations**

- Execution of a program consists of the sequential execution of instructions.
- Each instruction is executed during an instruction cycle made up of shorter subcycles (e.g., fetch, indirect, execute, interrupt).
- The execution of each subcycle involves one or more shorter operations, that is, micro-operations.
- A computer executes a program
- Each step does very little
- Atomic operation of CPU

#### **Constituent Elements of Program Execution**



### Categories of Micro-operation

- Transfer data between registers
- Transfer data from register to external interface
- Transfer data from external to register
- Perform arithmetic or logical ops

# William Stallings Computer Organization and Architecture

8<sup>th</sup> Edition
Chapter 15

**Control Unit Operation** 

- we have decomposed the behavior or functioning of the processor into elementary operations, called **micro-operations**.
- By reducing the operation of the processor to its most fundamental level, we are able to define exactly what it is that the control unit must cause to happen
- definition of these functional requirements is the basis for the design and implementation of the control unit.

#### Functional Requirements(of Control Unit)


- Define basic elements of processor
- Describe micro-operations processor performs
- Determine functions control unit must

perform

#### Registers

- Memory Address Register (MAR)
  - Connected to address bus
  - Specifies address for read or write op
- Memory Buffer Register (MBR)
  - Connected to data bus
  - Holds data to write or last data read
- Program Counter (PC)
  - Holds address of next instruction to be fetched
- Instruction Register (IR)
  - Holds last instruction fetched/current instruction being executed

#### Model of Control Unit



#### Functions of Control Unit

#### Sequencing

Causing the CPU to step through a series of micro-operations

#### • Execution

- Causing the performance of each micro-op
- This is done using Control Signals

- For the control unit to perform its function, it must have **inputs** that allow it to **determine the state of the system** and **outputs** that allow it to control the behavior of the system.
- These are the external specifications of the control unit.
- Internally, the control unit must have the logic required to perform its sequencing and execution functions

• The inputs are:

Clock: This is how the control unit "keeps time." It causes one micro-operation to be performed for each clock pulse (processor cycle time/clock cycle time)

Instruction register: The opcode and addressing mode of the current instruction are used to determine which micro-operations to perform during the execute cycle.

- Flags: needed by the control unit to determine the status of the processor and the outcome of previous ALU operations
- Control signals from control bus: The control bus portion of the system bus provides signals to the control unit

- The outputs are as follows:
- Control signals within the processor: two types: those that cause data to be moved from one register to another, and those that activate specific ALU functions.
- Control signals to control bus: two types: control signals to memory, and control signals to the I/O modules.
- Three types of control signals are used:
  - those that activate an ALU function,
  - those that activate a data path, and
  - those that are signals on the external system bus or other external interface.
- All of these signals are ultimately applied directly as binary inputs to individual logic gates

#### Control Signals (input)

#### Clock

One micro-instruction (or set of parallel micro-instructions) per clock cycle

#### Instruction register

- Op-code for current instruction
- Determines which micro-instructions are performed

#### Flags

- State of CPU
- Results of previous operations

#### From control bus

- Interrupts
- Acknowledgements

#### Control Signals - output

- Within CPU
  - Cause data movement
  - Activate specific functions
- Via control bus
  - To memory
- To I/O modules

#### Control Unit Implementation

- Hardwired implementation -the control unit is essentially a state machine circuit.
- Its input logic signals are transformed into a set of output logic signals, which are the control signals
- Microprogrammed implementation- uses sequences of instructions to perform control operations performed by micro operations called microprogramming/firmware

# Control Unit Organization- How can we use the concept of microprogramming to implement a control unit?

#### Chapter 16


# Micro-programmed Control William Stallings Computer Organization and Architecture 8th Edition

- Microprogramming language-each line describes a set of microoperations occurring at one time and is known as a microinstruction.
- A sequence of instructions is known as a **microprogram**, or *firmware*.

#### Implementation

- For each micro-operation, the control unit does is generate a set of control signals
- Each control signal is on or off
- Represent each control signal by a bit for each control line
- Construct a control word for each micro-operation
- Have a sequence of control words for each machine code instruction
- Add an address to specify the next micro-instruction, depending on conditions

### Functioning of Micro programmed Control Unit



- The control memory contains a program that describes the behavior of the control unit.
- The set of microinstructions is stored in the control memory.
- The control address register contains the address of the next microinstruction to be read.
- When a microinstruction is read from the control memory, it is transferred to a control buffer register.
- reading a microinstruction from the control memory is the same as **executing** that microinstruction.
- sequencing unit -loads the control address register and issues a read command.
- control unit still has the same inputs (IR,ALU, flags, clock) and outputs (control signals)

#### Micro programmed Control Unit Functions

- Sequence logic unit issues read command
- Word specified in control address register is read into control buffer register
- Control buffer register contents generates control signals and next address information
- Sequence logic loads new address into control buffer register based on next address information from control buffer register and ALU flags

#### **Next Address Decision**

- Depending on ALU flags and control buffer register
  - Get next instruction
    - Add 1 to control address register
  - Jump to new routine based on jump microinstruction
    - Load address field of control buffer register into control address register
  - Jump to machine instruction routine
    - Load control address register based on opcode in IR

- The upper decoder translates the opcode of the IR into a control memory address.
- The lower decoder is not used for horizontal microinstructions but is used for **vertical microinstructions**

### Advantages and Disadvantages of Microprogramming

- Simplifies design of control unit
  - Cheaper
  - Less error-prone
- Slower

### Tasks Done By Microprogrammed Control Unit

**Microinstruction sequencing-**Get the next microinstruction from the control memory.

Microinstruction execution-Generate the control signals needed to execute the microinstruction.

• Must consider both together-to design control unit affect the format of the microinstruction and the timing of the control unit

#### Micro Instruction Sequencing-Design Considerations

- Microinstruction sequencing technique-the size of the microinstruction time-(reduces the cost of that component) and the address-generation (to execute microinstructions as fast as possible)
- In executing a microprogram, the address of the next microinstruction to be executed is in one of these categories:
  - Determined by instruction register
  - Next sequential address
  - Branch

#### Sequencing Techniques

- Based on the current microinstruction, condition flags, and the contents of the instruction register, a control memory address must be generated for the next microinstruction
- Different techniques are based on the format of the address information in the microinstruction:
  - Two address fields
  - Single address field
  - Variable format




Figure 16.6 Branch Control Logic: Two Address Fields

- Multiplexer (data selector) is provided that serves as a destination for both address fields plus the instruction register.
- Based on an address-selection input, the multiplexer transmits either the opcode or one of the two addresses to the control address register (CAR).
- The CAR is subsequently decoded to produce the next microinstruction address.
- The address-selection signals are provided by a branch logic module whose input consists of control unit flags plus bits from the control portion of the microinstruction.
- Simple and it requires more bits in the microinstruction than other approaches

#### **Address Generation**

**Table 16.3** Microinstruction Address Generation Techniques

Explicit	<b>I</b> mplicit
Two-field	Mapping
Unconditional branch	Addition
Conditional branch	Residual control


- explicit techniques, in which the address is explicitly available in the microinstruction, and implicit techniques, which require additional logic to generate the address.
- With a two-field approach, two alternative addresses are available with each microinstruction
- A conditional branch instruction depends on the following types of information: ALU flags
- Part of the opcode or address mode fields of the machine instruction
- Parts of a selected register, such as the sign bit
- Status bits within the control unit

- **Mapping**, is required with virtually all designs-The opcode portion of a machine instruction is mapped into a microinstruction address (occurs only once per instruction cycle)
- Addition-combining or adding two portions of an address to form the complete address.
- Residual control-use of a microinstruction address that has previously been saved in temporary storage within the control unit

#### Microinstruction execution

- The control logic module **generates control signals** as a function of some of the bits in the microinstruction
- The execution of a microinstruction is to generate control signals.
- Some of these signals control points internal to the processor.
- The remaining signals go to the external control bus or other external interface


### Figure 16.10 Control Unit Organization




#### Micro-instruction Types

- Each micro-instruction specifies many **different** micro-operations to be performed in **parallel** 
  - (horizontal micro-programming)
- Each micro-instruction specifies **single** (or few) micro operations to be performed
  - (vertical micro-programming)

### Typical Microinstruction Formats



(a) Horizontal microinstruction



(b) Vertical microinstruction

#### Horizontal microinstruction

- There is one bit for each internal processor control line and one bit for each system bus control line.
- There is a condition field indicating the condition under which there should be a branch, and there is a field with the address of the microinstruction to be executed next when a branch is taken
- 1. To execute this microinstruction, turn on all the control lines indicated by a 1 bit; leave off all control lines indicated by a 0 bit.
- The resulting control signals will cause one or more micro-operations to be performed.
- 2. If the condition indicated by the condition bits is false, execute the next microinstruction in sequence.
- 3. If the condition indicated by the condition bits is true, the next microinstruction to be executed is indicated in the address field.

#### Vertical Micro-programming

- Width is narrow
- Limited ability to express parallelism
- Considerable encoding of control information require external memory word decoder to identify the exact control line being manipulated

#### Horizontal Micro-programming

- Wide memory word
- High degree of parallel operations possible
- Little encoding of control information

#### Applications of Microprogramminghttps://www.geeksforgeeks.org/applications-ofmicroprogrammed-control-unit/

- Microprogramming has many advantages like flexibility, simplicity, cost-effectiveness etc.
- **Development of control units** –making control units of such processors, because it is far less complex and can be easily modified
- **High level language support** —provide support for complex data types directly from the processor level.
- Development of special purpose processors –
- Improving the operating system
- User tailoring of the control unit -As the control Unit is developed using software, it can be easily reprogrammed. This can be used for custom-made modifications of the Control Unit

## William Stallings Computer Organization and Arraphitecture 7th Edition

Reduced Instruction Set Computers

V/S

**Complex Instruction Set Computers** 

### Introduction

- The architectural design of the **CPU** is RISC & CISC.
- The CISC architecture helps reduce program code by embedding multiple operations on each program instruction, which makes the CISC processor more complex
- RISC has a highly customized set of instructions used in portable devices due to system reliability such as Apple iPod, mobiles/smartphones, Nintendo DS,
- Hardware fused with software (Intel v/s Apple)
- Intel's hardware oriented approach is termed as CISC while

that of **Apple** is RISC

- Instruction Set Architecture- Interface to allow easy communication between the programmer and the hardware.
- ISA- execution of data, copying data, deleting it, editing
- Instruction Set , Addressing Modes,

### RISC-Reduced Instruction Set Computer

- A microprocessor architecture with a simple collection and highly customized set of instructions.
- It is built to minimize the instruction execution time by optimizing and limiting the number of instructions.
- It means each instruction cycle requires only one clock cycle
- RISC processor design has separate **digital circuitry** in the control unit (produces signals needed for the execution of each instruction in the instruction set of the processor)
- Examples of RISC processors:
  - IBM RS6000, MC88100
  - DEC's Alpha 21064, 21164 and 21264 processors

## CISC-Complex Instruction Set Computer

- If the control unit contains a number of micro-electronic circuitry to generate a set of control signals and each micro-circuitry is activated by a micro-code-CISC
- The primary goal of CISC architecture is to complete a task in as few lines of assembly code as possible.

#### • Examples of CISC processors are:

- Intel 386, 486, Pentium, Pentium Pro, Pentium II, Pentium
- Motorola's 68000, 68020, 68040, etc.

# CISC processor features

- Instruction set with 120-350 instructions
- Variable instruction/data formats
- Small set of general purpose registers(8-24)
- A large number of addressing modes
- High dependency on micro program
- Complex instructions to support HLL (High level language) features

# CISC processor features

- Complex pipelining (decomposing a sequential process into suboperations, with each sub-operation being executed in a dedicated segment that operates concurrently with all other segments.)
- Many functional chips needed to design a computer using CISC
- The length of the code is short, so it requires very little RAM.
- Difficult to design a superscalar processor (execution rate in excess of one instruction per machine cycle)

# RISC processor features

Instruction set with limited number of instructions

Simple instruction format

Large set of CPU registers

Very few addressing modes

Easy to construct a superscalar processor

# RISC processor features

Hardwired control unit for sequencing microinstructions

Supports on chip cache memory

All functional units on a single chip

Simple pipelining

#### Example for RISC vs. CISC

Consider the the program fragments:

The total clock cycles for the CISC version might be:

While the clock cycles for the RISC version is:

CISC	RISC							
Emphasis on hardware	Emphasis on software							
Multiple instruction sizes and formats	Instructions of same set with few formats							
Less registers	Uses more registers							
More addressing modes	Fewer addressing modes							
Extensive use of microprogramming	Complexity in compiler							
Instructions take a varying amount of cycle time	Instructions take one cycle time							
Pipelining is difficult	Pipelining is easy							

#### Pipelining

- Pipelining is the process of accumulating instruction from the processor through a pipeline.
- It allows storing and executing instructions in an orderly process. It is also known as pipeline processing.
- Pipelining is a technique where multiple instructions are overlapped during execution.
- Pipelining-to simplify hardware by using an instruction set composed of basic steps for evaluating, loading, and storing operations.
- the processor works on different steps of the instruction at the same time, more instructions can be executed in a shorter period of time.
- they are basically variations of these five, used in the MIPS R3000 processor:
  - fetch instructions from memory
  - read registers and decode the instruction
  - execute the instruction or calculate an address
  - access an operand in data memory
  - write the result into a register

### Principles of RISCs Pipeline

Keep the most frequently accessed operands in CPU registers.

It can minimize the register-to-memory operations.


It can use a high number of registers to enhance operand referencing and decrease the processor memory traffic.


It can optimize the design of instruction pipelines such that minimum compiler code generation can be achieved.

It can use a simplified instruction set and leave out those complex and unnecessary instructions.

- the length of the pipeline is dependent on the length of the longest step.
- more conducive to pipelining.
- While CISC instructions varied in length, RISC instructions are all the same length and can be fetched in a single operation.
- https://cs.stanford.edu/people/eroberts/courses/soco/projects/risc/ pipelining/index.html

# PIPELINING-Ex Laundry Analogy





# Problems with pipeline

- Stalling of pipeline
  - Data Dependency
  - Branch, etc...
- RISC processors operate at more than one cycle per instruction (practically).
- The processor might occasionally stall as a result of data dependencies and branch instructions.
  - A data dependency occurs when an instruction depends on the results of a previous instruction.
  - A particular instruction might need data in a register which has not yet been stored since that is the job of a preceding instruction which has not yet reached that step in the pipeline.
  - Solution-Code reordering-code could be rearranged so that those instructions are executed in between the two dependent instructions and the pipeline could flow efficiently.

- Branch instructions are those that tell the processor to make a decision about what the next instruction to be executed should be based on the results of another instruction.
- Branch instructions can be troublesome in a pipeline if a branch is conditional on the results of an instruction which has not yet finished its path through the pipeline.
- Superpipelining refers to dividing the pipeline into more steps. The more pipe stages there are, the faster the pipeline is because each stage is then shorter.
- Ideally, a pipeline with five stages should be five times faster than a non-pipelined processor


# RISC Pipelining

- Pipelining with Regular Instructions
- Most instructions are register to register
- Two phases of execution, I E
  - I: Instruction fetch
  - E: Execute
    - Perform ALU operation with register input and output
- For load and store(memory),I E D
  - I: Instruction fetch
  - E: Execute
    - Calculate memory address
  - D: Memory
    - Register to memory or memory to register operation

Load	$rA \leftarrow M$	1	E	D										
Load	$rB \leftarrow M$				1	Ε	D							
Add	$rC \leftarrow rA + rB$							1	Ε					
Store	$M \leftarrow rC$									1	Ε	D		
Branch	Χ						- 8			- 3	- 33		1	E

### (a) Sequential execution

timing of a sequence of instructions using no pipelining-Clearly, this is a wasteful process



### (b) Two-stage pipelined timing

**NOP** is typically used to generate a delay in execution or to reserve space in code memory.


- instruction fetch stage of the second instruction can be performed in parallel with the first part of the execute/memory stage.
- a branch instruction interrupts the sequential flow of execution-NOOP- generate a delay in execution or to reserve space in code memory

#### (c) Three-stage pipelined timing

three instructions can be overlapped, and the improvement is as much as a factor of 3

### RISC Architecture

- 9 **functional units** interconnected by multiple data paths with width ranging from 32-128 bits
- All internal- external buses are 32 bit wide
- Separate instruction (4KB)and data cache(8KB)
- MMU- implements paged virtual memory structure
- RISC integer unit executes load, store, fetch etc
- 2 floating point units, multiplier unit and adder unit
- Graphics unit to support 3D drawing



**RISC Architecture** 

### **CISC Architecture**




Fig. CISC Architecture