INSTALLATION GUIDE

Stone Cladding

Stone cladding rewards careful preparation. We recommend an experienced installer and a sound, correctly prepared substrate for a lasting result.

01

Before you start

- Use an experienced installer.
- Dry-blend pieces from several boxes to spread natural colour and texture.
- Check pieces for the right size, colour and finish before fixing.

02

Prepare the substrate

- Follow the manufacturer's system for the wall type.
- External walls generally need a weather-resistant barrier, metal lath and a scratch coat.
- The surface must be clean, sound and able to hold the weight.

03

Fixing

Use a suitable polymer-modified mortar or adhesive. Fit corner pieces first, then work the field. Butter the back for full contact and set each piece firmly, keeping joints consistent.

04

Conditions & jointing

Weather and finishing

Do not install in very hot, cold or wet conditions.

Where joints are grouted, point and tool them once firm. Allow flashings and weep points to drain freely.

A NOTE ON NATURAL STONE

Colour, veining and texture vary piece to piece. That variation is the character of the stone, not a fault.

05

Finishing

- Keep the stone clear of ground contact and constant moisture.
- Seal if desired with a breathable stone sealer.
- Clean off mortar smears before they set.

This installation guide is general information only. Always follow the instructions supplied with your product and use a suitably licensed tradesperson. If you are unsure, please contact OnWood Tiles.