INSTALLATION GUIDE

Tiles & Surfaces

A quality tiled surface starts with a proper installation. We recommend an experienced, licensed tiler and a few simple checks before the first tile is laid.

01

Before you start

- Inspect every box for shade, size, finish and faults.
- Do not lay tiles you are not happy with, laid tiles are considered accepted.
- Confirm the tile suits the application and slip rating.

02

Prepare the surface

- The substrate must be clean, dry, sound and level.
- Waterproof wet areas to AS 3740.
- Allow for movement and expansion joints as required.

03

Setting out

Dry-lay and blend tiles from several boxes to spread natural shade variation evenly. Plan your set-out so cut tiles fall in less visible areas.

04

Adhesive & grout

Match the product to the tile

Use an adhesive suited to the tile and substrate, with full coverage. Large-format tiles should be back-buttered.

Grout only once the adhesive has cured, then clean off haze promptly.

A NOTE ON VARIATION

Shade, tone and size variation is a natural feature of fired tiles. Blending across boxes gives the best result.

05

After laying

- Keep foot traffic off until fully set.
- Keep a few spare tiles from the same batch.
- Follow the care guide once the grout has cured.

This installation guide is general information only. Always follow the instructions supplied with your product and use a suitably licensed tradesperson. If you are unsure, please contact OnWood Tiles.