



whoever * whatever * wherever



W-locate Pte Ltd.
Fleet Innovative Dynamics

FIND

User Manual

This document and its graphical content is Copyright © 2011 by the W-locate Pte Ltd..
W-locate retains full copyright ownership, rights and protection in all material contained in this document.

1. System Requisites

- 1.1 Platform: PC, Apple
- 1.2 Operating System:
 - a. Windows XP, Vista, Window 7, Window Server
 - b. Mac: OSX and above
- 1.3 Internet Browser:
 - a. Internet Explorer, Safari, Chrome, Firefox
 - b. Enter URL: <http://116.12.193.4/find/>



Login Page

2. Login to Begin

- 2.1 Key in the Username and Password
- 2.2 Your default Username is _____, Password is _____
- 2.3 Enter to see default display dashboard and interface

Email help@w-locate.com or call helpline to recover or change login password

3. Dashboard Display

This is the default interface




Default Interface

- (1) Menu
- (2) Assets Status Menu
- (3) Assets Position and History Records
- (4) Zones Selector
- (5) Date and Time
- (6) Map Interface
- (7) Log Off

(1) Menu

a. Zones: Management of Place of interest (POI)




Zone Page

Step 1 - Enter name of zone

Step 2 - Select zone types

Step 3 – Draw zones (you will be brought to zone drawing page)



Zone Drawing Page

Step 4 – Select Polygon or Circle drawing tool. Draw zone. Click OK. (you will be

re-directed back to zone page)

Step 5 – Click update to confirm creation of zone.

Step 6 – Repeat if necessary. End

You can create up to 10 zones. To create more, please contact our FIND sales

b. Assets: Management of Assets

The screenshot shows the 'ASSETS' tab in the FIND software interface. On the left, there is a sidebar with fields for 'Name', 'Category', 'Device', and 'Phone Number'. Below this is a section titled 'RESTRICTED ZONES'. The main area displays a table of assets with columns for 'NAME', 'CATEGORY', 'DEVICE', and 'PHONE NUMBER'. The table contains five rows:

	NAME	CATEGORY	DEVICE	PHONE NUMBER
01111	Vehicle	FA1	No Phone	
Car 99	Vehicle	SET2	No Phone	
sample	Vehicle		No Phone	
sample2	Vehicle		No Phone	

At the bottom of the screen, there is an 'ADD' button and a status bar indicating 'Caltex Petrol AMK' and the date '26-Feb-2011 21:04:38'.

Assets Page

Step 1 – Enter name of assets

Step 2 – Select types of assets (Personnel, Equipment or Vehicle)

Step 3 – Select GPS device (Information can be found on our invoice)

Step 4 – Select zones to associate to the assets. All interaction between the assets and the zones will be logged and can be viewed as reports.

Step 5 – Click Add to confirm.

Step 6 – Click

- Camera icon to tag a photograph to the assets
- Gear icon to edit the settings
- Bin icon to delete asset (user will be prompted to confirm delete)

c. Reports: Generate reports

The screenshot shows a 'REPORTS' section of the FIND software. The 'Report' dropdown is set to 'Event' and the 'Asset' dropdown is also set to 'Event'. The table below displays event logs from February 26, 2011. The columns include TIMESTAMP, REMARKS, ASSET, DEVICE, ACKNOWLEDGED BY, and TIME ACKNOWLEDGED. The table shows multiple entries for GPSLands devices (SGD623Z) with various remarks like 'Ignition' and 'Engine On/Off'. The status bar at the bottom indicates '56 events loaded'.

Reports Page (Text)

Step 1 – Select report types and filters

Events: Over 20 selectable statuses to be selected


Position: Filters by positions

Speed: Filters by Speed and Speed Limits

Utilization: Filters by usage

Step 3 – Enter necessary information to generate desired reports

Step 4 – Select to view text or chart based report





Reports Page (Charts)


Step 5 – Download report to computer

(2) Assets Status Menu

Features include

- **View all assets status**

Status (green) – signal received
Status (red) – no signal received



Do not be alarmed with no signal; assets may have momentarily travelled to a weak GPS or GPRS zone.



Buttons

- **Lock on to selected assets**
- **Text viewer** – when selected, a text based status will replace the map view

STATUS							
ASSET	DEVICE	BATTERY	SIGNAL	ALERT	POSITION TIMESTAMP	LOCATION	SPEED (kph)
Van 000	FA1	0	H S		20-Feb-2011 20:18:12	Jurong East Ave 1, Singapore, Singapore	0
Car 001	SET2	1992	H S		26-Feb-2011 22:07:50	37 Jalan Pemimpin, Bishan, Singapore	0
Truck 9	SI	0	H S		26-Feb-2011 22:06:14	Tampines Ave 5, Tampines Changkat, Singapore	0
Truck 5	SK	0	H S		19-Feb-2011 12:36:40		0

- Minimize vehicle status menu

(3) Assets Position and History Records

Features:

- Position of assets displayed on map
 - Properties related to the assets
- includes: name, address, speed, mileage / distance and movement



Asset Properties

-  Buttons
 - Camera icon to see photograph of the assets
 - Chain icon to see Historical Record (See below)

History Records




History Page

Step 1 – Select date and time, click refresh

Step 2 – Go through each point 1 by 1 or scrub and play with the slider (5 different playback speeds)

(4) Zones Selector

Selecting the zone you have created, the map interface will instantly bring you to the location.



Zone Selector


(5) Date and Time

Displays current date and time.

(6) Map Interface

Features selectable map views:

- Graphic map
- Satellite map



Satellite Selector

- Zoom in and out (use scale button or mouse scroller)
- Move map (use direction button or click and hold left mouse button)

(7) Log Off

To log off, click on the top right hand corner.

END