





Note for reference only and use the pins #'s in the root page of the schematic. Reason pin 7 and 8 were swapped: to get proper phasing of this sense loop. Sheet: /Antenna Diagram/ File: antenna\_diagram.kicad\_sch Title: SignalSnagger Size: A4 Date: 2024-02-16 KiCad E.D.A. kicad (6.0.4-0) Rev: 0.28 Id: 4/4